



Operation Manual

PRODUCT NAME

Solid State Auto Switch

MODEL / Series / Product Number

*D-M9*A**

SMC Corporation




Contents

| | |
|-----------------------------------|----|
| Safety Instructions | 2 |
| Model Indication and How to Order | 8 |
| Summary of Product parts | 10 |
| Summary of Product parts | 10 |
| Definition and terminology | 10 |
| Mounting and Installation | 11 |
| How to install | 11 |
| Internal circuit | 12 |
| Troubleshooting | 13 |
| Specification | 16 |
| Specifications | 16 |
| Dimensions | 17 |
| Operating range | 18 |

Safety Instructions

These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution", "Warning" or "Danger". They are all important notes for safety and must be followed in addition to International standards (ISO/IEC) ^{*1)} and other safety regulations.

- *1) ISO 4414: Pneumatic fluid power -- General rules relating to systems.
ISO 4413: Hydraulic fluid power -- General rules relating to systems.
IEC 60204-1: Safety of machinery -- Electrical equipment of machines. (Part 1: General requirements)
ISO 10218-1992: Manipulating industrial robots -Safety.
etc.

| | |
|--|--|
|  Caution : | CAUTION indicates a hazard with a low level of risk which, if not avoided, could result in minor or moderate injury. |
|  Warning : | WARNING indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury. |
|  Danger : | DANGER indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury. |

Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results. The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product. This person should also continuously review all specifications of the product referring to its latest catalogue information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly. The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.
3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.

1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalogue.
3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
4. Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.

Caution

The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries.

If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first. ^{*2)}

Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.

2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.

This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.

3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalogue for the particular products.

^{*2)} Vacuum pads are excluded from this 1 year warranty.

A vacuum pad is a consumable part, so it is warranted for a year after it is delivered.

Also, even within the warranty period, the wear of a product due to the use of the vacuum pad or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction (WMD) or any other weapon is strictly prohibited.
2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulation of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

Operator

- ◆ This operation manual is intended for those who have knowledge of machinery using pneumatic equipment, and have sufficient knowledge of assembly, operation and maintenance of such equipment. Only those persons are allowed to perform assembly, operation and maintenance.
- ◆ Read and understand this operation manual carefully before assembling, operating or providing maintenance to the product.

■ Safety Instructions

Warning

- Do not disassemble, modify (including change of printed circuit board) or repair.
An injury or failure can result.
- Do not operate the Auto switch beyond specification range.
Operation at a range that exceeds the specifications can cause a fire, malfunction, or damage to the Auto switch.
Verify the specifications before use.
- Do not use the Auto switch in an atmosphere containing combustible or explosive gas.
A fire or explosion can result.
This Auto switch is not an explosion-proof type.
- These instructions must be followed when using the Auto switch in an interlocking circuit:
- Provide double interlocking by another system such as mechanical protection.
- Check the Auto switch regularly to ensure proper operation.
Otherwise malfunction can cause an accident.

Caution

- Do not touch terminals and printed circuit board inside the switch.
Otherwise it can cause electric shock, malfunction or damage to the unit.
- After maintenance, perform the appropriate functional inspection.
Stop operation when the equipment or component does not function properly.
Safety may not be guaranteed when an unintended malfunction occurs.
- Be sure to confirm the wiring condition.
This series, including this product, is not equipped with excessive current protection.
Therefore, incorrect wiring and or a short-circuited load could damage and or burn this product.

■ NOTE

- Follow the instructions given below when designing, selecting and handling your Auto switch.
 - The instructions on design and selection (installation, wiring, environment of use, adjustment, operation, maintenance and etc.) described below must also be followed.
 - Do not place two or more actuators close together.
When using more than two Auto switches mounted parallel with each other, keep 40 mm or more between actuator tubes to prevent influence (malfunction) due to magnetic interference. (Keep the allowable displacement for each Auto switch if specified)
 - Detection of a piston by Auto switch mounted in the middle part of a cylinder stroke depends on the speed of the piston. Satisfy the conditional equation below.
Where the maximum detectable piston speed = V[mm/s]
- $$V[\text{mm/s}] = \frac{\text{Travel of auto switch [mm]}}{\text{Change over time of load [ms]}} \times 1000$$
- Reserve a space for maintenance.
Remember to leave space for maintenance when installing the product.

● Product handling

*Installation

- Follow the specified tightening torque. (0.05 to 0.15 N·m)
Excessive tightening torque can break the mounting screws, mounting bracket or Auto switch.
Insufficient tightening torque can displace the Auto switch from the original position. (Refer to the installation manual)
- Connect frame-ground terminal (FG terminal) to the ground when using a switching power supply.
- Do not drop, hit or apply excessive shock (larger than 1000 m/s²) to the Auto switch.
Otherwise it can result in damage to the Auto switch causing failure or malfunction.

*Wiring

- Do not pull the lead wires.

Especially never lift actuator equipped with Auto switch by holding the lead wires.
It can result in damage to inside of Auto switch causing malfunction.

- Do not bend or apply tensile stress to lead wires repeatedly.

Wiring with repetitive bending stress or tensile stress can cause peel of a sheath. If the lead wire can move, fix it near the body of the Auto switch.

A bend radius of about 40 to 80 mm is recommended. Contact us for the details.

- Connect wires and cables correctly.

Miswiring can break the Auto switch depending on the miswired circuit.

- Do not connect wires while the power is on.

Otherwise it can break the circuit inside the Auto switch causing malfunction.

- Do not lay wires or cables with power cable or high-voltage cable in the same wiring route.

Lay the wires to the Auto switch to a wire duct or in a protective tube other than those for power cables or high-voltage cables to prevent contamination with noise or induced surge voltage from power lines or high-voltage lines.

- Verify the insulation of wiring.

Poor insulation (interference with other circuit, poor insulation between terminals and etc.) can introduce excess voltage or current to the Auto switch causing damage.

- Keep wiring as short as possible to prevent contamination from noise and induced surge voltage.

Do not use a cable longer than 100 m.

- When stripping the cable envelope, please pay attention to the stripping direction.

Insulator might be split or hurt depending on the directions.



*Environment

- Never use the product for a corrosive gas or liquid.

It can cause failure or malfunction.

- Do not use the product in a place where strong magnetic field exists.

It can cause a malfunction of the Auto switch, or demagnetization of a magnet inside actuator.

- Do not use the Auto switch in an environment where the Auto switch is always splashed with water drips.

It can cause poor insulation or malfunction due to swelling of a resin filled inside the Auto switch.

- Do not use the product in an atmosphere containing oils or chemicals.

Use of the Auto switch in an atmosphere containing various oils or chemicals such as coolant or detergent can result in giving bad influence (poor insulation, malfunction due to swelling of a resin filled inside the Auto switch, or hardening of lead wires) even if in a short operating period.

- Do not use the product in an atmosphere where steel dusts accumulate or magnetic bodies are gathered closely.

When an amount of steel chips or steel dusts such as sputters of welding accumulate around an actuator equipped with Auto switch, or magnetic bodies (those attracted by magnet) are gathered closely to the actuator, they can weaken a magnet inside the actuator causing inoperativeness of the Auto switch.

- Do not use the product in an environment where heat cycle exists.

Heat cycles other than ordinary change of the temperature can affect the inside of Auto switch.

- Do not use the Auto switch nearby a place where electric surges are generated.

Internal circuit elements of Auto switch can deteriorate or break when equipment generating a large surge (electromagnetic lifter, high frequency induction furnace, motor, etc.) is located near the Auto switch. Provide surge preventives, and avoid interference.

- Do not use a load generating surge voltage.

Use Auto switch equipped with surge absorber when a surge-generating load such as a relay or solenoid valve is driven directly.

*Adjustment and Operation

- Adjust an Auto switch in the middle of operating area and then fix it.

Adjust the position of Auto switch in a way that a piston stops at about the middle of operating area (where switch is in ON status).

Mounting the Auto switch close to the end of operating area can cause instability of operation.

Air grippers and rotary actuators have their own setting method. Follow their instructions.

- Turn the power on after connecting a load.

Otherwise it can cause excess current causing instantaneous breakage of the Auto switch.

*Maintenance

- Perform maintenance and check regularly.


Otherwise safety is not assured due to an unexpected malfunction or incorrect operation.

- Do not touch terminals or printed circuit board inside the switch while the power is on.

Otherwise it can cause in malfunction or damage to AUTO switch.

*Others

- Contact SMC for water-proof capability, endurance of wire bending or use at welding shop.
- Contact SMC when there is a problem of switch's ON/OFF positions (hysteresis).



Model Indication and How to Order

D-M9 **A**

● Output type

| Symbol | Spec. |
|--------|-------------|
| N | 3-wire, PNP |
| P | 3-wire, NPN |
| B | 2-wire |

● Electric entry

| Symbol | Spec. |
|--------|---------------|
| NIL | In line |
| V | Perpendicular |


● Lead wire length

| Symbol | Spec. |
|--------|------------------------------|
| NIL | 500 mm (Half strip) |
| M | 1000 mm (Half strip) |
| L | 3000 mm (Half strip) |
| Z | 5000 mm (Half strip) |
| SAPC | 500 mm (M8 3 pin pre-wire) |
| SBPC | 500 mm (M8 4 pin pre-wire) |
| SDPC | 500 mm (M12 4 pin pre-wire) |
| MAPC | 1000 mm (M8 3 pin pre-wire) |
| MBPC | 1000 mm (M8 4 pin pre-wire) |
| MDPC | 1000 mm (M12 4 pin pre-wire) |


Summary of Product parts

◆ Summary of Product parts





D-M9BA/M9NA/M9PA



D-M9BAV/M9NAV/M9PAV



◆ Definition and terminology

| Term | Meaning and definition |
|---------------------------|---|
| Hysteresis | <p>The difference between the points when the Auto switch turns on and off, which is provided to prevent chattering.</p>  |
| Most sensitive position | The center position of the sensor unit (which gets the strongest reaction of the sensor unit), which means the center position of an operating range as well. |
| Sequence controller (PLC) | The device to perform sequence control, which performs controlling such as receipt of inputs from the Auto switch along with programming and sending of the output to other machines. |
| Internal voltage drop | The voltage applied between the COM and signal line when the Auto switch turns on. |
| Current leakage | The current flowing to the load when the Auto switch turns off. |
| Load current | The current flowing to the load when the Auto switch turns on. |
| Solid state auto switch | Auto switch which generates on and off outputs with or without mechanical contact such as a transistor. |
| Reed auto switch | Auto switch which generates on and off outputs with a mechanical contact. |
| 2-wire auto switch | Auto switch which has only signal line and COM line. |
| NPN output | <p>Auto switch which sinks current from the signal line when turning on.</p>  |
| PNP output | <p>Auto switch which sources current from the signal line when turning on.</p>  |
| 2-color indication | <p>A type of indicating methods which lights up the red LED light up when the Auto switch comes to the operating position, and lights up the green LED when the Auto switch comes to the optimum operating position.</p>  |

Mounting and Installation

◆ How to install

When mounting the Auto switch to actuator it should be done with clamp for actuator.


“How to mount” depends on actuator type and tube I.D. Please refer the actuator catalogue.

When the Auto switch is mounted newly, please prepare the clamp for actuator after confirms that the actuator built in magnet.

• Proper tightening torque

Use a watchmaker driver whose grip diameter is 5 to 6mm when tightening the mounting screw.

M2.5 mount screw tightening torque range shall be 0.05 to 0.15N•m (0.5 to 1.5kgf•cm)



• Setting the detecting position

Set the actuator at the stroke end. Set the switch in the area to where the auto switch red lamp light.

(Detecting actuator end)


Based on A and B dimensions in the actuator catalogue, set the switch.

For actual installation works, perform adjustment with checking the operating conditions of the Auto switch.


Air grippers and rotary actuators have their own setting method. Follow their instructions.

◆ Internal circuit


D-M9NA(V)




D-M9PA(V)



D-M9BA(V)(Sink input mode)




D-M9BA(V)(Source input mode)



Note) The number marked on each lead wire color shows the pin number of pre-wired connector.

Troubleshooting

When the auto switch falls in operation failure, identify the trouble with the following flow chart.
A failure of the auto switch might depend on operating environment (application etc.) and needs to be given a measure by contacting to us separately.



◆ Trouble list

| Trouble No. | Trouble | Possible cause | Investigation to find possible cause | Countermeasure |
|-------------|--|--|--|--|
| 1 | The switch output doesn't turn off. The operation LED doesn't go off. | Malfunction due to disturbance magnetic field | The effect of magnetic field generated by adjacent actuator | Place a magnetic shield plate to the actuator. |
| | | Improper setting (mounting) position *Narrow angle | The presence of the following conditions - Switch operating angle - Actuator operating angle | Displace the switch set position from the center of the actuator operating range. |
| 2 | The switch output doesn't turn off. The operation LED doesn't light up. | Switch failure (2-wire type) | Check the switch wiring for any converse connection (brown, blue). | Correct wiring (refer to the internal circuit on P12). |
| | | Switch failure (3-wire type) | | Replace the switch. |
| 3 | The switch output doesn't turn off. The operation LED operates properly. | Incorrect wiring | Reverse connection of switch wiring (blue and black) | Correct wiring. |
| | | Wiring failure (3-wire type) | Check switch wiring for any converse connection (brown, blue) | Correct wiring (refer to the internal circuit on P12). |
| 4 | The switch output doesn't turn on. The operation LED doesn't light up. | Power supply failure | Power supply voltage (zero or extremely low) | Adjust power supply voltage to a given value (refer to power voltage and load voltage on P16). |
| | | Incorrect wiring | Voltage (load) applied to the switch | Correct wiring (refer to the internal circuit on P12). |
| | | Improper setting (mounting) position | Detection close to the limit of switch operating angle | Move the switch to proper position (near the center of the switch operating angle). |
| | | Displacement from set position | Looseness of the switch unit or switch mounting screw | Fix to proper position at appropriate torque Tightening torque range: 0.05 to 0.15N•m |
| | | Displacement of the actuator stopping angle | Deviation of the actuator stopping angle (position) | Stabilize stop position. (Correct decentrality and cushion.) |
| | | Lowering of magnetic force for detection (demagnetization) | The presence of magnetic filed source near the actuator (electric welding machine conductor and strong magnet, etc.) | Place a magnetic shield plate between magnetic filed source and the actuator. |
| | | | The effect of magnetic field generated by adjacent actuator (placed within 20mm) | Separate the actuator (by 40mm or more). Place a magnetic shield plate. |
| | | | The presence of deposit of magnetic material (cutting chip) on the actuator. | Remove the magnetic deposit. |
| | | Breakage of lead wire | The presence of repeated bending stress to a part of lead wire. (Bending radius, tensile force to the lead wire) | Correct wiring. (Adjust tensile force and enlarge bending radius) |


| Trouble No. | Trouble | Possible cause | Investigation to find possible cause | Countermeasure |
|-------------|---|---|--|--|
| 5 | The switch output doesn't turn on. The operation LED operates properly. | Non-conformity to load specification (2-wire type) | Check whether load spec. satisfies the following equation. Load voltage-(switch internal voltage drop x n) n: # of switch connected in series | Change the switch to 3-wire type or reed switch. Decrease the number of switch connected in series until the equation is satisfied. |
| | | Incorrect wiring (output line) (3-wire type) | Condition of connected part (connector contact pin and crimping terminal) | Correct wiring. (Perform wiring of connected part again.) |
| | | Breakage of lead wire (black) (3-wire type) | The presence of repeated bending stress to a part of lead wire. (Bending radius, tensile force to the lead wire) | Correct wiring. (Adjust tensile force and enlarge bending radius) |
| 6 | The operation is unstable. (chattering) | Improper setting (mounting) position | Detection close to the limit of switch operating angle | Move the switch to proper position (near the center of the switch operating angle). |
| | | Displacement from set position | Looseness of the switch unit or switch mounting screw | Fix to proper position at appropriate torque. Tightening torque range: 0.05 to 0.15N•m |
| | | Incorrect wiring | Condition of connected part (connector contact pin and crimping terminal) | Correct wiring. (Perform wiring of connected part again) |
| | | Breakage of lead wire | The presence of repeated bending stress to a part of lead wire. (Bending radius, tensile force to the lead wire) | Correct wiring. (Adjust tensile force and enlarge bending radius) |
| | | Malfunction due to disturbance magnetic field | The presence of magnetic field source near the actuator. (Cylinder, electric welding machine conductor, motor, magnet etc.) | Place a magnetic shield plate between magnetic field source and the actuator, or separate magnetic field source from the actuator. |
| | The switch operates at multiple points. | Malfunction due to disturbance magnetic field | The effect of magnetic field generated by adjacent actuator | Place a magnetic shield plate to the actuator. |
| | The load doesn't work. | Operating angle range Detection at intermediate position | Satisfaction of the following relations by the actuator rotation speed. Load operating time [s] < Auto switch operating angle range [mm] / Actuation operating speed [mm/s] | Decrease the actuating driving speed until specified relations can be satisfied. |

Specification


◆ Specifications

| Switch part no. | D-M9NA | D-M9NAV | D-M9PA | D-M9PAV | D-M9BA | D-M9BAV |
|-----------------------|--|---------------|---------|---------------|-----------------------|---------------|
| Wiring | 3-wire | | | | 2-wire | |
| Output | NPN | | PNP | | - | |
| Lead wire orientation | In line | Perpendicular | In line | Perpendicular | In line | Perpendicular |
| Applicable load | IC circuit/Relay/PLC | | | | 24 VDC Relay/PLC | |
| Power supply voltage | 5/12/24 VDC (4.5 to 28 VDC) | | | | - | |
| Current consumption | 10mA or less | | | | - | |
| Load voltage | 28 VDC or less | | - | | 24 VDC (10 to 28 VDC) | |
| Load current | 40 mA or less | | | | 2.5 to 40 mA | |
| Internal voltage drop | 0.8 V or less at load current of 10 mA (2 V or less at load current of 40 mA) | | | | 4.0 V or less | |
| Current leakage | 100 μ A or less at 24 VDC | | | | 0.8 mA or less | |
| Operating time | 1 ms or less | | | | | |
| Indication light | Operating position: The red LED lights up. Optimum operating position: The Green LED lights up. | | | | | |
| Electrical entry | Grommet | | | | | |
| Lead wire | Vinyl sheath cable 2.7 \times 3.2 oval, 0.15 mm ² , 2-wire (D-M9BA(V)), 3-wire (D-M9NA(V),D-M9PA(V)) | | | | | |
| Impact proof | 1000 m/s ² | | | | | |
| Insulation resistance | 50 M Ω or more under the test voltage 500 VDC (between case and cable) | | | | | |
| Withstand voltage | 1000 VAC 1min (between case and cable) | | | | | |
| Ambient temperature | -10 to 60 $^{\circ}$ C | | | | | |
| Enclosure | IEC 60529 criteria IP67, JISC0920 watertight construction | | | | | |

◆ Dimensions
OD-M9BA, NA, PA



OD-M9BAV, NAV, PAV



◆ Operating range

Unit: Operating range [mm]

Air cylinder Unit: Operating range [mm]

| Series / Bore size | 4 | 6 | 8 | 10 | 12 | 15 | 16 | 20 | 25 | 32 | 40 | 50 | 63 | 80 | 100 | 200 |
|--------------------|---|-----|---|----|-----|-----|----|-----|-----|-----|-----|-----|-----|----|-----|-----|
| CQS | — | — | — | — | 2.5 | — | 3 | 4.5 | 4.5 | — | — | — | — | — | — | — |
| CQ2 | — | — | — | — | — | — | — | — | — | 5.5 | 4.5 | 4 | 5.5 | 5 | 5.5 | — |
| RQ | — | — | — | — | — | — | — | 4.5 | 4.5 | 5.5 | 4.5 | 5 | 6 | 8 | 7.5 | — |
| CXT | — | — | — | — | 2.5 | — | 3 | 4.5 | 4.5 | 5 | 4.5 | — | — | — | — | — |
| CLQ | — | — | — | — | 2.5 | — | 3 | 4.5 | 4.5 | — | — | — | — | — | — | — |
| MK | — | — | — | — | 2 | — | 3 | — | — | 5 | 4.5 | 5 | 5 | — | — | — |
| MK2 | — | — | — | — | — | — | — | — | — | 5 | 5 | 5 | 5 | — | — | — |
| RSQ | — | — | — | — | 2.5 | — | — | — | — | 5.5 | 4.5 | 4 | — | — | — | — |
| CEP1 | — | — | — | — | 2.5 | — | — | 3.5 | — | — | — | — | — | — | — | — |
| CE1 | — | — | — | — | — | — | — | — | — | 5 | 5 | 5.5 | 5.5 | — | — | — |
| CXSJ | — | 2.5 | — | 3 | — | 3.5 | — | 4 | 4 | 4.5 | — | — | — | — | — | — |
| RZQ | — | — | — | — | — | — | — | — | — | 4.5 | 4.5 | 5 | 5 | — | — | — |
| CY1R | — | 3.5 | — | 5 | — | 5 | — | 4 | — | — | — | — | — | — | — | — |
| RLQ | — | — | — | — | — | — | — | — | — | 5.5 | 4.5 | 5 | 6 | — | — | — |

| Coolant valve /series | 200 | 300 | 400 |
|-----------------------|-----|-----|-----|
| SGC | 3 | 3.5 | 3.5 |

| Series / Bore size | Section | 6 | 8 | 10 | 12 | 15 | 16 | 20 | 25 | 30 | 32 | 40 | 50 | 63 | 80 |
|--------------------|---------|------------|-----|----|-----|-----|----|-----|-----|-----|----|-----|-----|-----|-----|
| MHZJ2 | M9W | Hysteresis | 0.5 | — | 0.5 | — | — | 0.3 | 0.8 | 0.5 | — | 0.7 | 1 | — | — |
| MHK2 | M9W | Hysteresis | — | — | — | 0.3 | — | 0.4 | 0.4 | 0.4 | — | — | — | — | — |
| MHSJ3 | M9W | Hysteresis | — | — | — | — | — | 0.3 | 0.3 | 0.4 | — | 0.6 | 0.6 | 0.6 | 0.6 |
| MHT2 | M9W | Hysteresis | — | — | — | — | — | — | — | — | 3 | 3 | 3 | 3 | — |
| MHQJ2 | M9W | Hysteresis | — | — | 0.5 | — | — | 0.5 | 0.5 | 0.5 | — | — | — | — | — |

| Revision history |
|---|
| A: Modify the contents. |
| B: Limited warranty and Disclaimer are added. |

SMC Corporation

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021 JAPAN

Tel: +81 3 5207 8249 Fax: +81 3 5298 5362

URL <http://www.smcworld.com>

Note: Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.

© 2006-2013 SMC Corporation All Rights Reserved



No.D-※S-OMK0010-B