Centring Unit

New

Alignment and positioning of transferred workpieces



Heavy workpieces can now be aligned and positioned with small cylinders,

resulting in compact conveyor lines.






Table Max. allowable load weight: 1000

Workpieces can be moved in any direction: forward/backward, right/left, at an angle, and even rotated (360°).

Ball bearings allow for smooth operation.

Table Centring accuracy

mm or less not loaded)

(Workpiece





Table centre movable range

Max. Ø 100 mm (MACM10-50)



3 types of table material can be selected.



Ultra high molecular weight polyethylene





For lock/unlock confirmation External photo sensor mountable

Select from lock port side or opposite side of port installation.





Built-in air locking mechanism

Table can be held in any position.



MACM Series




Centring Unit MACM Series

<Application Examples>

Conveyor Line


1 Transferred workpieces are stopped

Workpieces transferred at an angle are stopped at an alignment point (stops where the Centring unit is installed).



2 Centring unit rises


Cylinder rises to lift the workpiece (separates roller conveyor from workpiece).




3 Workpiece alignment/table lock

Alignment cylinder corrects skewed workpieces and realigns them.

After alignment, the table of the Centring unit is locked to maintain the corrected position even after the adjustment cylinders are released.



4 Centring unit descends/workpiece is transferred to next step





Liquid Crystal Cassette Transfer

1 Stops in front of rack

2 Is stored in rack

Is transferred to and stopped in front of the rack where skewed liquid crystal cassettes are to be stored






3 Alignment of cassette/table lock


The alignment cylinder corrects skewed workpieces and aligns the liquid crystal cassettes.

After alignment, the table of the Centring unit is locked to maintain the corrected position even after the alignment cylinders are released.




Working Principle

Neutral (Centring) condition



Movable condition




- When a force is applied to ① the table in the lateral direction, ② the bearing slides. When the bearing slides, ③ the spring for returning to centre also expands and contracts.
- When the force in the lateral direction is released, ④ the centre shaft is returned to the neutral position by ③ the spring for returning to centre.

Lock Mechanism


Unlocked condition

The table becomes free when unlocked.




Locked condition

The table is locked in place when locked.



- When air is supplied from the locking port, 6 the piston for locking descends and pushes 4 the centre shaft down. When 4 the centre shaft lowers, 5 the bearing holder plate is pressed, and the table is locked.
- When air is supplied from the unlocking port, (§) the piston for locking ascends and releases the lock.

Centring Unit MACM Series



⚠ Precautions

Be sure to read this before handling I the products. For safety instructions, I actuator and auto switch precautions, I refer to the "Handling Precautions for I SMC Products" and the "Operation I Manual" on the SMC website: http:// I www.smc.eu

Specifications

N

	Model	MACM2-12	MACM4-20	MACM6-30	MACM10-50							
Max. allowab	le load weight [KN]	2	4	6	10							
Stroke [mm]		12	20	30	50							
Table centre	movable range [mm]	Ø 24	Ø 40	Ø 60	Ø 100							
Centring acc	uracy [mm]	±1 or less										
	Action	Double acting										
	Fluid	Air										
Cylinder for	Operating temperature [°C]	0 to 60										
lock	Operating pressure [MPa]	0.4 to 0.7										
	Proof pressure [MPa]	1										
	Lubrication	Non-lube										
Weight [kg]		0.7	1	2	7							

Ultra high molecular weight polyethylene

Cast nylon

Operating Precautions

⚠ Caution

- 1. Use the product within the movable range.
- 2. Use the product within the allowable load weight.
- 3. Load workpieces within the load range.
- 4. Load workpieces within the allowable inclination range.
- 5. Do not use the product in applications where excessive external force or impact force is applied to it.

Improper handling includes the following:


- · Applying impact on the side of the table to move it to full stroke
- \cdot Continuously moving the table in a circle while the table is at a full stroke
- · Repeating reciprocation of the table at full stroke
- · Holding the body and swinging the table
- 6. Prevent over strokes.
- Secure the table in place when transporting the product or the equipment it is mounted on.
- 8. This is not a clean room series product.





MACM Series

Dimensions


MACM4, MACM6







MACM2, MACM10








Table type U or N



At maximum offset



[mm]

п	im	en	ci	0	20
$\boldsymbol{\nu}$	Ш	GII	SI	U	113

Difficultions [IIIII]														[111111]							
Mode	el	Α	В	С	D	DA	DB	Е	F	Н	Р	PA	PB	PC	PD	PE	Q	S	Т	U	W
MACM2	S, G					60	64		30	46				22.5°	7	10°	27.4	12	_	_	
	U	68 74	74	76						52									6	62	34
	N									50									4	02	
MACM4	S, G						78 12		32.5	50				7 18°		19	32	20	_	_	33
	U	86	90	90	6.6	72		12		56	M5 1	19	17						6	78	40
	N									54									4	70	40
МАСМ6	S, G					97	113		33.8	53									_	_	43
	U	118	125	125						59									6	98	60
	N									57									4	90	60
MACM10	S, G				11	152	182	18	53.8	77			24	13°		0°	53.3		_	_	
	U	J 185	5 197	198						83		31						50	6	108	70
	N									81									4	100	
		185	197	198	11	152	182	18	53.8			31	24	13°		0°	53.3	50		108	7


Dimensions

P: Port side photo sensor mounted type

B: Port back side photo sensor mounted type




P: Port side photo sensor mounted type





Mounted example of EE-SX671□ made by OMRON



- * The above photo sensor made by OMRON should be provided by the customer.
- * Mounting position adjustment may be required depending on the individual differences of the sensor.



SMC Corporation (Europe)

Austria 🕿 +43 (0)2262622800 www.smc.at office@smc.at Lithuania *****+370 5 2308118 www.smclt.lt info@smclt.lt Belgium **2** +32 (0)33551464 info@smcpneumatics.be www.smcpneumatics.be **Netherlands 2** +31 (0)205318888 info@smcpneumatics.nl www.smcpneumatics.nl Bulgaria ***** +359 (0)2807670 www.smc.bg office@smc.bg Norway *****+47 67129020 www.smc-norge.no post@smc-norge.no Croatia **2** +385 (0)13707288 www.smc.hr office@smc.hr Poland office@smc.pl **3** +48 222119600 www.smc.pl Czech Republic *****+420 541424611 office@smc.cz www.smc.cz **Portugal ***+351 226166570 www.smc.eu postpt@smc.smces.es Denmark **2** +45 70252900 www.smcdk.com smc@smcdk.com Romania **2** +40 213205111 smcromania@smcromania.ro www.smcromania.ro Estonia ***** +372 6510370 www.smcpneumatics.ee smc@smcpneumatics.ee Russia ***** +7 8127185445 www.smc-pneumatik.ru info@smc-pneumatik.ru Finland ***** +358 207513513 www.smc.fi smcfi@smc.fi Slovakia office@smc.sk ***** +421 (0)413213212 www.smc.sk France **2** +33 (0)164761000 www.smc-france.fr info@smc-france.fr ***** +386 (0)73885412 office@smc.si Slovenia www.smc.si Germany **2** +49 (0)61034020 www.smc.de info@smc.de Spain ***** +34 902184100 www.smc.eu post@smc.smces.es **2** +30 210 2717265 www.smchellas.gr sales@smchellas.gr **2** +46 (0)86031200 Greece Sweden post@smc.nu www.smc.nu Hungary ***** +36 23511390 office@smc.hu www.smc.hu Switzerland *****+41 (0)523963131 info@smc.ch Ireland **2** +353 (0)14039000 www.smcpneumatics.ie sales@smcpneumatics.ie Turkey www.smcpnomatik.com.tr ***** +90 212 489 0 440 info@smcpnomatik.com.tr Italy **2** +39 0292711 www.smcitalia.it mailbox@smcitalia.it ### +44 (0)845 121 5122 www.smcpneumatics.co.uk sales@smcpneumatics.co.uk UK

info@smclv.lv

2 +371 67817700

www.smclv.lv

Latvia