

Operation Manual

PRODUCT NAME

Vacuum gripper unit

MODEL / Series / Product Number

ZXP7*01-****-X1

The outward appearance showed on this manual is an example of the vacuum gripper unit with suction cups which is indicated by the product number: ZXP7A01-ZPB25JS-X1. Refer to the suction cup catalog for the detail of other applicable suction cups.

SMC Corporation

Contents

Safety instructions	2
1. Parts included in the package	
2. Names of Parts of the Product	7
3. Specifications	8
3.1. Specifications	8
3.2. Flow rate / Exhaust characteristics	9
3.3. How to calculate theoretical lifting force	10
3.4. How to order	
4. Mounting	12
4.1. Mounting	12
4.2. Wiring	14
4.3. Piping	15
4.4. URCap	16
5. Dimensions	21
5.1. Vacuum gripper unit	21
5.2. Suction cup with adapter	22
6. How to change the number of cups	24
6.1 Change to 1 cup (with flange)	24
6.2 Change to 1 cup (without flange)	25
6.3 Change to 2 cups	
7.Maintenance	27
7.1. Maintenance for vacuum gripper unit	27
7.2. Maintenance for suction cup	28
8.Precautions	29
8.1 Air supply	
8.2 Vacuum gripper unit precautions	
8.3 Suction cup precautions	31
9.Trouble shooting	



These safety instructions are intended to prevent hazardous situations and/or equipment damage. These instructions indicate the level of potential hazard with the labels of "Caution," "Warning" or "Danger." They are all important notes for safety and must be followed in addition to International Standards (ISO/IEC)*1), and other safety regulations.


*1) ISO 4414: Pneumatic fluid power -- General rules relating to systems.

ISO 4413: Hydraulic fluid power -- General rules relating to systems.

IEC 60204-1: Safety of machinery -- Electrical equipment of machines .(Part 1: General requirements)

ISO 10218: Manipulating industrial robots -Safety.

etc.



Λ Warning

1. The compatibility of the product is the responsibility of the person who designs the equipment or decides its specifications.

Since the product specified here is used under various operating conditions, its compatibility with specific equipment must be decided by the person who designs the equipment or decides its specifications based on necessary analysis and test results.

The expected performance and safety assurance of the equipment will be the responsibility of the person who has determined its compatibility with the product.

This person should also continuously review all specifications of the product referring to its latest catalog information, with a view to giving due consideration to any possibility of equipment failure when configuring the equipment.

2. Only personnel with appropriate training should operate machinery and equipment.

The product specified here may become unsafe if handled incorrectly.

The assembly, operation and maintenance of machines or equipment including our products must be performed by an operator who is appropriately trained and experienced.

3. Do not service or attempt to remove product and machinery/equipment until safety is confirmed.

- 1. The inspection and maintenance of machinery/equipment should only be performed after measures to prevent falling or runaway of the driven objects have been confirmed.
- 2. When the product is to be removed, confirm that the safety measures as mentioned above are implemented and the power from any appropriate source is cut, and read and understand the specific product precautions of all relevant products carefully.

3. Before machinery/equipment is restarted, take measures to prevent unexpected operation and malfunction.

- 4. Contact SMC beforehand and take special consideration of safety measures if the product is to be used in any of the following conditions.
 - 1. Conditions and environments outside of the given specifications, or use outdoors or in a place exposed to direct sunlight.
 - 2. Installation on equipment in conjunction with atomic energy, railways, air navigation, space, shipping, vehicles, military, medical treatment, combustion and recreation, or equipment in contact with food and beverages, emergency stop circuits, clutch and brake circuits in press applications, safety equipment or other applications unsuitable for the standard specifications described in the product catalog.
 - 3. An application which could have negative effects on people, property, or animals requiring special safety analysis.
 - 4.Use in an interlock circuit, which requires the provision of double interlock for possible failure by using a mechanical protective function, and periodical checks to confirm proper operation.





Safety Instructions

Caution

The product is provided for use in manufacturing industries.

The product herein described is basically provided for peaceful use in manufacturing industries. If considering using the product in other industries, consult SMC beforehand and exchange specifications or a contract if necessary.

If anything is unclear, contact your nearest sales branch.

Limited warranty and Disclaimer/Compliance Requirements

The product used is subject to the following "Limited warranty and Disclaimer" and "Compliance Requirements".

Read and accept them before using the product.

Limited warranty and Disclaimer

1. The warranty period of the product is 1 year in service or 1.5 years after the product is delivered, whichever is first.*2)

Also, the product may have specified durability, running distance or replacement parts. Please consult your nearest sales branch.

2. For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided.

This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.

- 3. Prior to using SMC products, please read and understand the warranty terms and disclaimers noted in the specified catalog for the particular products.
 - *2) Suction cups are excluded from this 1 year warranty.

A suction cup is a consumable part, so it is warranted for a year after it is delivered. Also, even within the warranty period, the wear of a product due to the use of the suction cup or failure due to the deterioration of rubber material are not covered by the limited warranty.

Compliance Requirements

- 1. The use of SMC products with production equipment for the manufacture of weapons of mass destruction(WMD) or any other weapon is strictly prohibited.
- 2. The exports of SMC products or technology from one country to another are governed by the relevant security laws and regulation of the countries involved in the transaction. Prior to the shipment of a SMC product to another country, assure that all local rules governing that export are known and followed.

▲ Caution

SMC products are not intended for use as instruments for legal metrology. Measurement instruments that SMC manufactures or sells have not been qualified by type approval tests relevant to the metrology (measurement) laws of each country.

Therefore, SMC products cannot be used for business or certification ordained by the metrology (measurement) laws of each country.



Explanation of Symbols

Symbol	Definition
\bigcirc	Things you must not do. Instructions are provided as a drawing or sentence next to the symbol.
0	Things you must do Instructions are provided as a drawing or sentence next to the symbol.

Operator

- 1. This Operation Manual is intended for those who have knowledge of machinery using pneumatic equipment, and have sufficient knowledge of assembly, operation and maintenance of such equipment. Only those persons are allowed to perform assembly, operation and maintenance.
- 2. Read and understand this Operation Manual carefully before assembling, operating or providing maintenance to the product.

Safety Instructions

	[▲] Warning
Disassembly prohibited	Do not disassemble, modify (including the replacement of board) or repair other than instructed in this manual. Otherwise, an injury or failure can result.
Do not	Do not operate the product outside of the specifications. Do not use for flammable or harmful fluids. Fire, malfunction, or damage to the product can result. Please check the specifications before use.
Do not	Do not use in an atmosphere containing flammable or explosive gases. Fire or an explosion can result. The product is not designed to be explosion proof.
Do not	Do not use the product in a place where static electricity is a problem. Otherwise failure or malfunction of the system can result.
Do not	Do not cut off the power and compressed air supplied to this product while it is operating. Otherwise it can cause injury due to dropping of workpieces or damage to the system.
Instruction	If using the product in an interlocking circuit - Provide a double interlocking system, for example a mechanical system. - Check the product for proper operation. Otherwise malfunction can result, causing an accident.
Instruction	 The following instructions must be followed during maintenance Turn off the power supply Stop the air supply, exhaust the residual pressure in piping and verify that the air is released before performing maintenance work. It may cause an injury.

	⚠ Caution
Do not touch	Do not touch the terminals and connectors while the power is on. Otherwise electric shock, malfunction or damage to the switch can result.
Instruction	Perform sufficient trial run. Otherwise, injury or damage to the system can result due to suction failure depending on the conditions of the suction of the workpiece or the pressure switch settings. Perform sufficient verification before using this product.
O Instruction	After maintenance is complete, perform appropriate functional inspections and leak test. Stop operation if the equipment does not function properly or there is leakage of fluid. If there is leakage from parts other than the piping, the product might be broken. Cut off the power supply and stop the fluid supply. Do not supply fluid if there is leakage. Safety cannot be assured in the case of an unexpected malfunction.

Precautions for Handling

Follow the instructions given below for selecting and handling of the vacuum gripper unit.

***Product specifications**

- It is recommended to use compressed air which purity class is 2:6:3 of ISO8573-1:2010.
- The applicable fluid is air.

Do not use a fluid containing chemicals, synthetic oils including organic solvent, salt and corrosive gases. Otherwise, damage to the vacuum gripper unit and malfunction can result.


- Use the specified operating pressure.
- Reserve a space for maintenance.
- Design the system allowing the required space for maintenance.
- Use the specified voltage. Otherwise failure or malfunction can result.
- Do not exceed the specified maximum allowable load. Otherwise it can cause damage or shorten the life of the product.
- Design the product to prevent reverse current when the circuit is opened or the product is forced to operate for operational check. Reverse current can cause malfunction or damage the product.

***Operating environment**

- Do not use in an environment where corrosive gases, chemicals, sea water, water or steam are present.
- Do not use the product in a place where the product could be splashed by oil or chemicals. If the product is to be used in an environment containing oils or chemicals such as coolant or cleaning solvent, even for a short time, the colonadid value or processor may be adversally affected (damage, malfunction, or herdening).
- short time, the solenoid valve or pressure switch/sensor may be adversely affected (damage, malfunction, or hardening of the lead wires).
 Do not use in an area where surges are generated.
- When there are machines or equipment that generate large surge near the pressure switch/sensor (magnetic type lifter, high frequency inductive furnace, motor, etc.), this can result in deterioration and damage of the internal elements. Take measures against the surge sources, and prevent the lines from coming into close contact. - Do not use a load which generates surge voltage.
- When a surge-generating load such as a relay or solenoid is directly driven, use the product with a surge absorbing element built-in.
- Mount the product in a location that is not affected by vibration or impact.
- It will cause failure or malfunction.
- Do not use the product in an environment that is exposed to temperature cycle.
- Heat cycles other than ordinary changes in temperature can adversely affect the inside of the product.
- Do not expose the product to direct sunlight.
- If using in a location directly exposed to sunlight, protect the product from the sunlight.
- Keep within the specified operating fluid and ambient temperature range.
 Operation under low temperature may lead to damage or operation failure due to frozen moisture in the fluid or air.
 Protection against freezing is necessary. Mounting of an air dryer is recommended for elimination of drainage and water.
 Avoid abrupt temperature changes even within the specified temperature range.
- Do not use in a location where the product is exposed to radiant heat from surrounding heat sources. Insufficient air quality may cause operation failure.




1. Parts included in the package



* Download the URCap from the SMC website and then store it in your USB memory.

2. Names of Parts of the Product



3.1. Specifications

Product specifications

	Mechanical int	erface standard	Compliant with "ISO9409-1-50-4-M6"				
	Fluid		Air				
	Operating temp	erature range[°C]	5 to 50				
	Connector type		M8/8PIN (Female)				
Common		ZXP7N01-X1	612				
	Weight [g]	ZXP7A01-X1	840				
	Weight [9]	Example) ZXP7A01-ZPB25JS-X1	896 note1)				
	Max. workload	[kg] Note2)	7				
	Impact / Vibrati	on resistance [m/s ²] Note3)	150 / 30				
	Air supply port(P)	One touch fitting (Φ6)				
	Power supply v	oltage [V]	DC24 ± 10%				
	Max. vacuum p	ressure [kPa] note4)	-84				
	Max. suction flo	ow [L/min(ANR)] note4)	17				
Vacuum ejector	Air consumption	n [L/min(ANR)] note4)	57				
Cjector	Supply pressur	e range [MPa]	0.3 to 0.55				
	Standard suppl	y pressure [MPa]	0.5				
	Rated pressure	range [kPa]	0 to -101				
Dragouro	Accuracy [%] (A	Ambient temperature at 25°C)	±2 F.S. (with rated pressure range)				
Pressure sensor	Linearity [%]		±0.4 F.S.				
	Repeatability [%	6]	±0.2 F.S.				
	Temperature ch	aracteristics [%]	±0.2 F.S. (Based on 25°C)				
Applicable s	suction cups		Refer to "3.4. How to order"				

Note 1) The weight changes by the selected suction cup. Refer to "3.4 How to order".

Note 2) Limited by the cup diameter, mounting orientation or workpiece. The weight of the workpiece shall be maximum workload or less.

Adsorption or transfer of workload exceeding the maximum workload leads to the decrease of vacuum due to air leakage.

Note 3) Impact resistance: The characteristics are satisfied after tested one time in each of the X, Y and Z directions without energization. (Initial value)


Vibration resistance: The characteristics are satisfied after tested a one sweep in each of the X, Y and Z directions at 10 to 500 Hz without energization. (Initial value)

Note4) Values at the standard supply pressure. Values are based on standard of SMC measurements. They depend on atmospheric pressure (weather, altitude, etc.) and measurement method.


3.2. Flow rate / Exhaust characteristics

Flow rate / Exhaust characteristics.

The flow rate characteristics correspond to the standard supply pressure (0.5MPa).



* The actual suction flow at the point of suction varies depending on the piping conditions to the vacuum port.



How to read the flow rate characteristics Graph

Flow rate characteristics are expressed in ejector vacuum pressure and suction flow. If suction flow changes, the vacuum pressure will also be changed. Normally this relationship is expressed in ejector standard operating pressure use. In the graph, Pmax is maximum vacuum pressure and Qmax is maximum suction flow. The values are specified according to catalog use. Changes in vacuum pressure are expressed in the below order.

- 1. When the ejector suction port is covered and made airtight, the suction flow becomes zero and vacuum pressure is at the maximum value (Pmax).
- 2. When the suction port is opened gradually, air can flow through, (air leakage), suction flow increases, but vacuum pressure decreases. (condition P1 and Q1)

3. When the suction port is opened further and fully opened, suction flow moves to the maximum value (Qmax), but vacuum pressure is near zero (atmospheric pressure).

As described above, the vacuum pressure changes when the suction flow changes. In other words, when there is no leakage from the vacuum port, the vacuum pressure can reach its maximum, but as the amount of leakage increases, the vacuum pressure decreases. When the amount of leakage and the maximum suction flow become equal, the vacuum pressure becomes almost zero.


In the case when a ventilative or leaky workpiece should be adsorbed, take note that vacuum pressure will not rise.

3.3. How to calculate theoretical lifting force

*This manual shows how to calculate theoretical lifting force only. Refer to the catalog of suction cups for further detail of suction cup selection method.

How to calculate theoretical lifting force

The theoretical lifting force of a cup can be found by calculation or from the theoretical lifting force table.



Theoretical lifting force table

The theoretical lifting force (not including the safety factor) can be determined by the cup diameter and vacuum pressure.

The required lifting force can then be determined by dividing the theoretical lifting force by the safety factor t.


Lifting force = Theoretical lifting force / t

Theoretical lifting force (Theoretical lifting force = P x S x 0.1) **Cup diameter (Φ8 to Φ32)**

Cup diameter (Ф8 to Ф32) [N]												
Cup diameter [r	Cup diameter [mm]			Φ13	Φ16	Ф20	Φ25	Ф32				
S: Cup area [cr	S: Cup area [cm ²]			1.33	2.01	3.14	4.91	8.04				
	-85	4.2	6.6	11	17	26	41	68				
	-80	4.0	6.2	10	16	25	39	64				
	-75	3.7	5.8	10	15	23	36	60				
Vaauum	-70	3.5	5.5	9.3	14	22	34	56				
Vacuum	-65	3.2	5.1	8.6	13	20	31	52				
pressure [kPa]	-60	3.0	4.7	8.0	12	18	29	48				
וגרמן	-55	2.7	4.3	7.3	11	17	27	44				
	-50	2.5	3.9	6.7	10	15	24	40				
	-45	2.2	3.5	6.0	9.0	14	22	36				
	-40	2.0	3.1	5.3	8.0	12	19	32				

3.4. How to order

■Vacuum Gripper unit



*1 Suction cup parts / How to order and Weight

ZXP7(A,N)01 -	(4)	(5)	(6)	(7)	(8)	-X1						
						Mass and part number f	or suction	o cup part f	or separat	e order		
							tion cup w	Adapter	Suction cup			
									. 8			
	(4)	(=)		(-)	(0)				8		9	Q
	(4) Cariaa	(5) Diameter	(6) Form	(7)	(8) Attachment		Mag	for oach	material (c		- · ·	
	Series	Diameter	FOIIII	Material	Attachment			S/SF			+	
						Part number	N (NDD)	(Silicone	(Urethan	F		\smile
							(NBR)	rubber)	rubber)	(FKM)		
	ZP	08	U	*		ZPT08U*-A6	4	4	4	4		ZP08U*
	ZP	08	В	*		ZPT08B*-A6	4	4	4	4		ZP08B*
	ZP	10	UT	*		ZPT10UT*-A6	4	4	4	4	ZPT1-A6	ZP10UT*
	ZP	13	UT	*		ZPT13UT*-A6	4	4	4	4	4	ZP13UT*
	ZP	16	UT	*		ZPT16UT*-A6	4	4	4	4		ZP16UT*
	ZP	10	U	*		ZPG10U*-7A-X2	7	7	7	7		ZP10U*
	ZP	13	U	*		ZPG13U*-7A-X2	7	7	7	8	ZPT2-7A-X2	ZP13U*
	ZP	16	U	*		ZPG16U*-7A-X2	7	7	7	8		ZP16U*
	ZP	20	U	*		ZPG20U*-7A-X2	9	10	10	10	ZPT3-7A-X2	ZP20U*
	ZP ZP	25	U	*		ZPG25U*-7A-X2	10	10	10	11	ZP13-7A-X2	ZP25U*
	ZP ZP	32 10	U C	*		ZPG32U*-7A-X2 ZPG10C*-7A-X2	10 7	11	11	12 7		ZP32U* ZP10C*
	ZP ZP	10	C C	*		ZPG10C*-7A-X2 ZPG13C*-7A-X2	7	7	7	7	ZPT2-7A-X2	ZP10C* ZP13C*
	ZP ZP	13	с С	*		ZPG13C*-7A-X2 ZPG16C*-7A-X2	7	7	7	8		ZP13C* ZP16C*
	ZP ZP	20	C C	*		ZPG16C*-7A-X2 ZPG20C*-7A-X2	9	10	10	 11		ZP16C* ZP20C*
	ZP	20	C C	*		ZPG20C*-7A-X2 ZPG25C*-7A-X2	10	10	10	11	ZPT3-7A-X2	ZP20C* ZP25C*
	ZP	32	c	*		ZPG25C*-7A-X2 ZPG32C*-7A-X2	10	10	10	12		ZP32C*
	ZP	10	B	*		ZPG32C*-7A-X2 ZPG10B*-7A-X2	7	7	7	8		ZP10B*
	ZP	13	B	*		ZPG13B*-7A-X2	7	8	8	8	ZPT2-7A-X2	ZP13B*
	ZP	16	B	*		ZPG16B*-7A-X2	8	8	8	9		ZP16B*
	ZP	20	B	*		ZPG20B*-7A-X2	11	11	11	13		ZP20B*
	ZP	25	B	*		ZPG25B*-7A-X2	11	12	12	14	ZPT3-7A-X2	ZP25B*
	ZP	32	B	*		ZPG32B*-7A-X2	14	15	15	18		ZP32B*
	ZP	20	UT	*		ZPG20UT*-7A-X2	4	4	4	4	ZPT1-A6	ZP2-20UT*
	ZP	16	J	*		ZPG16J*-7A-X2	8	8	8	9	ZPT2-7A-X2	ZP2-16J*
	ZP	B25	J	*		ZPGB25J*-7A-X2	14	15	15	18		ZP2-B25J*
	ZP	B30	J	*	1	ZPGB30J*-7A-X2	18	19	19	25	ZPT3-7A-X2	ZP2-B30J*
	ZP3P	20	JT2	SF		ZP3PG20JT2SF-7A-X2	-	21	-	-	ZP3PA-T1JT-7A-X2	ZP3P-20JT2SF-W
	ZP3P	20	JT2	SF	М	ZP3PG20JT2SF-M-7A-X2	-	21	-	-	-2P3PA-11J1-7A-X2	ZP3P-20JT2SF-WM
	ZP3P	32	JT2	SF		ZP3PG32JT2SF-7A-X2	-	48	-	-	ZP3PA-T2JT-7A-X2	ZP3P-32JT2SF-W
	ZP3P	32	JT2	SF	М	ZP3PG32JT2SF-M-7A-X2	-	48	-	-	2F3PA-12J1-1A-X2	ZP3P-32JT2SF-WM
	ZP3P	20	JT5	SF		ZP3PG20JT5SF-7A-X2	-	23	-	-	ZP3PA-T1JT-7A-X2	ZP3P-20JT5SF-WG
	ZP3P	25	JT5	SF		ZP3PG25JT5SF-7A-X2	-	25	-	-		ZP3P-25JT5SF-WG
	ZP3P	32	JT5	SF		ZP3PG32JT5SF-7A-X2	-	54	-	-	ZP3PA-T2JT-7A-X2	ZP3P-32JT5SF-WG

Note) Material symbol "N", "S", "U", or "F" is put in * of the product number.




4.1. Mounting


Mounting procedure

1) Confirm the gasket seal on the adapter, then mount 4 cups with adapter to the vacuum gripper unit. (Tightening torque: 1N • m or tighten for 45 degrees using a spanner after tightening by hand)

- 2) Mount parallel pin to the robot tool flange pin hole.
- 3) Align the parallel pin of the robot tool flange with the robot mounting flange, and assemble them with bolts included in the accessories. (Tightening torque: 5.2+/-0.5 Nm)
- 4) Tighten the vacuum gripper to the robot mounting flange. (Tightening torque: 5.2+/-0.5 Nm)

Removal should be performed by following the mounting procedure in reverse.








Vacuum gripper direction can be changed in 90-degree increments when attached to a robot. At that time, install it in the direction of the lower figure where the slack of the M8 connector cable is the smallest. (the M8 tool I/O connector of the robot comes to the opposite side of the electrical entry of the vacuum gripper unit)

If the cable is loose, it may be caught by peripheral equipment, workpiece, human body, etc. while the robot is running, causing unexpected accidents.




4.2. Wiring

Mount the M8 connector cable


Mount the M8 connector cable to the M8 connector (male) of the robot tool flange.


*Do not energize while securing the connector.

*Check that the connector is not loose



■M8 Connector pin





M8 connector female angle

Pin no.	Wire color	Function
1	White	Analog input for pressure sensor (AI0)
2	Brown	
3	Green	
4	Yellow	
5	Gray	Power supply voltage (24VDC)
6	Pink	Digital output for Release valve (DO1) *
7	Blue	Digital output for Pilot valve for supply (DO0) *
8	Red	Power supply (GND)


M8 connector pin assign

* The polarity of the digital output of the robot side (DO0/DO1) has to be NPN.



4.3. Piping

Tubing
 Connect a tube (applicable tube O.D. Ø6) to the air pressure supply (P) port.
 To remove the tube, push the release button and pull out the tube.



4.4. URCap

Installation and basic setting

- 1. Installation of URCap
- (1) Tap the "URCap" menu from the robot settings screen.(2) Insert the USB memory with a copy of the downloaded file into the teaching pad and tap the "+" button.

800	University	al Robots	Graphic	al Program	nming Envi	ironment											
Run	Program		+ Move	$\mathbf{Q}_{\mathbf{r}}$			I	PROGF NSTALLAT		ınnamed> fault	New	Open	Save		<u>ل</u> ر+	с с с с	\equiv
								ç	Setting	15							
	N D	erences		Active U	RCans			-	Jecting	,	Inacti	ve URCa	ns				
	 Pass Syst 	sword	, 								and the second sec		& Toolpa	ith			
	B	ackup RCaps obot egistrat		(1)													
		emote ontrol		URCap Ir	nformatio	on											
		etwork															
	U	pdate		(2)													
		Exit		(2)	-										 R	estart	
0	Power	off				Speed 💻			-0 1	.00%	(0 () (Simul	lation	

(3) Select "SMC-VacuumGripperUnit-xxx.urcap " from the file screen and tap the "open" button.

800	Univers	al Robo	ts Grap	hical	Progra	mming Environme	nt									
R	Ĭ.	2	4) (Q	M			<unnamed></unnamed>	[]				IR+	с с с с	=
Run	Program	Installation	n Mov	/e	1/0	Log		INSTALLATION		New	Open	Save			сс	_
								Select URC	Cap to install	ĺ						
	•	×		E	ŵ	Ø									-	()
	New	Cut	Сору	Paste	Delete	Rename									Backu	P
	A															
	SMC-	Vacuur	mGripp	berUn	it-1.0.	0.urcap (3)										
F	ilename:								Filter:							
5	SMC-Va	cuumG	rippe	rUnit	-1.0.0	urcap			URCap Files						•	•
														Open	Cancel	
				_											cuncer	-
	Powerd	ff				Speed	4		• 100%					Simi	ulation	
\mathbf{O}	Powerd					Speed			- 100 //	_ .	7 4		,	SILL		



(4) Tap the "Restart" button to restart the robot.


			Settings	5			
> Prefer	ences	Active URCaps		Inactive	URCaps		
> Passw	ord	🖔 SMC Vacuum Gripper Unit		Remo	te TCP & Toolpath		
V Syster	n						
	tem kup						
URC	Caps						
Rob Reg	oot Jistration						
	note htrol	URCap Information					
	work	URCap name: SMC Vacuum Grip Version: 1.0.0	pper Unit				^
	late	Developer: SMC Corporation. Contact Info: 4-2-2,KINUNODAI			JAPAN		
		Description: The URCap for con Copyright: Copyright(C) 2020 SI License Type: One-time purchas License: Copyright (c) 2020 SMC Corporal All rights reserved.	MC Corporation. se	oer unit.			
		Redistribution and use in source a	and binary forms. with or w	ithout			~
E	kit	+ -				(4)	Restart

*Before you make a change to the basic settings after the software installation, set the Tool Output Voltage to "24V" in the "Tool IO" setting from the "General" menu on the "Installation" tab. Set "Digital Output 0" and "Digital Output 1" to "Sinking(NPN)".


2. Select "SMC Vacuum Gripper Unit" on the "URCap" menu for basic settings.

(1):"Various status signal output to digital output port":

Sets the status of the output port. If "Enable" is selected, the signal for "Adsorb success", "Adsorb failure", and "Workpiece drop detection" can be assigned to the output port No. 5 / 6 / 7, respectively.



(2) Select "Disable" when the output port is not used.




Different signals cannot be assigned to the same port.

🔗 🖱 🕛 Universal Robots Graphical Programming Environment		
Run Program Installation Move V0 Log PROGRAM <unnamed>* C To To</unnamed>	4 A D 3	\equiv
General SMC Vacuum Unit		
> Safety		
> Features Installation Settings		
> Fieldbus		
Various status signal output to digital output port		
SMC Air Gripper Unit Select digital output port to output adsorb success signal digital_out[5]		
SMC Select digital output port to output adsorb failure signal digital_out[5] Vacuum Unit		
Remote TCP		
WARNING : Slected signals are set on the same port		
Notes By navigating to the General menu - Tool IO set the "Tool Output Voltage" to 24V.		
Next, set "Digital Output 0" and "Digital Output 1" to Sinking(NPN)		
Copyright (c) 2020 SMC Corporation.		
Power off Speed 100% D Simu	ation 🦳	

Program setting

Operation program can be set from the "Program" tab.

- (1) : <u>"Select operation"</u>
- 3 types of operation NODEs are available.
- 1 : "ADSORB ONLY NODE" starts adsorption. This does not monitor the pressure sensor signal.
- 2 : "ADSORB AND CHECK VACUUM LEVEL NODE" starts adsorption. In this case, after checking the pressure sensor signal and confirming the adsorption, the transition of the operation occurs.
- 3 : "RELEASE ONLY NODE" starts vacuum release. This does not monitor the pressure sensor signal.



(2) : <u>"Settings"</u>


- 1 : "Vacuum pressure level for checking" sets the vacuum pressure to output the signal for checking the adsorption.
- 2 : "Adsorb error detection time" sets the time to recognize an unsuccessful adsorption, that is, vacuum pressure to output the adsorption signal is not reached.
- 3 : "Blow-off time of release" sets time to supply vacuum release pressure.
- 4 : "Weight of the workpiece" enters the weight of the transferred object for each "Adsorb" command.

(3) : <u>"Monitor sensor signal"</u>

Pressure sensor detection pressure can be confirmed on the screen.


Manual operation


From the UR+ icon in the upper right corner of the screen, the manual operation of the vacuum gripper unit can be checked. The vacuum gripper unit operation (adsorb or release) and the vacuum pressure can be checked by tapping the "Adsorb" / "Release" button.






5.1. Vacuum gripper unit








* Cup distance is changeable.




5.2. Suction cup with adapter


*It is shown here for representative model only. See the suction cup catalog for the other models.



*₿*SMC



Model : ZPG(B25,B30)J*-7A-X2 (Suction cup form : Multistage bellows type 3.5-Stage)



Note1) "D" and (st) indicate the reference value during adsorption at vacuum pressure: -85[kPa].

6. How to change the number of cups

6.1 Change to 1 cup (with flange)

1. Removal of the cup.


- (1) Remove the suction cup with adapter from plate B using a spanner.
- (2) Loosen the bolt (M4 x 8), then remove plate B from plate A. Be careful not to lose the O-ring.
- (3) Loosen the bolt for sealing ($M\widetilde{X}8$), then remove the cup from plate A.



Completion drawing

- 2. Mounting of the plug and suction cup with adapter
 - (1) Confirm the gasket seal in the accessory plug, then mount the plugs to plate A. (4 places)
 - (2) Confirm the gasket seal in the adapter, then mount the suction cup with adapter removed in the process (1) to plate A.

Reassemble the parts by reversing the disassembling process with specified tightening torque.



(1) Disassemble the suction cups with adapter


Caution

Tightening torque: 1N • m, (As reference, tighten by 45 degrees using a spanner after tightening by hand))
 If tightened excessively, thread portion may be damaged and gasket may be deformed. This will cause air leakage. Insufficient tightening may loosen the thread or cause air leakage.

6.2 Change to 1 cup (without flange)

- 1. Removal of the cup mounting flange
 - (1) Loosen the bolt (M6 x 12), then remove the cup mounting flange. Be careful not to lose the O-ring.
 - (2) Remove the parallel pin.
- 2. Mounting of the suction cup with adapter
- (1) Remove the suction cup with adapter from the flange with cup removed in the process 1 above.
- (2) Confirm the gasket seal in the adapter, then mount the suction cup with adapter removed in the process(1) to the product.

Reassemble the parts by reversing the disassembling process with specified tightening torque.



(1) Disassemble the cup mounting flange

Tightening torque: 1N • m, (As reference, tighten by 45 degrees using a spanner after tightening by hand))
 If tightened excessively, thread portion may be damaged and gasket may be deformed. This will cause air leakage. Insufficient tightening may loosen the thread or cause air leakage.






6.3 Change to 2 cups

- 1. Removal of the cup
 - (1) Remove the suction cup with adapter from the adapter using a spanner.
 - (2) Loosen the bolt (M4 x 8), then remove plate B from plate A.
 - Be careful not to lose the O-ring.
- 2. Mounting of the plug

Confirm the gasket seal in the plug, then mount the plugs to plate A.

Reassemble the parts by reversing the disassembling process with specified tightening torque.



(1) Disassemble the suction cups with adapter

* Tightening torque: 1N • m, (As reference, tighten by 45 degrees using a spanner after tightening by hand)) If tightened excessively, thread portion may be damaged and gasket may be deformed. This will cause air leakage. Insufficient tightening may loosen the thread or cause air leakage.

Completion drawing

⁽²⁾ Plug mounting

7.Maintenance

■ Implement the maintenance and check shown below in order to use the vacuum gripper unit safely and in an appropriate way for a long period of time.

7.1. Maintenance for vacuum gripper unit

A Caution

1) Check before and after the maintenance work

When the product is to be removed, turn off the power supply, and be sure to cut off the supply pressure and exhaust the compressed air. Confirm that the air is released to atmosphere.

When mounting the product after the maintenance work, supply compressed air, connect to the power, check if it functions properly and have a leakage inspection.

2) Maintenance should be performed according to the procedure indicated in the Operation Manual. Improper handling can cause damage and malfunction of equipment and machinery.

3) Maintenance work

Compressed air can be dangerous when handled incorrectly. Therefore, in addition to observing the product specifications, replacement of elements and other maintenance activities should be performed by personnel with sufficient knowledge and experience pertaining to pneumatic equipment.

4) Draining

Remove condensate from air filters and mist separators regularly. If the collected drainage is drained to the downstream side, it can stick inside of the product, causing operation failure and failure to reach the specified vacuum pressure.

5) Replace the silencer built into the vacuum gripper unit regularly.

It is recommended to replace the silencer when the pressure drop reaches 5kPa as a guideline. The replacement cycle varies depending on the operating conditions, operating environment and supply air quality. However, if there is a vacuum pressure drop and/or delay in the vacuum (adsorption) response time which causes problem with the settings during operation, stop the operation of the product and replace the silencer regardless of the above mentioned replacement guideline.

Part number for the silencer assembly for replacement: ZX1-SAE-X121

< Silencer Assembly Replacement Procedure >

- Remove the cover.
- Loosen the 2 cross-recessed pan head screws to remove the silencer assembly.

P_D

- Assemble the new silencer assembly.
- Mount the cover.

Silencer assembly

Cover Hexagon socket head cap screw (M3x5) Tightening torque 0.32N · m

Cross-recessed pan head screw M2x23(2 pcs.) Tightening torque 0.25N·m

6) Do not disassemble or modify the product, other than the replacement parts specified in this manual.

7.2. Maintenance for suction cup

Caution

Suction cups are disposable. Replace them on a regular basis. 1)

Continued use of suction cups will cause wear and tear on the adsorption surface, and the exterior dimensions will gradually get smaller and smaller. As the cups' diameter gets smaller, their lifting force will decrease, though adsorption will still remain possible.


It is extremely difficult to provide advice on the frequency of suction cup replacement. This is because there are numerous factors at work, including surface roughness, operating environment (temperature, humidity, ozone, solvents, etc.), and operating conditions (vacuum pressure, workpiece weight, pressing force of the suction cups on the workpieces, presence or absence of a buffer, etc.).

(The weakening of bent parts or the wear or sticking of rubber parts may occur with the bellows type cup.) Thus, the customer should decide when suction cups should be replaced, based on their condition at the time of initial use.

The bolts may become loose depending on the operating conditions and environment. Be sure to perform regular maintenance.

<How to replace the suction cup>

- Pull the lock ring upward, and, after lifting it up to the adapter, remove the old cup by pulling it downward.
- While holding the lock ring in the raised position place a new cup onto the adapter.
- Confirm that the cup is securely in place, and then return the lock ring to its original position.
- * The cup without lock ring is just inserted to the end of the adapter.



Cup disassembly

8.Precautions


8.1 Air supply

MWarning

Use clean air.

It is recommended to use compressed air which purity class is 2:6:3 of ISO8573-1:2010. Supply air containing foreign matter, water, oil, condensate, etc., can cause malfunction of the supply valve and release valve. So, install air preparation equipment on the upstream side of the product (refer to the piping example below) and perform maintenance periodically to control the supply air properly.

Refer to "SMC Air Preparation System" for further details on compressed air quality.



Vacuum gripper unit

8.2 Vacuum gripper unit precautions

Designing

🕂 Warning

If power or air supply is shutdown,vacuum pressure may decrease and this product may drop a workpiece during absorption.

Please perform of safety measures by customer systems.

```
■Mounting
```

Warning

) Tighten to the specified tightening torque.

If the tightening torque is exceeded, the product, the mounting screws, brackets and the pressure switch can be broken. Insufficient torque can cause displacement of the product and the pressure switch from each proper position and loosening of the mounting screws.

2) Hold the product itself when handling. Do not pull the M8 connector cable strongly or lift up the product by holding this cable. It can cause the malfunction of the product.

■Wiring

Warning

- 1) Do not perform wiring while the power is on. Otherwise damage to the solenoid valve or the internal parts of the pressure switch/sensor can result, causing malfunction.
- 2) Never disassemble the M8 connector cable or make any modifications including additional machining. Doing so may cause human injury and/or an accident.

▲Caution

1) Avoid repeated bending, tensioning or external force to the M8 connector cable.



Piping

<u>∕</u>Caution

1) Preparation before piping

Before piping, perform air blow (flushing) or cleaning to remove any cutting chips, cutting oil, dust, etc. from the piping.

2) Installation of tubing

- Cut the tubing perpendicularly, being careful not to damage the outside surface. Use an SMC tube cutter TK-1,2,3. Do not cut the tubing with pliers, nippers, scissors, etc., otherwise the tubing will be deformed and problems may result.
- Grasp the tubing, and slowly push it straight (0 to 5°) into the one-touch fitting until it comes to a stop.
- Pull the tubing back gently to make sure it has a positive seal. Insufficient installation may cause air to leak or the tubing to release.

3) Removal of tubing

- Push the release button flange evenly and sufficiently to release the tube. Do not push in the tubing before pressing the release button.
- Pull out the tubing while keeping the release button depressed. If the release button is not held down sufficiently, the tubing cannot be withdrawn.
- To release the tubing, remove the previously lodged portion of the tubing. If the lodged portion is left on without being removed, it may result in air leakage and make the removal of the tubing difficult.
- 4) When using tubing from a manufacturer other than SMC, be careful of the tolerance of the tubing O.D. and tubing material.
 - Nylon tubing Within ±0.1mm
 - Soft nylon tubing Within ±0.1mm
 - Polyurethane tubing Within+0.15mm, Within -0.2mm

Do not use tubing which does not satisfy the specified tubing O.D. accuracy. It may cause difficulty in connecting the tubing, leakage, disconnection of the tubing, or fitting damage.

- 5) Do not apply unnecessary forces, such as twisting, pulling moment loads, vibration, impact, etc., on fittings or tubing.
- 6) Tubing, with the exception of coiled tubing, requires stationary installation. Do not use standard tubing (non-coiled) din applications where tubing is required to travel inside the flexible protection tube. Tubing that travels may sustain abrasion, extension, or severance due to tensile force. The removal of tubing from the fitting may also occur. Use caution prior to use in an application.

Do not lift up the product by holding the tubing after piping.


It causes malfunction of one-touch fitting.

Refer to Fittings & Tubing Precautions from 1 to 4 shown in Best Pneumatics 6 on SMC's website (URL <u>http://www.smcworld.com</u>) for the recommended piping conditions.

7) When change the direction of the one touch fitting of the air pressure supply port(P), change the direction after untighten the universal elbow.

SVU

When the one touch fitting is moved by force without untighten the universal elbow, it may result in air leakage. When tightening the universal elbow, tightening by hand, and give it an additional 1/2 rotations turn with a wrench approximately. (As a guideline, the tightening torque should be 1 to 1.5 Nm.)



8) Adjust the length of air tube following by the movement of the robot arm to avoid adding tension the tube.


When adding the tension of tube repeatedly, it may result in air leakage. And the tube bending radius in the vicinity of the fitting should be at least the minimum bending radius of the tubing.

Exhaust from Ejector

If the operating environment contains a lot of particles or mist, the sound absorbing material may be clogged. If the sound absorbing material is clogged, it will cause a reduction in the ejector performance. Replace the sound absorbing material in such case. (Refer to "7.2. Maintenance for vacuum gripper unit")

Exhaust noise

When vacuum ejector generates vacuum, noise can be heard from the exhaust port when the standard supply pressure is close to the pressure that generates peak vacuum pressure making vacuum pressure unstable. If the vacuum pressure range is adequate for adsorption, there should not be a problem. If the noise causes a problem or affects the setting of the pressure switch, change the supply pressure slightly to avoid the pressure range of the noise.



Workpiece

If water drops or dust are attached on the workpiece surface, they may go into the vacuum ejector and may cause the low vacuum performance. Also when workpieces are permeable, there is a case that sufficient lifting force cannot get. In such cases, it is necessary to perform a suction test to check the compatibility to your application before actual usage.

8.3 Suction cup precautions

Design

Warning

1) In cases where the workpieces are heavy or dangerous objects, etc., take measures to address a possible loss of adsorption force (installation of a drop prevention guide, etc.).

In the case of transportation by vacuum adsorption using suction cups, the adsorption force is lost when there is a drop in vacuum pressure. Furthermore, since vacuum pressure can also deteriorate due to the wear and cracking of cups, vacuum leakage from piping, etc., be certain to perform maintenance on vacuum equipment.

Selection

- 1) The cup materials which can be used differ depending upon the operating environment. An appropriate cup material should be selected. Furthermore, since suction cups are manufactured for use with industrial products, they should not come into direct contact with medicines, food products, etc.
- 2) Depending upon the weight and shape of the workpieces, the diameter, quantity, and shape of cups suitable for use will vary.


Refer to "3.3. How to calculate theoretical lifting force " for the theoretical lifting force. Also, the selectable cups will differ based upon conditions other than the above, such as the condition of the workpiece surface (presence or absence of oil or water), the workpiece material, and its gas permeability. Confirmation is necessary by actually performing vacuum adsorption on the subject workpieces.

3) Do not apply an impact or large force to a cup when adsorbing a workpiece. This will cause the deformation, cracking, and wear of the cup to be accelerated. The stiffening ribs, etc., should touch lightly, while staying within the cup skirt's deformation range. Positioning should be performed accurately, especially in the case of small-diameter cups.



- 4) When transporting vertically, factors such as acceleration, wind pressure, and impact force must be considered in addition to the workpiece weight. Use caution particularly when lifting items such as glass plates and circuit boards because a large force will be applied by wind pressure. When a workpiece which is oriented vertically is transported horizontally, large forces are applied by acceleration when movement is started and stopped. Furthermore, in cases where the cup and workpiece can slip easily, accelerations and decelerations of horizontal movement should be kept to
- 5) When transporting flat shaped workpieces that have large surface areas using multiple cups, care must be taken in arranging the cups, so that the workpieces are evenly adsorbed.
- 6) Use caution since the workpiece could rotate during transfer. Use of more than one cup for each workpiece is recommended.

Horizontal lifting




Vertical lifting (This type of application should generally be avoided.)


Adsorption


a minimum.

This product has 4 pneumatically connected cups per ejector. If one cup fails to operate, all other cups cannot adsorb the object. Safety measures needs to be taken to prevent falling of workpiece during transfer of the object. When adsorption with cups which do not adsorb object is required, connect the vacuum saving valve, ZP2V series (Applicable model: ZP2V-B6-05). The valve suppresses the decrease of the vacuum pressure and there is a case that the workpiece can be held.

For the feasibility of workpiece and conditions of customer, operation check with the actual equipment is required.







<Reference>

Theoretical lifting force of vacuum cup diameter 32mm with ZP2V-B06-05 at supply pressure 0.5 MPa

	Vacuum pressure	Theoretical lifting force	Horizontal lifting force
	[kPa]	[N]	[N] (Safety factor 1/4)
1 cup adsorption	-50	40.2	10
2 cups adsorption	-67	53.8	13.4
3 cups adsorption	-73	58.7	14.6

(Calculated by "W = P X S, S = $\pi \cdot r^2$, r = $\Phi 32 / 2$ ". Refer to 3.3 How to calculate theoretical lifting force for the detail.)

■Storage

1) It is recommended to store suction cups in the environment shown in the table below. Storing in an environment other than that recommended below may lead to changes in properties (deformation, discoloration, cracking, increased adhesiveness, etc.).

Recommended Storage Environment for Suction cups

Temperature	15 to 25[°C]
Humidity	50[%] or less, No condensation
Other	Location that is shaded from direct sunlight or fluorescent light Location without the presence of ozone (For NBR and conductive NBR)



9.Trouble shooting

Condition & Description of improvement	Contributing factor	Countermeasure	
Initial adsorption problem (During trial operation)	Adsorption area is small. (Lifting force is lower than the workpiece mass.)	Recheck the relationship between workpiece mass and lifting force. - Use a suction cup with a large adsorption area. - Increase the quantity of suction cups.	
	Vacuum pressure is low. (Leakage from adsorption surface) (Air permeable workpiece)	Eliminate (reduce) leakage from adsorption surface. - Reconsider the shape of a suction cup. Check the relationship between suction flow rate and arrival pressure of vacuum ejector. - Increase adsorption area.	
	Inadequate supply pressure of vacuum ejector	Measure supply pressure in vacuum generation state. - Use standard supply pressure. - Reconsider compressed air circuit (line).	
	Clogging of vacuum ejector (Infiltration of foreign matter during piping)	Remove foreign matter.	
Late vacuum achieving time (Shortening of response time)	The set vacuum pressure for the suction verification is too high.	Set to suitable setting pressure.	
Fluctuation in vacuum pressure	Fluctuation in supply pressure	Reconsider compressed air circuit (line). (Addition of a tank etc.)	
	Vacuum pressure may fluctuate under certain conditions due to ejector characteristics.	Lower or raise supply pressure a little at a time, and use in a supply pressure range where vacuum pressure does not fluctuate.	
Occurrence of abnormal noise (intermittent noise) from exhaust of vacuum ejector	Intermittent noise may occur under certain conditions due to ejector characteristics.	Lower or raise supply pressure a little at a time, and use in a supply pressure range where the intermittent noise does not occur.	
Adsorption problem over time (Adsorption is normal during trial operation.)	Clogging of the silencer	Replace the silencer. Add a filter to supply (compressed) air circuit.	
	Presence of foreign matter in the ejector.	Remove foreign matter. Replace the ejector Add a filter to supply (compressed) air circuit.	
	Cup (rubber) deterioration, cracking, etc.	Replace cups. Check the compatibility of vacuum cup material and workpiece.	
Workpiece is not released.	The increase of stickiness due to the wearing of the cup (rubber).	Replace cups. Check the compatibility of the cup material and workpiece.	
	Vacuum pressure is too high.	Set the vacuum pressure to the minimum value necessary.	

Revision history

Rev. A: P.12 Correction of "How to order" and adding suction cup variation Rev. B: P.6,24~26 Add to part number,P.8 Add to specifications,P.10~12,14,27,30 Revise errors,P22,29 Add to caution.

SMC Corporation

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021 JAPAN Tel: + 81 3 5207 8249 Fax: +81 3 5298 5362 URL <u>https://www.smcworld.com</u>

Note: Specifications are subject to change without prior notice and any obligation on the part of the manufacturer. © 2020 SMC Corporation All Rights Reserved

