



# Operation Manual

## PRODUCT NAME

*Mechanically jointed rodless cylinder*  
*Basic type*  
*With Slide bearing guide type*  
*With cam follower guide type*  
*With linear guide type*  
*With High rigidity/ Linear guide type*  
*With Protective Cover type*

## MODEL / Series / Product Number

**MY1B/M/C/H/HT Series**  
**MY1B/H\*-\*Z Series**  
**MY1MW/CW Series**

**SMC Corporation**

# Contents

Safety Instructions ----- P. 2

## 1. Product Specifications

1.1 Specifications ----- P. 4

1.2 End-lock type ----- P. 6

## 2. Operation and Mounting

2.1 Air Supply ----- P. 6

2.2 Operating Environment ----- P. 7

2.3 Design ----- P. 8

2.4 Mounting and Installation ----- P. 9

2.5 Piping ----- P. 13

2.6 Speed Control ----- P. 15

2.7 Shock Absorbing Mechanism ----- P. 15

2.8 Directional Control ----- P. 18

2.9 Mounting of Auto Switch ----- P. 18

## 3. Maintenance and Inspection

3.1 Inspection ----- P. 19

3.2 Maintenance ----- P. 20

3.3 Replacement Parts ----- P. 20

## 4. Troubleshooting

----- P. 20

| Revision history |
|------------------|
|------------------|

## SMC Corporation

4-14-1, Sotokanda, Chiyoda-ku, Tokyo 101-0021 JAPAN

Tel: + 81 3 5207 8249 Fax: +81 3 5298 5362

URL <http://www.smcworld.com>

---

Note: Specifications are subject to change without prior notice and any obligation on the part of the manufacturer.  
© 2011 SMC Corporation All Rights Reserved