

# Mini-Rotary Actuator Rack-and-Pinion Type/Size: 05, 1 *Series CRJ*

CRB

CRBU

CRJ

CRA1

CRQ

MRQ

MSQ

MSU


**More Compact!**



In our pursuit of excellence in size and weight reduction, we proudly announce the release of the Series CRJ Mini-Rotary Actuator!

# Mini-Rotary Actuator *Series CRJ*

Rack-and-Pinion Type/Size: 05, 1




## Flexible mounting

A new compact body design not only reduces overall space requirements, but also achieves space savings in wiring and piping.

Ease in mounting is maximized thanks to the merits of the new compact body.


### Free mount




Top mount



Speed controllers do not protrude from the top of the body.





Bottom mount



Side mount



### Wiring and piping direction can be selected depending on mounting conditions.

Mounting examples for auto switch and speed controller



# Improved allowable load


Large roller bearing and large diameter output shaft add to overall compactness while ensuring high rigidity.



Model		CRJ05	CRJ1
Allowable load (N)	Fr	25	30
	FS(a)	20	25
	FS(b)	20	25
Output shaft size (mm)		ø5	ø6


# Reduced backlash

Even with a single rack design, the use of a special construction minimizes backlash.




## With external stopper/Series CRJU

4 to 5 times allowable kinetic energy (Basic type compared to CRJB)



Angle is adjustable:  $\pm 5^\circ$  at each rotation end



# Variations

Series		Rotation angle				Port location	Auto switch
		90°	100°	180°	190°		
Basic type	CRJB05	●	●	●	●	Front port	D-F8
	CRJB 1	●	●	●	●		
With external stopper	CRJU05	●	—	●	—	Side port	D-F9
	CRJU 1	●	—	●	—		

CRB

CRBU

CRJ

CRA1



CRQ

MRQ

MSQ

MSU

# Series CRJ Model Selection


Procedure	Calculation	Example
<p><b>1 Operating conditions</b></p> <p>List all possible operating conditions according to the mounting position.</p> 	<ul style="list-style-type: none"> <li>• Model used</li> <li>• Operating pressure</li> <li>• Mounting position</li> <li>• Load type               <ul style="list-style-type: none"> <li>Ts (N·m)</li> <li>Tf (N·m)</li> <li>Ta (N·m)</li> </ul> </li> <li>• Load configuration</li> <li>• Rotation time t (s)</li> <li>• Rotation angle</li> <li>• Load mass m (kg)</li> <li>• Distance between central axis and center of gravity H (mm)</li> </ul>	 <p> <b>Rotary actuator:</b> CRJB05-90    <b>Pressure:</b> 0.4MPa  <b>Mounting orientation:</b> Vertical    <b>Type of load:</b> Inertial load Ta  <b>Load 1 configuration:</b> 20mm x 10mm (rectangular plate)  <b>Load 2 configuration:</b> 5mm x 5mm (square plate)  <b>Rotation time t:</b> 0.2s    <b>Rotation angle:</b> 90°  <b>Load 1 mass m1:</b> 0.03kg    <b>Load 2 mass m2:</b> 0.006kg  <b>Distance between central axis and center of gravity H:</b> 7mm         </p>
<p><b>2 Required torque</b></p> <p>Confirm the type of load as shown below, and select an actuator that satisfies the required torque.</p> <ul style="list-style-type: none"> <li>• Static load: Ts</li> <li>• Resistance load: Tf <b>Load types</b></li> <li>• Inertial load: Ta</li> </ul>	<p>           Effective torque <math>\geq Ts</math>            Effective torque <math>\geq (3 \text{ to } 5) \times Tf</math>            Effective torque <math>\geq 10 \times Ta</math> </p> <p><b>Effective torque</b></p>	<p><b>Inertial load</b></p> $10 \times Ta = 10 \times I \times \dot{\omega}$ $= 10 \times 1.57 \times 10^{-6} \times (2 \times (\pi/2) / 0.2^2)$ $= 0.0012 \text{ N}\cdot\text{m} < \text{Effective torque} \quad \text{OK}$ <p>Note) I substitutes for ⑤, the value for inertial moment.</p>
<p><b>3 Rotation time</b></p> <p>Confirm that it is within the rotation adjustment time range.</p>	<p>0.1 to 0.5s/90°</p>	<p>0.2s/90°    OK</p>
<p><b>4 Allowable load</b></p> <p>Confirm that the radial load, thrust load and moment are within the allowable ranges.</p>	<p>Thrust load: <math>m \times 9.8 \leq \text{Allowable load}</math></p> <p><b>Allowable load</b></p>	<p><math>(0.03 + 0.006) \times 9.8 = 0.35 \text{ N} &lt; \text{Allowable load} \quad \text{OK}</math></p>
<p><b>5 Inertial moment</b></p> <p>Find the load's inertial moment "I" for the energy calculation.</p>	$I_1 = m \times (a^2 + b^2) / 12$ $I_2 = m \times (a^2 + b^2) / 12 + m \times H^2$ $I = I_1 + I_2$ <p><b>Inertial moment</b></p>	$I_1 = 0.03 \times (0.02^2 + 0.01^2) / 12 = 1.25 \times 10^{-6} \text{ kg}\cdot\text{m}^2$ $I_2 = 0.006 \times (0.005^2 + 0.005^2) / 12 + 0.006 \times 0.007^2$ $= 0.32 \times 10^{-6} \text{ kg}\cdot\text{m}^2$ $I = 1.25 \times 10^{-6} + 0.32 \times 10^{-6}$ $= 1.57 \times 10^{-6} \text{ kg}\cdot\text{m}^2$
<p><b>6 Kinetic energy</b></p> <p>Confirm that the load's kinetic energy is within the allowable value.</p>	$1/2 \times I \times \omega^2 \leq \text{Allowable energy}$ $\omega = 2\theta / t \quad (\omega: \text{Terminal angular velocity})$ $\theta: \text{Rotation angle (rad)}$ $t: \text{Rotation time (s)}$ <p><b>Allowable kinetic energy/Rotation time</b></p>	$1/2 \times 1.57 \times 10^{-6} \times (2 \times (\pi/2) / 0.2)^2$ $= 0.00019 \text{ J} = 0.19 \text{ mJ} < \text{Allowable energy} \quad \text{OK}$

## Effective Torque

Unit: N·m

Size	Operating pressure (MPa)						
	0.15	0.2	0.3	0.4	0.5	0.6	0.7
<b>05</b>	0.013	0.017	0.026	0.034	0.042	0.050	0.059
<b>1</b>	0.029	0.038	0.057	0.076	0.095	0.11	0.13

Note) Effective torque values are representative values. They are not guaranteed values. Use them only as a guide.




## Load Types

### • Static load: Ts

#### Definition for our purposes:

A load that requires pressing force only, as represented by the clamp.

(If the mass of the clamp itself in the drawing below is considered in the calculations, it should be regarded as an inertial load.)




### • Resistance load: Tf

#### Definition for our purposes:

A load that is affected by external forces such as friction or gravity. Since the purpose is to move the load, and speed adjustment is necessary, allow an extra margin of 3 to 5 times in the effective torque.

\* Actuator effective torque  $\geq (3 \text{ to } 5) \times T_f$

(If the mass of the lever itself in the drawing below is considered in the calculations, it should be regarded as an inertial load.)




### • Inertial load:

#### Definition for our purposes:

The load that is actually rotated by the actuator. Since the purpose is to rotate the load, and speed adjustment is necessary, allow an extra margin of 10 times or more in the effective torque.

\* Actuator effective torque  $\geq S \times T_a$   
(S is 10 times or more)

#### Accelerating torque calculation



## Allowable Load

Set the load and moment applied to the shaft within the allowable values provided in the table below.

(Operation above the allowable values can cause adverse effects on service life, such as pain in the shaft and loss of accuracy.)

Size	Allowable radial load Fr (N)	Allowable thrust load (N)	
		Fs(a)	Fs(b)
<b>05</b>	25	20	20
<b>1</b>	30	25	25


CRB
CRBU
<b>CRJ</b>
CRA1
CRQ
MRQ
MSQ
MSU

## Inertial Moment Formulas

I: Inertial moment kg·m<sup>2</sup>, m: Load mass kg

### 1. Thin shaft


Position of rotational axis: Perpendicular to the shaft anywhere along its length



$$I = m_1 \times \frac{a_1^2}{3} + m_2 \times \frac{a_2^2}{3}$$

### 2. Thin shaft


Position of rotational axis: Through the shaft's centre of gravity



$$I = m \times \frac{a^2}{12}$$

### 3. Thin rectangular plate (rectangular parallelepiped)


Position of rotational axis: Through the plate's centre of gravity



$$I = m \times \frac{a^2}{12}$$

### 4. Thin rectangular plate (rectangular parallelepiped)


Position of rotational axis: Perpendicular to the plate through one end (also the same in the case of a thicker plate)



$$I = m_1 \times \frac{4a_1^2 + b^2}{12} + m_2 \times \frac{4a_2^2 + b^2}{12}$$

### 5. Thin rectangular plate (rectangular parallelepiped)


Position of rotational axis: Through the centre of gravity and perpendicular to the plate (also the same in the case of a thicker plate)



$$I = m \times \frac{a^2 + b^2}{12}$$

### 6. Cylinder (including thin round plate)


Position of rotational axis: Through the plate's central axis



$$I = m \times \frac{r^2}{2}$$

### 7. Solid sphere


Position of rotational axis: Through the sphere's diameter



$$I = m \times \frac{2r^2}{5}$$


### 8. Thin round plate

Position of rotational axis: Through the plate's diameter



$$I = m \times \frac{r^2}{4}$$


### 9. Load at the end of lever



$$I = m_1 \times \frac{a_1^2}{3} + m_2 \times a_2^2 + K$$

(Example) When the shape of m<sub>2</sub> is a sphere, refer to 7 above.  $K = m_2 \times \frac{2r^2}{5}$

### 10. Gear transmission



1. Find the inertial moment  $I_B$  for the rotation of shaft (B).
2. Next,  $I_B$  is entered to find the inertial moment  $I_A$  for the rotation of shaft (A) as

$$I_A = \left(\frac{a}{b}\right)^2 \times I_B$$

## Kinetic Energy/Rotation Time

Even in cases where the torque required for rotation of the load is small, damage to internal parts may result from the inertial force of the load.

Take into account the load's inertial moment and rotation time during operation when making your model selection. (The inertial moment and rotation time charts can be used for your convenience in making model selections.)

### 1. Allowable kinetic energy and rotation time adjustment range

From the table below, set the rotation time within the proper adjustment range for stable operation. Note that slow speed operation exceeding the rotation time adjustment range, may lead to sticking or stopping of operation.


Size		Allowable kinetic energy mJ	Rotation time adjustment range for stable operation s/90°
05	Basic type <b>CRJB05</b>	0.25	0.1 to 0.5
	With external stopper <b>CRJU05</b>	1.0	
1	Basic type <b>CRJB 1</b>	0.40	
	With external stopper <b>CRJU 1</b>	2.0	

### 2. Inertial moment calculation

Since the formulas for inertial moment differ depending on the configuration of the load, refer to the inertial moment calculation formulas on the preceding page.

### 3. Model selection

Select models by applying the inertial moment and rotation time that you have calculated to the chart below.



#### 1. <How to read the chart>

- Inertial moment .....  $1 \times 10^{-5} \text{kg}\cdot\text{m}^2$
  - Rotation time .....  $0.5 \text{s}/90^\circ$
- CRJB05 is selected in this case.

#### 2. <Calculation example>

Load configuration: A cylinder of radius 0.05m and mass 0.04kg

Rotation time:  $0.4 \text{s}/90^\circ$

$$I = 0.04 \times 0.05^2 / 2 = 5 \times 10^{-5} \text{kg}\cdot\text{m}^2$$

In the inertial moment and rotation time chart, find the intersection of the lines extended from the points corresponding to  $5 \times 10^{-5} \text{kg}\cdot\text{m}^2$  on the vertical axis (inertial moment) and  $0.4 \text{s}/90^\circ$  on the horizontal axis (rotation time).

Since the resulting intersection point falls within the CRJU1 selection range, CRJU1 may be selected.

CRB
CRBU
<b>CRJ</b>
CRA1
CRQ
MRQ
MSQ
MSU

# Mini-Rotary Actuator Air Consumption

Air consumption is the volume of air that is expended by the Mini-Rotary Actuator's reciprocal operation inside the actuator and in the piping between the actuator and the switching valve. It is required for selection of a compressor and for calculation of its running cost.

\* The air consumption (Q<sub>CR</sub>) required for one reciprocation of a single Mini-Rotary Actuator alone is shown in the table below, and can be used to simplify the calculation.

## Formulas

$$Q_{CR} = 2V \times \left( \frac{P + 0.1}{0.1} \right) \times 10^{-3}$$

$$Q_{CP} = 2 \times a \times \ell \times \frac{P}{0.1} \times 10^{-6}$$

$$Q_C = Q_{CR} + Q_{CP}$$

Q<sub>CR</sub> = Air consumption of Mini-Rotary Actuator [ℓ (ANR)]

Q<sub>CP</sub> = Air consumption of tubing or piping [ℓ (ANR)]

V = Internal volume of Mini-Rotary Actuator [cm<sup>3</sup>]

P = Operating pressure [MPa]

ℓ = Length of piping [mm]

a = Internal cross section of piping [mm<sup>2</sup>]

Q<sub>C</sub> = Air consumption required for one reciprocation of Mini-Rotary Actuator [ℓ (ANR)]

When selecting a compressor, it is necessary to choose one that has sufficient reserve for the total downstream air consumption of all pneumatic actuators. This is affected by factors such as leakage in piping, consumption by drain valves and pilot valves, and reduction of air volume due to temperature drops.

## Formula

$$Q_{C2} = Q_C \times n \times \text{Number of actuators} \times \text{Reserve factor}$$

Q<sub>C2</sub> = Compressor discharge flow rate  
n = Actuator reciprocations per minute

## Internal cross section of tubing and steel piping

Nominal size	O.D. (mm)	I.D. (mm)	Internal cross section a (mm <sup>2</sup> )
T□ 0425	4	2.5	4.9
T□ 0604	6	4	12.6
TU 0805	8	5	19.6
T□ 0806	8	6	28.3
1/8B	—	6.5	33.2
T□ 1075	10	7.5	44.2
TU 1208	12	8	50.3
T□ 1209	12	9	63.6
1/4B	—	9.2	66.5
TS 1612	16	12	113
3/8B	—	12.7	127
T□ 1613	16	13	133
1/2B	—	16.1	204
3/4B	—	21.6	366
1B	—	27.6	598

## Air Consumption

Air consumption of rotary actuator: Q<sub>CR</sub> ℓ (ANR)

Size	Rotation	Internal volume (cm <sup>3</sup> )	Operating pressure (MPa)						
			0.15	0.2	0.3	0.4	0.5	0.6	0.7
05	90°	0.15	0.00074	0.00089	0.0012	0.0015	0.0018	0.0021	0.0024
	180°	0.31	0.0015	0.0018	0.0025	0.0031	0.0037	0.0043	0.0049
1	90°	0.33	0.0016	0.0020	0.0026	0.0033	0.0039	0.0046	0.0052
	180°	0.66	0.0033	0.0039	0.0052	0.0065	0.0078	0.0091	0.010



# Mini-Rotary Actuator

## Series CRJ

### How to Order

**Basic type** CRJ B 05 — 90 E — F9B S

**With external stopper** CRJ U 05 — 90 E — F9B S

**Rotation angle**

90	90°
100	100°
180	180°
190	190°

**Size**

05
1

**Number of auto switches**

Nil	2 pcs.
S	1 pc.

**Auto switch type**

Nil	Without auto switch (built-in magnet)
-----	---------------------------------------


\* Select applicable auto switches from the table below.

**Rotation angle**


90	90°
180	180°

**Connecting port position**

**Nil** Front port



**E** Side port



These auto switches have been changed  
Contact SMC or view [www.smcworld.com](http://www.smcworld.com)

F9N → M9N  
F9P → M9P  
F9B → M9B

### Applicable auto switches

Type	Special function	Electrical entry	Indicator light	Wiring (output)	Load voltage		Auto switch part no.		Lead wire length (m)*			
					DC	AC	Electrical entry direction		0.5 (Nil)	3 (L)	5 (Z)	
							Perpendicular	In-line				
Solid state switch	—	Grommet	Yes	3-wire (NPN)	24V	12V	—	—	F9N	●	●	—
				F8N				—	●	●	○	
				—				F9P	●	●	—	
				F8P				—	●	●	○	
				—				F9B	●	●	—	
				F8B				—	●	●	○	
	Diagnostic indication (2-colour indication)	—	—	—	3-wire (NPN)	—	—	—	F9NW	●	●	○
	3-wire (PNP)				—			F9PW	●	●	○	
	2-wire				—			F9BW	●	●	○	
	—				—			—	—	—	—	

\* Lead wire length symbols: 0.5m ..... Nil (Example) F9N  
3m ..... L (Example) F9NL  
5m ..... Z (Example) F9NWZ

\* Auto switches marked "○" are produced upon receipt of order.

CRB

CRBU

CRJ

CRA1

CRQ

MRQ

MSQ

MSU



## Specifications

Size/Type	05		1	
	Basic type	With external stopper	Basic type	With external stopper
Fluid	Air (non-lube)			
Max. operating pressure	0.7MPa			
Min. operating pressure	0.15MPa			
Ambient and fluid temperature	0° to 60°C (with no freezing)			
Rotation angle <sup>Note)</sup>	90 <sup>+8°</sup> <sub>0</sub> , 100 <sup>+10°</sup> <sub>0</sub> 180 <sup>+8°</sup> <sub>0</sub> , 190 <sup>+10°</sup> <sub>0</sub>	90, 180	90 <sup>+8°</sup> <sub>0</sub> , 100 <sup>+10°</sup> <sub>0</sub> 180 <sup>+8°</sup> <sub>0</sub> , 190 <sup>+10°</sup> <sub>0</sub>	90, 180
Angle adjustment range	—	±5° at each rotation end	—	±5° at each rotation end
Cylinder bore size	ø6		ø8	
Port size	M3			

Note) If optimum accuracy of the rotation angle is required, select an actuator with external stopper.

## Allowable Kinetic Energy and Rotation Time Adjustment Range

Size/Type			Allowable kinetic energy (mJ)	Rotation time adjustment range for stable operation (s/90°)
05	Basic type	CRJB05	0.25	0.1 to 0.5
	With external stopper	CRJU05	1.0	
1	Basic type	CRJB 1	0.40	
	With external stopper	CRJU 1	2.0	


## Weights

Type/Size	Model	Weight (g) <sup>Note)</sup>	
Basic type	05	CRJB05-90	32
		CRJB05-100	
		CRJB05-180	
		CRJB05-190	
	1	CRJB 1-90	54
		CRJB 1-100	
		CRJB 1-180	
		CRJB 1-190	
With external stopper	05	CRJU05-90	47
		CRJU05-180	53
	1	CRJU 1-90	70
		CRJU 1-180	81

Note) Above values do not include auto switch weights.


## Rotating Direction and Rotation Angle

- The shaft turns clockwise when the A port is pressurized, and counterclockwise when the B port is pressurized.
- For actuators with external stopper, the rotation end can be set within the ranges shown in the drawing by adjusting the stopper bolt.




### Basic type

For 90° and 100°




For 180° and 190°




### With external stopper

For 90°



For 180°



- Note) • The drawings show the rotation range for the shaft's single flat.  
 • The single flat position in the drawings shows the counterclockwise rotation end when the rotation angle is adjusted to 90° and 180°.

CRB

CRBU

**CRJ**

CRA1

CRQ

MRQ


MSQ

MSU


# Series CRJ

## Construction

### Basic type/CRJB



### With external stopper/CRJU



### Parts list


No.	Description	Material
1	Body	Aluminum alloy
2	Piston	Stainless steel
3	Shaft	Stainless steel
4	Bearing retainer	Aluminum alloy
5	Cover	Aluminum alloy
6	Bearing	Bearing steel
7	Piston seal	NBR
8	O-ring	NBR
9	Wear ring	Resin

No.	Description	Material
10	Magnet	Magnetic material
11	Round head no. 0 Phillips screw	Steel wire
12	Hexagon socket head set screw	Stainless steel
13	Stopper	Chrome molybdenum steel
14	Holder	Aluminum alloy
15	Stopper retainer	Steel
16	Hexagon socket head set screw	Steel wire
17	Hexagon nut	Steel wire
18	Hexagon socket head cap screw	Stainless steel

\* The mounting position of hexagon socket head set screws (no. 12) varies depending on the connecting port position.


**Dimensions/Size 0.5, 1**

**Basic type/CRJB**



CRB
CRBU
<b>CRJ</b>
CRA1
CRQ
MRQ
MSQ
MSU

**With external stopper/CRJU**




Size	Rotation angle	A	BA	BB	BC	BD	BE	BF	BG	BH	BI	CA	CB	D	DD	J	JA	JB	JC	JD	H	N	Q	S	SD	UU	W
CRJB05	90°	19.5	30	32.4	9.5	11	6.5	3.5	17.1	20	7	21.5	5.5	5g6	10h9	M4	5.8	3.5	M4	5	14.5	12.5	13.5	43	3.4	28	4.5
	180°			43.4								27												54			
CRJB 1	90°	23.5	35	37.4	12.5	14	9	4.5	21.1	22	8.5	24	7.5	6g6	14h9	M5	7.5	4.5	M5	6	15.5	13.5	16.5	48	5.9	32	5.5
	180°			50.4								30.5												61			


(mm)

# Series CRJ


## Auto Switch/Proper Mounting Position at Rotation End



For D-F9



For D-F8



Size	Rotation	D-F9 auto switch			D-F8 auto switch		
		A	Rotation range $\theta_m$	Actuation range	B	Rotation range $\theta_m$	Actuation range
05	90°	20.5	40°	10°	16.5	20°	10°
	180°	23.2			19.2		
1	90°	22.4	30°	10°	18.4	15°	10°
	180°	25.6			21.6		

Rotation range  $\theta_m$ : Value of the operating range  $L_m$  of a single auto switch converted to an axial rotation range.

Actuation range: Value of auto switch hysteresis converted to an angle.

# Auto Switch Common Specifications

## Auto Switch Common Specifications

Type	Solid state switch
Operating time	1ms or less
Impact resistance	1000m/s <sup>2</sup>
Insulation resistance	50MΩ or more at 500VDC (between lead wire and case)
Withstand voltage	1000VAC for 1min. (between lead wire and case)
Ambient temperature	-10° to 60°C
Enclosure	IEC529 standard IP67 JISC0920 watertight construction

CRB

CRBU

CRJ

CRA1

CRQ

MRQ

MSQ

MSU

## Lead Wire Lengths

### Indication of lead wire length

(Example)

**D-F9P** L

↓  
Lead wire length

	Lead wire length
Nil	0.5m
L	3m
Z	5m

Note 1) Lead wire length Z: Auto switch applicable to 5m length  
Solid state switches: All models are produced upon receipt of order.

Note 2) The standard lead wire length is 3m for water resistant 2-color indication solid state switches. (0.5m is not available.)

Note 3) For solid state with flexible wire specification, enter "-61" after the lead wire length.

(Example)

**D-F9PL**-61

↓  
Flexible specification

## Lead Wire Colour Changes

Lead wire colours of SMC auto switches have been changed in order to meet standard IEC947-5-2 for production beginning September, 1996 and thereafter, as shown in the tables below.

Take special care regarding wire polarity during the time that the old colours still coexist with the new colours.

### 2-wire

	Old	New
(+) Output	Red	Brown
(-) Output	Black	Blue

### 3-wire

	Old	New
(+) Power supply	Red	Brown
GND Power supply	Black	Blue
Output	White	Black

### Solid state with diagnostic output

	Old	New
(+) Power supply	Red	Brown
GND Power supply	Black	Blue
Output	White	Black
Diagnostic output	Yellow	Orange

### Solid state with latch type diagnostic output

	Old	New
(+) Power supply	Red	Brown
GND Power supply	Black	Blue
Output	White	Black
Latch type diagnostic output	Yellow	Orange



# Series CRJ/Specific Product Precautions

Be sure to read before handling.

## Rotation Angle Adjustment

### ⚠ Caution

As a standard feature, the actuator with external stopper is equipped with a rotation angle adjustment screw that can be used to adjust the angle of rotation.

Size	Angle adjustment per single rotation of angle adjustment screw
05	2.3°
1	2.3°

The rotation adjustment range for the actuator with external stopper is  $\pm 5^\circ$  at each rotation end. Please note that adjusting beyond this range, may cause product malfunction.

## Mounting of Speed Controller and Fittings

### ⚠ Caution

The M3 piping port is used. In case the speed controller or fittings are directly connected, use the series listed below.

- Speed controller  
AS12□1F/Elbow type  
AS13□1F/Universal type
- One-touch fitting  
One-touch mini Series KJ
- Reducer bushing Series M3


## Auto Switch Mounting

### ⚠ Caution

If a size 05 actuator with auto switch is being used, keep the magnetic body away at least 2mm or more from the bottom of the actuator.

If the magnetic body comes closer than 2mm, malfunction of the auto switch may occur due to the magnetic force drop.

\* When using the bottom face for mounting, a non-magnetic spacer (such as aluminum) is required as shown below.



## Maintenance


### ⚠ Caution

This product requires special tools; therefore, it cannot be disassembled for maintenance.

## External Stopper Unit

### ⚠ Caution

Order external stopper unit with the unit part numbers shown below.



Model	Unit part no.
CRJU05- 90	P531010-1
CRJU05-180	P531010-2
CRJU 1- 90	P531020-1
CRJU 1- 180	P531020-2

Note 1) External stopper units for 180° cannot be applied to the 90° Mini-Rotary Actuators.

Note 2) When using external stoppers for 90°, use Mini-Rotary Actuators with a rotation range of 100°, and for 180°, use actuators with a rotation range of 190°.

## External Stopper Assembly Procedure

\* Actuators with external stopper (Model CRJU) come already assembled; therefore, the following procedure is not required.

### ⚠ Caution




Figure 1

Figure 2

1 Assemble the stopper retainer to the stopper temporarily. Then place the stopper retainer in the single flat position and tighten with hexagon socket head cap screws.

Leave a space of approximately 0.5mm between the stopper and the Mini-Rotary Actuator, as shown in Figure 1.

Tighten the hexagon socket head cap screws evenly so that the stopper retainer is not unevenly tightened as in Figure 2.

Furthermore, take precautions to avoid applying excessive force to the shaft when tightening.

2 Tighten the holder assembly with hexagon socket head cap screws.

	Tightening torque N·m
Hexagon socket head cap screws	0.8 to 1.2