# **Precision Regulator**

# IR1000-A/2000-A/3000-A Series



ARJ AR425

to 935

ARX

AMR

ARM

ARP

IR□-A

IR

IRV

VEX

SRH

SRP


SRF

ITV

IC ITVH ITVX

PVQ VY1


VBA VBAT AP100




# Reduction in air consumption

# Air consumption is reduced with a new original structure.

With this new original structure, running costs are reduced.






# Flow rate: Up to approx. twice


(Compared to the	[L/min(ANR)]	
IR	Current model	Series
720	320	IR1000-A
1900	940	IR2000-A
	_	

Supply pressure: 0.7 MPa




Supply pressure: 0.7 MPa








#### 

#### Application Examples













# Balance and drive Accurate balance pressure setting Note) • Limits pressure fluctuation when driving a cylinder,



maintaining excellent static and dynamic balance.







Note) The set pressure may vary depending on the elapsed time and change in ambient temperature after pressure setting. If the setting value varies, adjust the pressure with the knob.



#### Series Variations

		Series	Model	Set pressure range (MPa)	Port size	SRH
	IR1000-A	7	IR1000-A	0.005 to 0.2		SRP
		G TO TO THE STATE OF THE STATE	IR1010-A	0.01 to 0.4	1/8	SRF
(qc		0.10	IR1020-A	0.01 to 0.8		ITV
(Knob)	IR2000-A		IR2000-A	0.005 to 0.2		IC
Type (	111200071		In2000-A	0.005 to 0.2		ITVH
o Ty		S STAN CO	IR2010-A	0.01 to 0.4	1/4	ITVX
Basic			IR2020-A	0.01 to 0.8		PVQ
	IR3000-A		IR3000-A	0.01 to 0.2		VY1
		G G	IR3010-A	0.01 to 0.4	1/4, 3/8, 1/2	VBA VBAT
		6. 6	IR3020-A	0.01 to 0.8		AP100

ARJ AR425 to 935 ARX AMR

ARM ARP

IR□-A

IR IRV

VEX

# RoHS

#### Symbol



Basic type (Knob)

#### **Standard Specifications**

Model	Basic type (Knob)			
Model	IR10□0-A	IR20□0-A	IR30□0-A	
Fluid		Air		
Proof pressure		1.5 MPa		
Max. supply pressure		1.0 MPa		
Min. supply pressure Note 1)	Set pressure	e + 0.05 MPa	Set pressure + 0.1 MPa	
	IR1000-A: 0.005 to 0.2 MPa	IR2000-A: 0.005 to 0.2 MPa	IR3000-A: 0.01 to 0.2 MPa	
Set pressure range	IR1010-A: 0.01 to 0.4 MPa	IR2010-A: 0.01 to 0.4 MPa	IR3010-A: 0.01 to 0.4 MPa	
	IR1020-A: 0.01 to 0.8 MPa	IR2020-A: 0.01 to 0.8 MPa	IR3020-A: 0.01 to 0.8 MPa	
Sensitivity		Within 0.2% of full span		
Repeatability Note 2)		Within ±0.5% of full span		
Air consumption Note 3)		1 L/min (ANR) or less		
Port size	1/8	1/4	1/4, 3/8, 1/2	
Pressure gauge port		1/8 (2 locations)		
Ambient and fluid temperature Note 4)	−5 to 60°C (No freezing)			
Weight (kg) Note 5)	0.13	0.23	0.47	

Note 1) When there is no flow rate on the outlet. (Refer to Operation (3) on page 806.)

Note 2) Other characteristics such as aging deterioration and temperature characteristics are not included.

Note 3) Measuring conditions: supply pressure 1.0 MPa, set pressure 0.2 MPa

Note 4) –5 to 50°C for the products with the digital pressure switch Note 5) Without accessories

#### Accessories (Option)/Part No.

Description		IR10□0-A	IR20□0-A	IR30□0-A	
Bracket assembly Note 1)		IR10P-501AS	IR20P-501AS	IR30P-501AS	
Hexagon	panel nut	IR10P-600S	IR20P-600S	IR20P-600S	
Round type	0.2 MPa setting	G33-2-□01	G43-2-□01	G43-2-□01	
pressure	0.4 MPa setting	G33-4-□01	G43-4-□01	G43-4-□01	
gauge Note 2)	0.8 MPa setting	G33-10-□01	G43-10-□01	G43-10-□01	
	NPN 1 output	l ISE20-N-M-□01-L			
Digital pressure switch Note 3)	PNP 1 output	ISE20-P-M-□01-L			
	NPN 2 outputs/ Voltage output	IS	E20A-R-M-□01	-J	
	NPN 2 outputs/	ISE20A-S-M-□01-J			

Note 1) This is an assembly of the bracket and set nut.

Note 2) ☐ in part numbers for a round type pressure gauge indicates a type of connection thread. No indication is necessary for R; however. indicate N for NPT.

A 1.0 MPa pressure gauge is fitted for 0.8 MPa setting. Please contact SMC regarding the supply of pressure gauge with psi unit specifications.

Note 3) in part numbers for a digital pressure switch indicates a type of connection thread. No indication is necessary for R; however, indicate N for NPT. For details on handling digital pressure switch and specifications, refer to the Best Pneumatics No. 8.

Please contact SMC regarding the supply of digital pressure switch with unit conversion function.


#### **Modular Products and Accessories**

Applicable products	Applicable size				
and accessories	IR1000-A series	IR2000-A series	IR3000-A series		
Filter	AF20-A	AF30-A	AF40-A		
Spacer	Y200-A	Y300-A	Y400-A		
Spacer with bracket	Y200T-A	Y300T-A	Y400T-A		

Refer to pages 427 and 430 for details of the modular applicable products and accessories. The former modular and mounting brackets can be used.



#### How to Order



• Option/Semi-standard: Select one each for a to e.

 Option/Semi-standard symbol: When more than one specification is required, indicate in alphanumeric order.



ARJ

AR425

to 935

ARX

Made to Order (Refer to page 804-1)

Symbol	Specifications/Content
10-	Clean series
25A-	Secondary battery compatible
-X1155	Fluororubber specification
-X1	Non-grease specifications
IRM□-	Manifold specifications

						-X1 IRM□-	Non-grease special Manifold special		
_	_	_		Symbol	Description		Body size		
						1	2	3	
T				_	0.005 to 0.2 MPa	•	•	_	
	_			0	0.01 to 0.2 MPa			•	
İ	S	et p	ressure range	1	0.01 to 0.4 MPa	•	•	•	
				2	0.01 to 0.8 MPa	•	•	•	
				+			•		
				0	Bottom exhaust	•	•	•	
		Exha	aust direction	1	Front exhaust	_	_	•	
L				2	Rear exhaust		_	•	
_				+					
				Nil	Rc	•	•	•	
		Pipe	e thread type	N	NPT	•	•	•	
				F	G		•	•	
_				+					
				01	1/8	•	<del></del>	_	
			Port size	02	1/4		•	•	
Port size		03	3/8		_	•			
				04	1/2	<u> </u>		•	
			I	+ Nil	AAPIL 1 P P			_	
			а	Marria	B Note 2)	Without mounting option With bracket	•	•	•
				Mounting	H	With hexagon panel nut (for panel mount)	-	•	
;	<del>-</del>				with nexagon panel nut (for panel mount)		•		
-	ote		1	+ Nil	Without pressure gauge				
	Option Note 1)		Pressure gauge	G	Round type pressure gauge		+ :	-	
:	ŧ			EA	NPN open collector 1 output				
(	0	b	With digital	EB	PNP open collector 1 output				
			pressure switch		NPN open collector 1 output + Analog voltage output		<b>—</b>	-	
			F. 200010 CIMON	ED	NPN open collector 1 output + Analog current output			•	
				+					
Ī				Nil	Flow direction: Left to right	•	•	•	
		С	Flow direction	R	Flow direction: Right to left	•	•	•	
•	ard ard			+	<u> </u>				
	ığ		I/h	Nil	Upward	•	•	•	
	sta	d	Knob	V	Downward	•	•	•	
	Semi-standard			+			•		
,	Ser			Nil	Name plate and pressure gauge in imperial units: MPa	•	•	•	
	٠,	е	Pressure unit Note 3)	Z	Name plate and pressure gauge in imperial units: psi	•	•	•	
Ĺ				7.0	Digital pressure switch: With unit conversion function			•	

Note 1) Options are shipped together with the product, but not assembled. B and H cannot be selected at the same time. The current bracket cannot be used for this product. Note 2) Assembly of a bracket and set nuts.

Digital pressure switch: With unit conversion function

Note 3) See pressure	unit	table	below.
----------------------	------	-------	--------

ZA

Note 3) See pressure unit table below.					
	Pipe thread	Name plate	Pressure gauge	Pressure gauge in imperial units	
	type	in imperial units	perial units G EA, EB, EC, ED		Sales Note 6)
	Rc				lanan
Nil	NPT	MPa	MPa	Fixed SI unit	Japan, Overseas
	G				Overseas
	Rc	_	_	_	
Z Note 4)	NPT	psi	psi	With unit conversion function (Initial value psi)	Only overseas
	G	_	_	_	
	Rc			With unit conversion	
ZA Note 5)	NPT	MPa	_	function	Only overseas
	G			Turiction	


Note 4) For pipe thread type: NPT


Note 5) For options: EA, EB, EC, ED

Note 6) According to the new Measurement Law, only the SI unit type is provided for use in Japan.


#### IR1000-A Series


\* The data shown below are representative values, and are not guaranteed.






#### Pressure Characteristics









#### IR2000-A Series

\* The data shown below are representative values, and are not guaranteed.








# 

IR IRV

#### **Pressure Characteristics**









VY1

VBA VBAT


#### IR3000-A Series


\* The data shown below are representative values, and are not guaranteed.






#### Pressure Characteristics








#### Construction

#### Basic type (Knob): IR20□0-A



#### Working principle

When the knob is rotated, the flapper is pushed through the spring, and a gap is generated between the nozzle and flapper. The supply pressure flows to the inlet passes through the path between the nozzle and flapper and acts on the supply diaphragm as nozzle back pressure. The force generated by the diaphragm pushes down the valve, and the supply pressure flows to the outlet. The discharged air pressure acts on the exhaust diaphragm, and counteracts against the force generated by the supply diaphragm. The air pressure acts on the nozzle diaphragm at the same time, and counteracts against the compression force of the spring to adjust the set pressure. When the set pressure increases too much, the nozzle diaphragm is pushed up, and a gap is generated between the flapper and nozzle diaphragm after the flapper is closed. The balance of the supply diaphragm and exhaust diaphragm is lost when the nozzle back pressure flows into the atmosphere. The exhaust valve is open after the valve is closed, and excess pressure on the outlet is released to the air. Due to this pilot mechanism, fine pressure variations are detected and precise pressure adjustment is possible.

#### Component Parts

0011	ipoliciit i alto					
NI-	Donalistica.	Material				
INO.	No. Description	IR1000-A	IR2000-A	IR3000-A		
1	Bonnet	Aluminum die-casted				
2	Nozzle diaphragm assembly	Aluminum, Weather resistant NBR				
3	Seal	HNBR				
4	Seal	NBR				
5	Diaphragm spacer	Polyacetal				
6	Supply diaphragm	Weather resistant NBR —				
7	Exhaust diaphragm assembly	Steel, Aluminum, Weather resistant NBR Aluminum, Weather resistant NBR,				
8	Valve assembly	Stainless steel, Aluminum, HNBR Aluminum, HNBR				
9	Rody	Aluminum die-casted				

ARJ AR425 to 935

passage AMR

ARM

IR□-A

IRV VEX

SRH

SRP SRF

> ITV IC

ITVH

ITVX PVQ

VY1


VBA VBAT

#### Construction

#### Basic type (Knob): IR10□0-A



IN side passage






OUT side passage

#### Basic type (Knob): IR30 □ 0-A



IN side passage






OUT side passage

#### Basic type (Knob): IR30□2-A



IN side passage







OUT side passage

#### **Dimensions**

#### Basic type (Knob): IR10□0-□01□-A










Mounting hole for

hexagon panel nut








When connecting to the EXH port, contact your SMC sales representative separately.

#### With digital pressure switch: IR10□0-□01□E□-A



ARJ AR425 to 935 ARX AMR

> ARP R■-A

IR IRV

VEX

SRP SRF

ITV

IC


ITVH

ITVX PVQ

VY1

#### **Dimensions**

#### Basic type (Knob): IR20□0-□02□-A



60.5

When connecting to the EXH port, contact your SMC sales representative separately.


EXH

#### With digital pressure switch: IR20□0-□02□E□-A

EXH

2 x 1/8

Pressure gauge port



Panel

91.7

65.3

42

Exhaust port

EXH


161

#### **Dimensions**

Pressure gauge port

IN.

#### Basic type (Knob): IR30□0-□0□□-A



76.1

84

OUT




2.3 M28 x 1.5 2 x 1/4 to 1/2 Port size

With digital pressure switch: IR30□0-□0□□E□-A

EXH

□66



ARJ AR425 to 935 ARX

AMR ARM

ARP IR□-A

IR

IRV VEX

SRH SRP

SRF ITV

IC ITVH


ITVX

PVQ VY1


VBA VBAT AP100

#### **Dimensions**

#### Basic type (Knob): IR30□2-□0□□-A



#### With digital pressure switch: IR30□½-□0□□E□-A




# IR1000-A/2000-A/3000-A Series Made to Order

Please contact SMC for detailed dimensions, specifications, each part number and lead times,



Clean	1 Clean Series			
10 — IR	0			
Clean series Specifications				
Cleanliness	ISO Class 3			
Bleed hole	With M5 fitting (Applicable tubing O.D. ø6)			
EXH port	IR1000-A series: With M5 fitting (Applicable tubing O.D. ø6) IR2000-A series: With R1/8 fitting (Applicable tubing O.D. ø6) IR3000-A series: 1/2 female thread			
Pressure gauge	Oil-free + Stud parts nickle plated			
Grease	Fluorine grease			



Zinc chromate or copper-based plating is not used.


specification

Grease Grease compatible with low dew point

Parts surface treatment

Note 1) Electroless nickel plating is used. Note 2) Combinations with the pressure gauge are not available.






Note 1) Assembly is performed in a general assembly environment.

Note 2) Parts are not washed.

Note 3) Fluorine grease is used on some of the wetted parts (sliding parts) and non-wetted parts (threaded part on the setting knob).



Specifications				
Stations	2 to 8 stations			
	Common SUP	IR1000-A series: 1/4, IR2000-A series: 1/2		
Port	Individual OUT	IR1000-A series: 1/8, IR2000-A series: 1/4		
	Individual EXH (From IR body)			
Set pressure	0.2 MPa, 0.4 I	MPa and 0.8 MPa settings can be combined.		
Accessory (Pressure gauge)	G33-□-01(IR1000-A series), G43-□-01(IR2000-A series)			

Note 1) Regulators to be manifolded are counted starting from stations 1 on the left side with the OUT ports in front.

Note 2) When regulators with a different set pressure are manifolded, viewing OUT ports from front, the low pressure range is installed on the left side and high pressure range is on the right side. In case of the Example 2) above mentioned, stations 1 and 2 are of 0.2 MPa setting, stations 3 and 4 are of 0.4 MPa setting, and station 5 is of 0.8 MPa setting.

Note 3) For the model with pressure gauge (G), the pressure gauge is shipped together, but not assembled.

VBA

VBAT AP100





# IR1000-A/2000-A/3000-A Series **Specific Product Precautions 1**

Be sure to read this before handling the products. Refer to back page 50 for Safety Instructions and pages 387 to 391 for F.R.L. Precautions.

**Piping** 

## **⚠** Warning


1. Screw piping together with the recommended proper torque while holding the side with the female threads.

Looseness or faulty sealing will occur if tightening torque is insufficient, while thread damage will result if the torque is excessive

Furthermore, if the side with the female threads is not held while tightening, excessive force will be applied directly to piping brackets, etc., causing damage or other problems.


Recomme	[N·m]			
Connection thread	1/8	1/4	3/8	1/2 Note)
Torque	7 to 9	12 to 14	22 to 24	28 to 30

Note) Tightening force for connecting to the EXH port of IR30□2-A is 8 to 10 N·m.



2. Do not allow twisting or bending moment to be applied other than the weight of the equipment.

Provide separate support for external piping, as damage may otherwise occur.



3. Piping materials without flexibility such as steel tube piping are prone to be effected by excess moment load and vibration from the piping side. Use flexible tubing in between to avoid such an effect.

#### 

1. Preparation before piping

Before piping is connected, it should be thoroughly blown out with air (flushing) or washed to remove chips, cutting oil and other debris from inside the pipe.

Piping

# **⚠** Caution

2. Winding of sealant tape

When screwing piping or fittings into ports, ensure that metal chips from the pipe threads or sealing material do not enter the piping. Also, when the sealant tape is used, leave 1.5 to 2 thread ridges exposed at the end of the threads.



**Operating Environment** 

# ∧ Warnina

- 1. Do not use in an atmosphere having corrosive gases, chemicals, sea water, water, water steam, or where there is direct contact with any of these.
- 2. Do not operate in locations where vibration or impact occurs.
- 3. In locations which receive direct sunlight, provide a protective cover, etc.
- 4. In locations near heat sources, block off any radiated heat.
- In locations where there is contact with spatter from water, oil or solder, etc., implement suitable protective measures.

Air Supply

#### **∕**!∖ Warning

- 1. Please consult with SMC when using the product in applications other than compressed air.
- 2. Do not use compressed air which includes chemicals, synthetic oils containing organic solvents, salt or corrosive gases, etc., as this can cause damage or malfunction.
- 3. If condensate in the drain bowl is not emptied on a regular basis, the bowl will overflow and allow the condensate to enter the outlet side. This will cause a malfunction of pneumatic equipment.

When removing drain is difficult, use of a filter with an auto drain is recommended.

# ∕**.**∖ Caution

- 1. Condensate or dust, etc. in the supply pressure line can cause malfunctions. In addition to an air filter (SMC AF series, etc.), please use a mist separator (SMC AM, AFM series) depending on the conditions. Refer to "Air Preparation Equipment Model Selection Guide"
  - (pages 2 and 3) for air quality.
- 2. When a lubricator is used at the supply side of the product, it can cause malfunctions. Do not use a lubricator at the supply side of the product. If lubrication is required for terminal devices, connect a

lubricator on the output side of the regulator.

AR425 to 935 ARX

AMR

**ARJ** 

ARM ARP

IR□-A

IR

IRV VEX

SRH SRP

SRF

ITV IC

ITVH

ITVX

PVQ VY1

VBA VBAT AP100

805





# IR1000-A/2000-A/3000-A Series Specific Product Precautions 2

Be sure to read this before handling the products.

Refer to back page 50 for Safety Instructions and pages 387 to 391 for F.R.L. Precautions.

#### Maintenance

# **⚠** Warning

- When the product is removed for maintenance, reduce the set pressure to "0" and shut off the supply pressure completely beforehand.
- 2. When a pressure gauge is to be mounted, remove the plug after reducing the set pressure to "0".
- When using the regulator between a solenoid valve and an actuator, check the pressure gauge periodically. Sudden pressure fluctuations may shorten the durability of the pressure gauge.
  - A digital pressure gauge is recommended for such situation or as deemed necessary.

#### Handling

#### **⚠** Caution

 When the precision regulator with pressure gauge is used, do not apply impact to the product by dropping it, etc. during transportation or installation.

This may cause misalignment of the pressure gauge pointer.

#### Operation

#### **∧** Caution

- Do not use a precision regulator outside the range of its specifications as this can cause failure. (Refer to the specifications.)
- 2. When mounting is performed, make connections while confirming port indications.
- When mounting the bracket or tightening the hexagon panel nut on the panel, tighten them to the recommended proper torque.

Looseness or faulty sealing will occur if tightening torque is insufficient, while thread damage will result if the torque is excessive

#### Recommended Proper Torque (N·m)

Set nut (for bracket)

IR10□0-A	IR20□0-A	IR30□□-A
	2.0±0.2	

Hexagon panel nut (for knob type only)

		, , ,
IR10□0-A	IR20□0-A	IR30□□-A
	3.5±0.5	

- After pressure adjustment, be sure to tighten the lock nut. When tightening the nut, tighten so that the knob does not move due to friction caused by tightening.
- When pressure is applied to the inlet of a regulator, make sure that the output is connected to the circuit. Air blow occurs from the outlet and it depends on the operating conditions.
- The set pressure may vary depending on the elapsed time and change in ambient temperature after pressure setting. If the setting value varies, adjust with the knob.

#### Operation

### **⚠** Caution

- If the directional control valve (solenoid valve, mechanical valve, etc.) is mounted and ON-OFF is repeated for a long time, the set pressure may vary. If the setting value varies, adjust with the knob.
- There may be pulsation or noise depending on the pressure conditions, piping conditions and ambient environment. In this case, it is possible to improve the problem by changing the pressure conditions and piping conditions.

   May be problem in a put improved contact your SMC colors.

   May be problem in a put improved contact your SMC colors.

   May be problem in a put improved contact your SMC colors.

   MC colo
  - If the problem is not improved, contact your SMC sales representative.
- The capacity of the output side is large, and when used for the purpose of a relief function, the exhaust sound will be loud when being relieved. Therefore, operate with a silencer (SMC AN series, etc.) mounted on the exhaust port (EXH port).
  - When using the IR1000-A and 2000-A series, contact your SMC sales representative.
- When installing a pressure gauge to the product, do not apply pressure more than the maximum display pressure. This will cause a malfunction.
- When using a precision regulator between a solenoid valve and cylinder, caution should be taken regarding the following points.
  - The residual pressure of the cylinder will be exhausted from the regulator's exhaust port. (Depending on the conditions, partial backflow may occur.)
  - When holding pressure at the intermediate position of a closed center solenoid valve, due to reduced pilot pressure the pressure inside the cylinder will not be able to be held because the regulator will perform an exhaust operation. If it is necessary for the pressure inside the cylinder to be held, please consider using in combination with a separate shut-off valve.
  - When releasing pressure at the intermediate position of an exhaust center solenoid valve, depending on the conditions, vacuum pressure may remain inside the cylinder. If the introduction of atmospheric pressure is required, please consider using in combination with a separate atmospheric pressure introduction valve.
- 12. When using the IR3000-A series in balancing applications, abnormal noises may occur depending on the pressure and circuit conditions. In such cases, the noise will often cease if changes are made to the pressure or piping conditions or if a high noise reduction type silencer (such as SMC's ANA1 series, etc.) is installed.
- 13. The min. supply pressure is the min. required supply pressure for when there is no flow on the output side. If flow is to be used, or if the volume on the outlet side is large, supply pressure with sufficient margins in regards to the set pressure if responsiveness is required.
- 14. When a precision regulator is used in applications in which back pressure is frequently applied or when it is used in environments where vibration is present or pulsations are present in the set pressure, wear of the exhaust valve may be accelerated, resulting in increased premature exhaust leakage.