
## Series 11-MXJ Ø4, Ø6, Ø8 Air Slide Table



#### Auto Switch Specifications (Refer to the WEB catalog for detailed specifications and auto switches not in the following table.)

	Special Electrica			Wiring	Load voltage		Itage	Auto switch model	Lead wire length (m)*			
Type	function	Electrical entry	Indicator light	(Output)	DC		AC	Electrical entry direction	0.5	3	Applicable load	
	Idilottoti	entry	ligit	(Output)			AC	In-line	(Nil)	(L)		
Reed auto switch	_	Grommet	Yes	2-wire	24 V 12 V		100 V	A93	•	•	_	Relay, PLC
Solid state auto switch	_	Grommet	Yes	3-wire (NPN)	1 24 V I	12 V		M9N	•	•	_	Relay, PLC
			res	2-wire		12 V		M9B	•	•	Re	Helay, PLC

<sup>\*</sup> Lead wire length symbols 0.5 m......Nil (Example) A93 3 m.....L A93L

PLC: Programmable Logic Controller

#### **Specifications**

Mod	el	11-MXJ4	11-MXJ6	11-MXJ8				
Bore size (mm)		4.5	6	8				
Piping port size		M3 x 0.5						
Fluid			Air					
Action			Double acting					
Operating pressure	1	0.15 to 0.7 MPa						
Proof pressure		1.05 MPa						
Ambient and fluid to	emperature	-10 to 60°C						
Operating speed ra		50 to 500 mm/s						
(Average operating	speed) Note)	(Metal stopper: 50 to 200 mm/s)						
Cushion		Rubber bumper						
• • • • • • • • • • • • • • • • • • • •		1.05 MPa -10 to 60°C 50 to 500 mm/s (Metal stopper: 50 to 200 mm/s) Rubber bumper (Metal stopper: Without cushion) Non-lube	ushion)					
Lubrication			Non-lube					
Stroke adjusting rang	ge (Metal stopper)	0 t	o 5 mm at both er	nds				
Stroke length tolera	ince	+1 0 mm						
Cleanliness class	Without adjuster		Class 5					
(ISO class)	Metal stopper		Class 6	Class 6				
Note) Average operating	speed: Speed that th	e stroke is divided b	y a period of time fro	om starting the				


#### Suction Flow Rate of Vacuum Suction Type (Reference values)

Size	Suction flow rate L/min (ANR
4	1
6	1
8	1

#### Auto Switch Proper Mounting Position (Detection at Stroke End)

Reed Solid state auto switch auto switch D-A93 D-M9□

operation to reaching the end.



\* Values in the table below are used as a reference when mounting the auto switches for stroke end detection. For actually setting the auto switches, adjust them after confirming their operation. Reed Auto Switch: D-A93

neeu Auto	SWILCII.	D-A33											(mm)
		-	4			В				С			
Model		Str	oke			Str	oke			Str	oke		Auto switch operating range
	5	10	15	20	5	10	15	20	5	10	15	20	operating range
11-MXJ4	9	4	_	_	14	14	_	_	0.5	0.5	_	_	
11-MXJ6	9	4	3	_	14	14	18	_	0.5	0.5	-0.5	_	4
11-MXJ8	9	4	10	5	14	14	25	25	-0.5	-0.5	0.5	0.5	
Solid State	Auto S	witch (Le	ad Wire,	In-line l	Entry): D	-M9□							(mm)

	· · · · · · · · · · · · · · · · · · ·													
			A		В				С				A . da a itala	
Model	Model Stroke				Stroke				Stroke				Auto switch operating range	
	5	10	15	20	5	10	15	20	5	10	15	20	operating range	
11-MXJ4	13	8	_	_	18	18	_	_	4.5	4.5	_	_	2	
11-MXJ6	13	8	7	_	18	18	22	_	4.5	4.5	3.5	_	0.5	
11-MXJ8	13	8	14	9	18	18	29	29	3.5	3.5	4.5	4.5	2.5	

### **Auto Switch Mounting**

When using the solid state auto switch (D-M9\(\sigma\)), mount it in the illustrated direction. The lower slot is for extension end detection.

#### · Lead wire, in-line entry (D-M9□)






#### Dimensions Note) In the 11-MXJ4, there is no change in total length by stroke.

# Basic (Without switch rail) 11-MXJ4- N Vacuum port M3 x 0.5 (Plugged when the product is a symmetric type.) (Plugged when the product is a symmetric type.)

27.5


8


5.



- Note 1) When using a positioning pin, use a stepped positioning pin. For details, please consult with your SMC sales representative.
- Note 2) Since the body and table are constructed with a magnetic substance, it becomes magnetized when magnets, etc. are attached to them, and this may cause the auto switch malfunction.
- Note 3) If workpiece holding bolts are used, they can touch the body and cause malfunctions, etc.

  Refer to the Specific Product Precautions.









A-A

<sup>\*</sup> Other dimensions are the same as standard model (Series MXJ).


#### **Dimensions**




Operating port 2 x M3 x 0.5 11-MXJ6-□□□N 12 (Plugged when the product is a symmetric type.) Vacuum port M3 x 0.5 (Plugged when the product is a symmetric type.) 4 Ó Ó 5. Κ 8




- Note 1) When using a positioning pin, use a stepped positioning pin. For details, please consult with your SMC sales representative.
- Note 2) Since the body and table are constructed with a magnetic substance, it becomes magnetized when magnets, etc. are attached to them, and this may cause the auto switch malfunction.
- Note 3) If workpiece holding bolts are used, they can touch the body and cause malfunctions, etc. Refer to the Specific Product Precautions.






Model	G	GA	Н	I	J	K	М	Z	ZZ
11-MXJ6-5	11	17	17	5	17	27.5	42.5	37	43
11-MXJ6-10	11	17	17	5	17	27.5	42.5	37	43
11-MXJ6-15	13	22	20	7	20	31.5	47.5	42	48
							_		



\* Other dimensions are the same as standard model (Series MXJ).

#### **Dimensions**





48 55

39.5 54.5

55

39.5 54.5 48

11-MXJ8-15

11-MXJ8-20

19 28

19 28 20

20 8

8

#### **Made to Order**

Anti-corrosive guide unit -X42

11-MXJ Standard model no. -X42

Martensitic stainless steel is used for table and body. Use this treatment if more effective anti-corrosiveness is necessary.

Anti-corrosive treatment Note 2) is applied to the table and body.

Note 1) Dimensions are the same as standard type.

Note 2) Special anti-corrosive treatment makes the table and body black.