
Circulating Fluid Temperature Controller Refrigerated Thermo-chiller

HRZ Series



Energy Saving






Space Saving

Installation area: Max. 29% reduction (SMC comparison)

By emitting the heat from the rear side, ventilation slits on the side are unnecessary offering reduced installation space.

- Current model: Body space: W400 mm x D845 mm Ventilation space: 100 mm
- HRZ008-H: Body space: W380 mm x D870 mm Ventilation space: 0



HRS

HRS090

HRS100/150

HRSH090

HSHH

HRSE

HRZ

HRZD

HRW

HECR

HEC


HEB

HED

Technical Data

HRZ008-H 0.66 m²

Current model 0.93 m²



SMC

Communications

- Analog communication (Refer to "Options" on page 249.)
- DeviceNet communication (Refer to "Options" on

Fluid contact parts adopt the materials compatible for various circulating fluids.

• Fluorinated fluids: Flourinert™ FC-3283, FC-40

GALDEN[®] HT135. HT200

• 60% ethylene glycol aqueous solution


Regarding the fluid other than the above, please contact SMC. Flourinert[™] is a trademark of 3M. GALDEN[®] is a registered


Easy Maintenance

Circulating fluid automatic recovery function (Refer to "Options" on page 249.)

Circulating fluid inside a thermo-chiller tank can be recovered automatically. (Recovery volume: 15 L to 17 L)

- Reduced maintenance time
- Faster operation
- Reduced circulating liquid loss by evaporation or spill






Circulating fluid electric


resistance ratio control function (Refer to "Options" on page 249.) (DI control kit)

Easy maintenance

Checking the electrical component parts accessible from the front side only




- Possible to replace the maintenance parts (such as a pump) without removing the pipings and discharging the circulating fluid.
- Various alarm displays (Refer to page 245.)






Application Examples



SMC



Circulating fluid circuit

With the **circulating pump**, circulating fluid will be discharged to the user's equipment side. After the circulating fluid will heat or cool the user's equipment side, it will be returned to the **main tank** via the **heat exchanger**.

A **sub-tank** is not used under the normal operation. It will be used when a circulating fluid is recovered from the user's equipment side.

The **internal pump** is used to transfer a circulating fluid from the **sub-tank** to the **main tank**. (Refer to "Circulating fluid automatic recovery function" on page 223.)

Refrigeration circuit

When the circulating fluid temperature is rising higher than the set temperature, open the **expansion valve (a)** to introduce refrigerant gas at a lower temperature to the **heat exchanger**. With this, the circulating fluid will be cooled down.

Oppositely, when the circulating fluid is getting lower against the set temperature, open the **expansion valve (b)** and introduce refrigerant gas at a high temperature without going through the **water-cooled condenser** to the **heat exchanger**. With this heat, the circulating fluid will be heated.

CONTENTS

HRZ Series



Refrigerated Thermo-chiller HRZ Series

Model Selection

Guide to Model Selection Press	age 2	227
Required Cooling Capacity CalculationPa	age 2	228
Precautions on Model SelectionP	age 2	229
Circulating Fluid Typical Physical Property Values ··· Pa	age 2	230

Fluorinated Fluid Type

How to Order/Specifications Page 231
Cooling Capacity/Heating Capacity Page 232
Pump Capacity Page 233

Ethylene Glycol Type

How to Order/Specifications	Page 234
Cooling Capacity/Heating Capacity	Page 235
Pump Capacity	Page 236

Tap/Deionized Water Type

How to Order/Specifications	Page 237
Cooling Capacity/Heating Capacity/Pump Capacity ····	Page 238

Double Inverter Type

How to Order/Specifications	Page 239
Cooling Capacity/Heating Capacity/Pump Capacity ····	Page 240

Common Specifications

•	
Dimensions	Page 241
Communication Functions	Page 243
Contact Input/Output	Page 243
· Serial RS-485 ·····	Page 244
Connector Location	Page 244
Operation Display Panel	Page 245
Alarm ·····	Page 245

Optional Accessories

①Bypass Piping Set ······Page 246
② Anti-quake Bracket Page 246
③4-Port Manifold Page 247
④ DI Filter ······ Page 247
(5) Insulating Material for DI Filter Page 247
$\textcircled{6}$ 60% Ethylene Glycol Aqueous Solution $\cdots\cdots$ Page 248
⑦ Concentration Meter Page 248

Options

Analog Communication	Page 249
DeviceNet Communication	Page 249
NPT Fitting	Page 249
DI Control Kit ·····	Page 249
Circulating Fluid Automatic Recovery	Page 250

Specific Product Precautions Page 251



HED



Guide to Model Selection

1. How much is the temperature in degrees centigrade for the circulating fluid?

Temperature range which can be set with the thermo-chiller

L : -20°C to 40°C ("L2" (tap water, deionized water specification) can be set 10°C to 40°C.)

H: 20°C to 90°C


W: -20°C to 90°C (Select "W" only when the temperature ranges of "L" or "H" are not applicable. HRZ010-W2S (tap water, deionized water specification) can be set 10°C to 60°C.)

Example) User requirement: 50°C (→ Temperature range 20°C to 90°C, "H" type will be appropriate.)

2. What kind of the circulating fluids will be used?

Relationship between circulating fluid (which can be used with the thermo-chiller) and temperature

Fluorinated fluids: Fluorinert[™] FC-3283/GALDEN[®] HT135



Example) User requirement: Fluorinated fluids


Based on the results 1. and 2., Cooling capacity relating "Fluorinated fluids" and "Temperature range 20° C to 90° C" is shown on page 232.

3. What is the kW for the required cooling capacity? * To calculate the cooling capacity, referring to page 228.

Example) User requirement: 5 kW \rightarrow

Plot the point of intersection between the operating temperature (50°C) and the cooling capacity (5 kW) in the cooling capacity graph.

[Cooling Capacity Graph] Circulating Fluid: Fluorinated Fluids, Temperature Range: 20 to 90°C



The point plotted in the graph is the requirement from the user. Select the thermo-chiller models exceeding this point. In this case, select the **HRZ004-H**.

GALDEN® is a registered trademark, belonging to the Solvay Group or its corresponding owner. Fluorinert™ is a trademark of 3M.

A 227



Example 1: When the heat generation amount in the user's equipment is known.

Heat generation amount Q: 3.5 kW

Cooling capacity = Considering a safety factor of 20%, 3.5 x 1.2 = 4.2 kW

Specific heat C:

(at 20°C)

. 0.96 x 10³ J/(kg⋅K)

Example 2: When the heat generation amount in the user's equipment is not known.

Obtain the temperature difference between inlet and outlet by circulating the circulating fluid inside the user's equipment.

Heat generation amount Q: UnknownCirculating fluid temperature difference $\Delta T (= T2 - T1)$: 6.0°C (6.0 K)Circulating fluid outlet temperature T1: 20°C (293.15 K)Circulating fluid return temperature T2: 26°C (299.15 K)Circulating fluid flow rate L: 20 L/minCirculating fluid: Fluorinated fluid
Density γ : 1.80 x 103 kg/m3

 Refer to page 230 for the typical physical property values by circulating fluid.


$$\mathbf{Q} = \frac{\Delta \mathbf{T} \mathbf{x} \mathbf{L} \mathbf{x} \, \gamma \, \mathbf{x} \, \mathbf{C}}{\mathbf{60} \, \mathbf{x} \, \mathbf{1000}}$$

 $=\frac{6.0 \times 20 \times 1.80 \times 10^3 \times 0.96 \times 10^3}{60 \times 1000}$

= 3456 W = 3.5 kW

Cooling capacity = Considering a safety factor of 20%, $3.5 \times 1.2 = 4.2 \text{ kW}$

Thermo-chiller



Unknown $6.0^{\circ}C$ $20^{\circ}C$ $26^{\circ}C$ $1.2 \text{ m}^3/\text{h}$ Fluorinated fluid Density γ : $1.80 \times 10^3 \text{ kg/m}^3$ Specific heat **C**: $0.23 \text{ kcal/kg.}^{\circ}C$ (at $20^{\circ}C$)

Example of current measurement units (Reference)

 Refer to page 230 for the typical physical property values by circulating fluid.

$$\mathbf{Q} = \frac{\Delta \mathbf{T} \mathbf{x} \mathbf{L} \mathbf{x} \gamma \mathbf{x} \mathbf{C}}{860}$$

6 0 x 1 2 x 1 80 x 10³ x 0 23

$$=\frac{\frac{6.0 \times 1.2 \times 1.80 \times 10^{5} \times 0.23}{860}}{860}$$

Cooling capacity = Considering a safety factor of 20%,

3.5 x 1.2 = 4.2 kW

HRZD HRZ

HRW

HECR

HEC

HEB

HED

Technical Data

HRS

HRS090

HRS100/150

HRSH090

HRSH

HRSE

HRZ Series

Required Cooling Capacity Calculation

Example 3. When there is no heat generation, and when cooling the object below a certain temperature and period of time.

either HRZ002-L or HRZ004-H.)

Cooling capacity = Considering a safety factor

of 20%,

(In this case, selected thermo-chiller model will be

2.3 x 1.2 = 2.8 kW (When the circulating

fluid temperature is 20°C.)

= 2.3 kW

Cooled substance total volum Cooling time h Cooling temperature difference Circulating fluid	: 15 min	Example of current measurement units (Reference) 0.06 m³ 0.25 h 20°C Fluorinated fluid Density γ: 1.80 x 10 ³ kg/m³			
 Refer to page 230 for the ty by circulating fluid. 	Specific heat C : 0.96 x 10 ³ J/(kg·K) (at 20°C) ypical physical property values				
$Q = \frac{\Delta T \times V \times \gamma \times C}{h \times 60 \times 1000}$ 20 x 60 x 1.80 x 10	$1^{3} \times 0.06 \times 10^{3}$	$Q = \frac{\Delta T \times V \times \gamma \times C}{h \times 860}$ 20 x 0.06 x 1.80 x 10 ³ x 0.23			
$=\frac{20 \times 60 \times 1.80 \times 10}{15 \times 60 \times 10}$		$=\frac{20\times0.00\times100\times100\times0.25}{0.25\times860}$			


= 2304 W = 2.3 kW

Cooling capacity = Considering a safety factor of 20%,

2.3 x 1.2 = 2.8 kW (When the circulating fluid temperature is 20°C.)

(In this case, selected thermo-chiller model will be either HRZ002-L or HRZ004-H.)

Thermo-chiller



* This is the calculated value by changing the fluid temperature only. Thus, it varies substantially depending on the water bath or piping material or shape.

Precautions on Model Selection

1. Heating capacity

When setting the circulating fluid temperature at a higher temperature than the room temperature, the circulating fluid temperature will be heated with the thermo-chiller. Heating capacity varies depending on the model of the HRZ series. Also, the heating capacity varies depending on the circulating fluid temperature. Consider the heat radiation amount or thermal capacity of the user's equipment. Check beforehand if the required heating capacity is provided, based on the heating capacity graph for the respective model.

2. Pump capacity

<Circulating fluid flow rate>

Pump capacity varies depending on the model selected from the HRZ series. Also, circulating fluid flow varies depending on the circulating fluid discharge pressure. Consider the installation height difference between our thermo-chiller and a user's equipment, and the piping resistance such as circulating fluid pipings, or piping size, or piping curves in the machine. Check beforehand if the required flow is achieved using the pump capacity curves for each respective model.

<Circulating fluid discharge pressure>

Circulating fluid discharge pressure has the possibility to increase up to the maximum pressure in the pump capacity curves for the respective model. Check beforehand if the circulating fluid pipings or circulating fluid circuit of the user's equipment are fully durable against this pressure.



Model Selection HRZ Series

Circulating Fluid Typical Physical Property Values

* Shown below are reference values. Please contact circulating fluid supplier for details.

Fluorinated Fluids

Physical property value						
Temperature	[kg/m³] [g/L]	[J/(kg·K)]	([kcal/kg⋅°C])			
–10°C	1.87 x 10 ³	0.87 x 10 ³	(0.21)			
20°C	1.80 x 10 ³	0.96 x 10 ³	(0.23)			
50°C	1.74 x 10 ³	1.05 x 10 ³	(0.25)			
80°C	1.67 x 10 ³	1.14 x 10 ³	(0.27)			

60% Ethylene Glycol Aqueous Solution

Physical property value	Density γ	Specific heat C			
Temperature	[kg/m³] [g/L]	[J/(kg⋅K)]	([kcal/kg·°C])		
-10°C 1.10 x 10 ³		3.02 x 10 ³	(0.72)		
20°C 1.08 x 10 ³		3.15 x 10 ³	(0.75)		
50°C	1.06 x 10 ³	3.27 x 10 ³	(0.78)		
80°C	1.04 x 10 ³	3.40 x 10 ³	(0.81)		

Water

Density γ: 1 x 10³ [kg/m³] [g/L]

Specific heat C: 4.2 x 10³ [J/(kg·K)] (1.0 [kcal/kg·°C])


HEB

HED

Thermo-chiller Fluorinated Fluid Type HRZ Series

CE

How to Order



Specifications (For details, please refer to our "Product Specifications" information.)

	Model	HRZ001-L	HRZ002-L	HRZ004-L	HRZ008-L	HRZ001-H	HRZ002	H HRZ004-H	HRZ008-H	HRZ002-W	HRZ008-W
Co	oling method	Water-cooled refrigeration									
Re	frigerant		R404A (HFC)								
Re	frigerant charge kg	1.15	1.15	1.3	2	0.75	0.75	1.15	1.15	1.15	1.15
Co	ntrol system					PID c	ontrol				
An	bient temp./humidity*1				Temperature	e: 10 to 35°C	, Humidity	/: 30 to 70%RF	l		
	Circulating fluid*2	Fluorin	ert [™] FC-328	3/GALDEN®	HT135	Fluo	rinert [™] F0	C-40/GALDEN®	HT200	 -20 to 40°C: FC-3283/GA 20 to 90°C: F FC-40/GALD 	LDEN [®] HT135 Fluorinert [™]
E	Temp. range setting*1 °C		-20	to 40			_	20 to 90	_	-20	to 90
system	Cooling capacity*3 kW	1.0 (at –10°C)	2.0 (at –10°C)	4.0 (at –10°C)	8.0 (at –10°C)	1.0 (at 20°C)	2.0 (at 20°C	4.0 (at 20°C)	8.0 (at 20°C)	2.0 (at 20°C)	8.0 (at 20°C)
fluid	Heating capacity*3 kW	2.8 (at –10°C)	3.2 (at –10°C)	3.6 (at –10°C)	5.9 (at –10°C)	2.3 (at 20°C)	2.6 (at 20°C	2.8 (at 20°C)	3.0 (at 20°C)	2.3 (at 20°C)	3.3 (at 20°C)
ing	Temp. stability*4 °C					±C).1				
Circulating	Pump capacity MPa (50/60 Hz)*5	0.45/0.65 (at 20 L/min)		0.65/0.95 (at 30 L/min)	0.40/0 (at 20 L/			0.45/0.65 (at 20 L/min)			
Ū	Rated flow ^{*6} L/min	20 30			30	20					
	Main tank capacity*7 L	Approx. 15			Approx. 22	Approx	Approx. 12 Approx. 15				
	Sub-tank capacity ^{*8} L	Approx. 16 Approx. 17 Approx. 15 Approx. 16									
	Port size		Rc3/4								
	Fluid contact material		Stainle	ss steel, EPI	DM, Copper	brazing (Hea	at exchang	ger), PPS, Silic	one, Fluorore	esin	
stem	Temperature range °C					10 to :					
Cooling water system	Pressure range MPa		1		1	0.3 to				1	
wate	Required flow rate (50/60 Hz)*9 L/min	5/5	6/6	15/22	18/23	3/4	5/6	9/10	13/14	6/7	13/14
oling	Port size					Rc1/					
-	Fluid contact material					<u> </u>		anger), Silicone			
tem	Power supply			200 VAC 50				z Allowable vo	0 0		
Electrical system	Breaker capacity A		30	0.5	60	20			30		
rica	Rated current A	20 25 46 14 23									
ect	Alarm	munications Contact input/output (D-sub 25 pin) and Serial RS-485 (D-sub 9 pin) (Refer to pages 243 ar)			
	• •	10		175 E morking S	275	145 165					
	Safety standards UL, CE marking, SEMI (S2-0703, S8-0701, F47-0200), SEMATECH (S2-93, S8-95) 1. It should have no condensation), SEIVIATECH			

*1 It should have no condensation.

*2 GALDEN[®] is a registered trademark, belonging to the Solvay Group or its corresponding owner. Fluorinert™ is a trademark of 3M. Regarding the fluid other than the above, please contact SMC.

*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at rated circulating fluid flow rate. Values common for 50/60 Hz.

*4 Value with a stable load without turbulence in the operating conditions. It may be out of this range depending on operating conditions.

*5 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C.

*6 Required flow rate for cooling capacity or maintaining the temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 246). *7 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)

*8 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.


*9 Required flow rate when a load for the cooling capacity is applied at a facility water temperature of 25°C.

*10 Weight in the dry state without circulating fluids




Cooling Capacity

HRZ001-L/002-L/004-L/008-L




HRZ002-W/008-W




Heating Capacity

HRZ001-L/002-L/004-L/008-L




HRZ002-W/008-W




SMC

HRZ001-H/002-H/004-H/008-H



HRZ001-H/002-H/004-H/008-H






HRS


HRZ Series

Pump Capacity (Thermo-chiller Outlet)


HRZ001-L/002-L/004-L




HRZ001-H/002-H




HRZ008-L



HRZ004-H/008-H HRZ002-W/008-W



* When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)



Cooling Stainless steel, EPDM, Copper brazing (Heat exchanger), Silicone, Brass, NBR Fluid contact material system Power supply 3-phase 200 VAC 50 Hz, 3-phase 200 to 208 VAC 60 Hz Allowable voltage range $\pm 10\%$ Breaker capacity Α 30 60 20 30 Rated current Electrical s 19 Α 26 46 14 23 Refer to page 245. Alarm Contact input/output (D-sub 25 pin) and Serial RS-485 (D-sub 9 pin) (Refer to pages 243 and 244.) Communications Weight*10 175 275 145 165 165 kg UL, CE marking, SEMI (S2-0703, S8-0701, F47-0200), SEMATECH (S2-93, S8-95) Safety standards

*1 It should have no condensation.

*2 Dilute pure ethylene glycol with tap water. Additives such as preservatives cannot be used.

*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at rated circulating fluid flow rate. Values common for 50/60 Hz.


*4 Value with a stable load without turbulence in the operating conditions. It may be out of this range when a DI control kit (option Y) is used or in some other operating conditions. *5 The capacity at the thermo-chiller outlet when the circulating temperature is 20°C.

*6 Required flow rate for cooling capacity or maintaining the temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 246).

*7 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)

*8 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.

*9 Required flow rate when a load for the cooling capacity is applied at a facility water temperature of 25°C.





HRS

HRS090

HRS100/150

HRSH090

HRSH

HRSE

HRZ

HRZD

HRW

HECR

HEC


HEB

HED


HRZ Series

Cooling Capacity

HRZ001-L1/002-L1/004-L1/008-L1




HRZ002-W1/008-W1




Heating Capacity


HRZ001-L1/002-L1/004-L1/008-L1



HRZ002-W1/008-W1



HRZ001-H1/002-H1/004-H1/008-H1



A HRZ008-H1 HRZ004-H1 HRZ002-H1 HRZ002-H1 HRZ001-H1

50

Circulating fluid temperature [°C]

60

70

80

90

HRZ001-H1/002-H1/004-H1/008-H1



0


20

30


40

Pump Capacity (Thermo-chiller Outlet)

HRZ001-L1/002-L1/004-L1 HRZ004-H1/008-H1 HRZ002-W1/008-W1




HRZ001-H1/002-H1



* When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)

SMC






HRS

HRS090

Thermo-chiller Tap/Deionized Water Type (€ HRZ Series SEMI

How to Order



Specifications (For details, please refer to our "Product Specifications" information.)

Model		HRZ001-L2	HRZ002-L2	HRZ004-L2	HRZ008-L2	
Cooling method		Water-cooled refrigeration				
Refrigerant		R134a (HFC)				
Refrigerant charge	kg	1.1 1.1 1.1 1.1				
Control system		PID control				
Ambient temperature/humidity*	1	Temperature: 10 to 35°C, Humidity: 30 to 70%RH				
Circulating fluid*2		Tap water, Deionized water				
Temperature range setting*1	°C	10 to 40				
Cooling capacity ^{*3} Heating capacity ^{*3} Temperature stability ^{*4}	kW	1.0 (at 20°C)	4.0 (at 20°C)	8.0 (at 20°C)		
Heating capacity*3	kW	0.90 (at 20°C)	0.98 (at 20°C)	1.15 (at 20°C)	1.25 (at 20°C)	
	°C	±0.1				
Pump capacity (50/60 Hz)*5 Rated flow*6 Main tank capacity*7 Sub-tank capacity*8	MPa	0.25/0.38 (at 20 L/min)				
Rated flow ^{*6}	L/min	20				
Main tank capacity*7	L	Approx. 15				
Sub-tank capacity*8	L	Approx. 16				
Port size		Rc3/4				
Fluid contact material		Stainless steel, EPDM, Copper brazing (Heat exchanger), PPS, Silicone, Fluororesin				
Temperature range	°C	10 to 25				
Image: State of the state	MPa		0.3 to	0.7		
Bequired flow rate (50/60 Hz)*	July L/min	5/5 6/6 15/22 18				
Port size			Rc1	/2		
S Fluid contact material		Stainless steel, EPDM, Copper brazing (Heat exchanger), Silicone, Brass, NBR				
E Power supply		3-phase 200 VA	C 50 Hz, 3-phase 200 to 208	VAC 60 Hz Allowable volt	age range ±10%	
Breaker capacity	Α		30)		
Rated current	Α		19	9		
Power supply Breaker capacity Rated current Alarm Communications			Refer to p	•		
		Contact input/output	(D-sub 25 pin) and Serial RS		pages 243 and 244.	
Weight ^{*10}	kg		16	-		
Safety standards		UL, CE marki	ng, SEMI (S2-0703, S8-0701	, F47-0200), SEMATECH (S2-93, S8-95)	

I It should have no condensation.

*2 If tap water or deionized water is used, please use water that conforms to Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994/cooling water system - circulation type - make-up water). The minimum electric conductivity of the deionized water used as the fluid should be 0.5 µS/cm (or electric resistivity 2 MΩ•cm at maximum).

*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at rated circulating fluid flow rate. Values common for 50/60 Hz.

*4 Value with a stable load without turbulence in the operating conditions. It may be out of this range when a DI control kit (option Y) is used or in some other operating conditions.
 *5 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C.

*6 Required flow rate for cooling capacity or maintaining the temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 246). *7 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)

*8 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.


*9 Required flow rate when a load for the cooling capacity is applied at a facility water temperature of 25°C.

*10 Weight in the dry state without circulating fluids




Cooling Capacity

HRZ001-L2/002-L2/004-L2/008-L2



Pump Capacity (Thermo-chiller Outlet)


HRZ001-L2/002-L2/004-L2/008-L2



 When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)

Heating Capacity

HRZ001-L2/002-L2/004-L2/008-L2





HRS

HRS090

HED


Thermo-chiller Double Inverter Type

HRZ Series

SE

CE

How to Order



Specifications

Model		HRZ010-WS	HRZ010-W1S	HRZ010-W2S			
Cooling method		Water-cooled refrigeration					
Refrigerant			R404A (HFC)				
Refrigerant charge	kg	1.55	1.55	1.55			
Control system		PID control					
Ambient temperature/humidity	y *1	Temperature: 10 to 35°C, Humidity: 30 to 70%RH					
Circulating fluid*2		 –20 to 40°C: Fluorinert[™] FC-3283/GALDEN[®] HT135 20 to 90°C: Fluorinert[™] FC-40/GALDEN[®] HT200 	60% ethylene glycol aqueous solution	Tap water, Deionized water			
E Temperature range setting	^{*1} °C	–20 t	o 90	10 to 60			
Cooling capacity*3	kW	10 (at 20°C)	10 (at 20°C)	9 (at 20°C)			
Heating capacity*3	kW	5.0 4.5 (at 20°C) (at 20°C)		2.5 (at 20°C)			
Temperature stability*4	°C	±0.1 (In cases when the circulating fluid discharge port and the return port are directly connected					
Pump capacity*5	MPa	Max. 0.72 (at 20 L/min)	Max. 0.40 (at 20 L/min)	Max. 0.38 (at 20 L/min)			
Pump capacity ^{*6} Rated flow ^{*6} Flow range ^{*7}	L/min		20				
	L/min	10 to 40 (With flow control function by inverter)					
Main tank capacity*8	L	Approx. 15					
Sub-tank capacity ^{*9}	L	Approx. 16					
Port size		Rc3/4					
Fluid contact material		Stainless steel, EPDM, Copper brazing (Heat exchanger), PPS, Silicone, Fluororesin					
Temperature range	°C	10 to	10 to 25				
Temperature range Pressure range Required flow rate (50/60 Hz) Port size Fluid contact material	MPa		0.3 to 0.7				
Required flow rate (50/60 Hz)	* ¹⁰ L/min		15/15				
Port size		Rc1/2					
		Stainless steel, EPDM, C	Copper brazing (Heat exchanger), PI	PS, Silicone, Brass, NBR			
Power supply		3-phase 200 VAC 50 Hz, 3	3-phase 200 to 208 VAC 60 Hz Allo	wable voltage range $\pm 10\%$			
Power supply Breaker capacity Rated current Alarm Communications	Α		30				
Rated current	Α	26	25	25			
Alarm			Refer to page 245.				
		Contact input/output (D-sub 25 p	oin) and Serial RS-485 (D-sub 25 pir	n) (Refer to pages 243 and 244.)			
Weight*11	kg		165				
Safety standards		UL, CE marking, SEMI	(S2-0703, S8-0701, F47-0200), SEN	1ATECH (S2-93, S8-95)			
It should have no condensation.				· · · ·			

*1 It should have no condensation.

*2 GALDEN[®] is a registered trademark, belonging to the Solvay Group or its corresponding owner. Fluorinert[™] is a trademark of 3M. Dilute pure ethylene glycol with tap water. Additives such as preservatives cannot be used. If tap water or deionized water is used, please use water that conforms to Water Quality Standards of the Japan Refrigeration and Air Conditioning Industry Association (JRA GL-02-1994/cooling water system - circulation type - make-up water). The minimum electric conductivity of the deionized water used as the fluid should be 0.5 µS/cm (or electric resistivity 2 MΩ•cm at maximum).

*3 ① Facility water temperature: 25°C, ② Circulating fluid flow rate: Values at rated circulating fluid flow rate. Values common for 50/60 Hz.

*4 Value with a stable load without turbulence in the operating conditions. It may be out of this range when a DI control kit (option Y) is used or in some other operating conditions. *5 The capacity at the thermo-chiller outlet when the circulating fluid temperature is 20°C.

*6 Required flow rate for cooling capacity or maintaining the temperature stability. When used below the rated flow, use the individually sold, "Bypass Piping Set" (Refer to page 246). *7 May not be able to control with the set value depending on the piping specification in the user side.

*8 Minimum volume required for operating only the thermo-chiller. (Circulating fluid temperature: 20°C, including the thermo-chiller's internal pipings or heat exchanger)


*9 Preliminary space volume without main tank capacity. Available for collecting the circulating fluid inside an external piping or for preliminary injection.

*10 Required flow rate when a load for the cooling capacity is applied at a facility water temperature of 25°C.

*11 Weight in the dry state without circulating fluids




Cooling Capacity




Heating Capacity

HRZ010-WS/010-W1S/010-W2S



Pump Capacity (Thermo-chiller Outlet)


HRZ010-WS




The pump capacity of the HRZ010-W1S is same as that of the HRZ001-L1 group on page 236.

The pump capacity of the HRZ010-W2S is same as on page 238.


HRZ010-W2S





* When pump inverter is operating at frequency of 60 Hz (maximum).

HRZ010-W1S



 When the circulating fluid flow is below 6 L/min, the in-built operation stop alarm will be activated. It is not possible to run the equipment. (common for all models)
 With flow control function by inverter HRSH090

HRSH

НЕСВ






НЕD

Technical Data

240

HRZ Series Common Specifications


Dimensions



						[mm]
	Model		Α	в	с	D
Fluorinated fluid type	Ethylene glycol type	Tap/Deionized water type	A	В	C	
HRZ001-H HRZ002-H	HRZ001-H1 HRZ002-H1	_	380	870	860	ø18.5 to 20.5
HRZ001-L HRZ002-L, W HRZ004-L, H HRZ008-H, W HRZ010-WS	HRZ001-L1 HRZ002-L1, W1 HRZ004-L1, H1 HRZ008-H1, W1 HRZ010-W1S	HRZ001-L2 HRZ002-L2 HRZ004-L2 HRZ008-L2 HRZ010-W2S	380	870	950	ø18.5 to 20.5

(Dimensional tolerance of A, B, and C: ± 10 mm)

Common Specifications *HRZ Series*



					[mm]
1	Model	•	Б	С	P
Fluorinated fluid type	Ethylene glycol type	A	B	C	D
HRZ008-L	HRZ008-L1	415	1080	1075	ø35.0 to 38.0

(Dimensional tolerance of A, B, and C: ±10 mm)

SMC

HED

HRZ Series

Communication Functions (For details, please refer to our "Communication Specifications" information.)

Contact	Input/Output	

n or no. his product's side) off size ulation method ted input voltage erating voltage range ted input current ut impedance ulation method ted load voltage erating load voltage range ximum load current ted load voltage ximum load current ted load voltage ximum load current ted load voltage ximum load current		D-	er to page 244 -sub 25 P typ M2 Pho 2 21.6 VD 5 I 4 Pho 2 21.6 VD 2 21.6 VD 4 8 VAC or le 500 mA AC/D 48 VAC or le 500 mA AC/D 48 VAC or le	4 for be, F 2.6 x 2.6 x 2.6 x 2.6 x 2.6 x 2.6 x 2.6 x 0.0 to 0.0 to	26.4 VDC TYP Ω upler DC 26.4 VDC A or less		
nis product's side) lt size ulation method ted input voltage erating voltage range ted input current ut impedance ulation method ted load voltage erating load voltage range ximum load current ted load voltage stating rotection ted load voltage ximum load current ted load voltage		D-	-sub 25 P typ M2 Pho 2 21.6 VD 5 r 4 Pho 2 21.6 VD 2 21.6 VD 2 21.6 VD 48 VAC or le 500 mA AC/D 48 VAC or le 500 mA AC/D 48 VAC or le	2.6 x 2.6 x 24 VE 24 VE 20 to mA 1 4.7 ks btocoo 24 VE 20 to 80 m mA c Diod 90 C (R 00 c 90 C (R 900 c 900 c	emale connector 0.45 upler DC 26.4 VDC TYP Ω upler DC 26.4 VDC 26.4 VDC 26.4 VDC a 4 VDC or less lesistance load) 4 VDC or less ce load/Inductive		
It size ulation method ted input voltage erating voltage range ted input current ut impedance ulation method ted load voltage erating load voltage range ximum load current takage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	M2 Pho 2 21.6 VD 5 r 4 Pho 2 21.6 VD 2 21.6 VD 8 0.1 r 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	2.6 x btocco 24 VE 0C to mA 1 4.7 ks 24 VE 0C to 24 VE 0C to 80 m mA c Diod 9ss/2 0C (R esss/2 istan	0.45 upler 26.4 VDC TYP Ω upler DC 26.4 VDC 26.4 VDC A or less le 4 VDC or less tesistance load) 4 VDC or less ce load/Inductive		
ulation method ted input voltage erating voltage range ted input current ut impedance ulation method ted load voltage erating load voltage range ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	Pho 2 21.6 VD 5 r 4 Pho 2 21.6 VD 8 0.1 r 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	24 VE DC to mA 1 4.7 ks btoco 24 VE DC to 80 m mA c Diod ess/2 C (R ess/2 istan	upler DC 26.4 VDC TYP Ω upler DC 26.4 VDC A or less le 4 VDC or less lesistance load) 4 VDC or less ce load/Inductive	load)	
ted input voltage erating voltage range ted input current ut impedance ulation method ted load voltage erating load voltage range ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	21.6 VD 5 1 4 Pho 2 21.6 VD 8 0.1 r 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	24 VE OC to mA 1 4.7 ks btocco 24 VE OC to 80 m mA c Diod ess/2 C (R ess/2 istan	26.4 VDC 26.4 VDC TYP Ω upler DC 26.4 VDC A or less le 4 VDC or less lesistance load) 4 VDC or less ce load/Inductive	load)	
erating voltage range ted input current ut impedance ulation method ted load voltage erating load voltage range ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	21.6 VD 5 r 4 Pho 2 21.6 VD 3 0.1 r 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	DC to mA 1 4.7 ks btocco 24 VE DC to 0C to 0C to 0C to 0Diod 0Diod 0C (R ess/2 istan	26.4 VDC TYP Ω upler DC 26.4 VDC A or less le 4 VDC or less esistance load) 4 VDC or less ce load/Inductive	load)	
ted input current ut impedance ulation method ted load voltage erating load voltage range ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	5 I 4 Pho 2 21.6 VD 3 0.1 r 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	mA 1 4.7 kg btocco 24 VE 0C to 0C to 80 m mA c Diod ess/2 C (R ess/2 istan	TYP Ω upler DC 26.4 VDC A A or less le 4 VDC or less resistance load) 4 VDC or less ce load/Inductive	load)	
ut impedance ulation method ed load voltage erating load voltage range ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	4 Pho 2 21.6 VD 4 0.1 r 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	4.7 kg otoco 24 VE 0C to 80 m MA c Diod ess/2 0C (R ess/2 istan	Ω upler DC 26.4 VDC A A or less le 4 VDC or less resistance load) 4 VDC or less ce load/Inductive	load)	
ulation method ted load voltage erating load voltage range ximum load current takage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	Pho 2 21.6 VD 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	otoco 24 VE 26 to 80 m mA c Diod 255/2 20C (R 255/2 istan	upler DC 26.4 VDC A r less le 4 VDC or less resistance load) 4 VDC or less ce load/Inductive	load)	
ted load voltage erating load voltage range ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	2 21.6 VD 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	24 VE 9C to 80 m Diod Diod 9SS/2 9C (R 9SS/2 istan	DC 26.4 VDC A or less le 4 VDC or less resistance load) 4 VDC or less ce load/Inductive	load)	
erating load voltage range ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	21.6 VD 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	DC to 80 m mA c Diod ess/2 DC (R ess/2 istan	26.4 VDC A or less le 4 VDC or less lesistance load) 4 VDC or less ce load/Inductive	load)	
ximum load current akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	80 m mA c Diod ess/2 PC (R ess/2 istan	A or less le 4 VDC or less lesistance load) 4 VDC or less ce load/Inductive	load)	
akage current rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	0.1 r 48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	mA c Diod ess/2 PC (R ess/2 istan	or less le 4 VDC or less esistance load) 4 VDC or less ce load/Inductive	load)	
rge protection ted load voltage ximum load current ted load voltage		5 800 mA To th	48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	Diod ess/2 eC (R ess/2 istan	e 4 VDC or less esistance load) 4 VDC or less ce load/Inductive	load)	
ed load voltage ximum load current ed load voltage		5 800 mA To th	48 VAC or le 500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	ess/2 PC (R ess/2 istan	4 VDC or less lesistance load) 4 VDC or less ce load/Inductive	load)	
ximum load current red load voltage		5 800 mA To th	500 mA AC/D 48 VAC or le AC/DC (Resi he thermo-chille	PC (R ess/2 istan	esistance load) 4 VDC or less ce load/Inductive	load)	
ed load voltage		800 mA . To th	48 VAC or le AC/DC (Resi	ess/2 istan	4 VDC or less ce load/Inductive	load)	
•		800 mA . To th	AC/DC (Resi	istan	ce load/Inductive	load)	
		To th	he thermo-chille				
agram	Interna				24 COM output (Ou 24 VDC input (Supply 24 COM input (Supply Setting at the time of shipment from factory Run/Stop signal 	Run/Stop signal 1 Run/Stop signal 2 DIO REMOTE signal 1 DIO REMOTE signal 2 Output signal 1 Output signal 2 Output signal 3 Output signal 4 Output signal 5 Alarm signal	o-chiller) nt or thermo-chiller)*1
aç	gram	Interna	gram	gram	gram	gram	gram

*1 When using the power supply of the thermo-chiller, short circuit pins 1 and 2 and pins 14 and 15 respectively. When using the power supply of the user's equipment, connect the lead wires to pins 2 and 15 and 5bort circuit

When using the power supply of the user's equipment, connect the lead wires to pins 2 and 15 and short circuit pins 14 and 15. Incorrect connections may cause a malfunction.

^{*2} The custom function is equipped for contact input/output. Using the custom function enables the user to set the signal type for contact input/output or pin assignment numbers. For details, please refer to the "Communication Specifications" information.

Common Specifications *HRZ Series*

HRS

HRS090

HRS100/150

HRSH090

HRSH

HRSE

HRZ

HRZD

HRW

HECR

HEC

HEB

HED

Technical Data

Serial RS-485


The serial RS-485 enables the following items to be written and read out. <Writing> Run/Stop Circulating fluid temperature setting Circulating fluid automatic recovery start/ stop*1 <Readout> Circulating fluid present temperature Circulating fluid present temperature Circulating fluid flow Circulating fluid discharge pressure Circulating fluid discharge pressure Circulating fluid electric resistivity*² Alarm occurrence information

Item Specifications Connector no. P2 Connector type (on this product's side) D-sub 9 P type, Female connector Fixing bolt size M2.6 x 0.45 Standards EIA RS485 Protocol Modicon Modbus To the thermo-chiller User's equipment side $\langle \Gamma$ 2 -0 Circuit diagram SD+ -7 SD-Internal circuit -5 -0 SG

*1 Only when the circulating fluid automatic recovery function (option Z) is selected.
*2 Only when the DI control kit (option Y) is selected.

Status (operating condition) information


Connector Location



∕∂ SMC

HRZ Series

Operation Display Panel



Alarm


This unit can display 28 kinds of alarm messages as standard. Also, it can read out the serial RS-485 communication.

Alarm code	Alarm message	Operation status	Main reason
01	Water Leak Detect FLT	Stop	Liquid deposits in the base of this unit.
02	Incorrect Phase Error FLT	Stop	The power supply to this unit is incorrect.
03	RFGT High Press FLT	Stop	Pressure in the refrigeration circuit has exceeded the limitation.
04	CPRSR Overheat FLT	Stop	Temperature inside the compressor has increased.
05	Reservoir Low Level FLT	Stop	The amount of circulating fluid is running low.
06	Reservoir Low Level WRN	Continue	The amount of circulating fluid is running low.
07	Reservoir High Level WRN	Continue	Filling the circulating fluid too much.
08	Temp. Fuse Cutout FLT	Stop	Temperature of the circulating fluid tank is raised.
09	Reservoir High Temp. FLT	Stop	Temperature of the circulating fluid has exceeded the limitation.
11	Reservoir High Temp. WRN	Continue	Temperature of the circulating fluid has exceeded the limitation set by user.
12	Return Low Flow FLT	Stop	The circulating fluid flow has gone below 6 L/min.
13	Return Low Flow WRN	Continue	The circulating fluid flow has gone below the limitation set by user.
14	Heater Breaker Trip FLT	Stop	Protection device for the electric circuit of the heater is activated.
15	Pump Breaker Trip FLT	Stop	Protection device for the electric circuit of the circulating pump is activated.
16	CPRSR Breaker Trip FLT	Stop	Protection device for the electric circuit of the compressor is activated.
17	Interlock Fuse Cutout FLT	Stop	Overcurrent is flown to the control circuit.
18	DC Power Fuse Cutout WRN	Continue	Overcurrent has flowed to the (optional) solenoid valve.
19	FAN Motor Stop WRN	Continue	Cooling fan inside the compressor has stopped.
20	Internal Pump Time Out WRN	Continue	The internal pump continuously run for more than a certain period of time.
21	Controller Error FLT	Stop	The error occurred in the control systems.
22	Memory Data Error FLT	Stop	The data stored in the controller of this unit went wrong.
23	Communication Error WRN	Continue	The serial communications between this unit and user's system has been suspended.
24	DI Low Level WRN	Continue	DI level of the circulating fluid has gone below the limitation set by user. (Option)
25	Pump Inverter Error FLT	Stop	An error has occurred in the inverter for the circulating pump. The alarm is only for the HRZ010-W \Box S.
26	DNET Comm. Error WRN	Continue	The DeviceNet communications between this unit and user's system has been suspended. (Only for DeviceNet communication specification - option D)
27	DNET Comm. Error FLT	Stop	An error has occurred in the DeviceNet communication system of this unit. (Only for DeviceNet communication specification - option D)
28	CPRSR INV Error FLT	Stop	An error has occurred in the inverter for the compressor. The alarm is only for the HRZ010-W \square S.

HRZ Series **Optional Accessories**

1 Bypass Piping Set


When the circulating fluid goes below the rated flow, cooling capacity will be reduced and the temperature stability will be badly affected. In such a case, use the bypass piping set.



* Necessary to be fitted by user.


Applicable model

Part no.



HRZ Series

3 4-Port Manifold




4 DI Filter

This is the ion replacement resin to maintain the electric resistivity of the circulating fluid.

Users who selected the DI control kit (option Y) need to purchase the DI filter separately.

Part no.	Applicable model				
HRZ-DF001	Common for all models which can select the DI control kit. (option Y)				

 The DI filters are consumable. Depending on the status (electric resistivity set value, circulating fluid temperature, piping volume, etc.), product life cycles will vary accordingly.




Weight: Approx. 20 kg

5 Insulating Material for DI Filter

When the DI filter is used at a high-temperature, we recommend that you use this insulating material to protect the radiated heat from the DI filter or possible burns. When the DI filter is used at a low-temperature, we also recommend that you use this to prevent heat absorption from the DI filter and to avoid forming condensation.


Part no.	Applicable model
HRZ-DF002	Common for all models which can select the DI control kit. (option Y)



(6) 60% Ethylene Glycol Aqueous Solution

This solution can be used as a circulating fluid for ethylene glycol-type thermo-chillers. (Capacity: 10 L)

Part no.	Applicable model
HRZ-BR001	Common for all ethylene glycol-type models



⑦ Concentration Meter

This meter can be used to control the condensation of ethylene glycol solution regularly.

Part no.	Applicable model	
HRZ-BR002	Common for all ethylene glycol-type models	

ſ

HRS

HRSH

HRSE

HRZ

HRZD


НВШ

HECR

НЕС

HEB

HED







* Options have to be selected when ordering the thermo-chiller. It is not possible to add them after purchasing the unit.

Option symbol

Analog Communication



Analog communication

In addition to the standard contact input/output signal communication and the serial RS-485 communication, analog communication function can be added.


The analog communication function enables to write and read out the following items.

<Writina> Circulating fluid temperature setting <Readout> Circulating fluid present temperature Electric resistivity*1

*1 Only when the DI control kit (option Y) is selected.

Scaling voltage - circulating fluid temperature can be set arbitrarily by user.

For details, please refer to our "Communication Specifications" information.



DI control kit


Select this option if you want to maintain the electric resistance ratio (DI level) of the circulating fluid at a certain level. However, some components have to be fitted by user. For details, refer to specification table for this option.

Please note that this is not applicable to the fluorinated liquid type.


Applicable model		HRZ00□-L1-Y HRZ00□-H1-Y HRZ00□-W1-Y HRZ010-W1S-Y	HRZ00⊡-L2-Y HRZ010-W2S-Y
Allowable circulating fluid	—	60% ethylene glycol aqueous solution	Deionized water
DI level display range	MΩ⋅cm	0 to 20	
DI level set range	tet range MΩ⋅cm 0 to 2.0*1		
DI level reduction alarm set range	MΩ⋅cm	0 to 2.0	

The DI filter is needed to control the DI level. (SMC Part No.: HRZ-DF001)

Please purchase additionally because the DI filter is not included in this option. Also, if necessary, additionally purchase the insulating material for the DI filter. (SMC Part No.: HRZ-DF002)



- * Install the DI filter outside the thermo-chiller for piping. Secure the space for installing the DI filter on the rear side of the thermo-chiller.
- It may go outside of the temperature stability range of ±0.1°C when this option is used in some operating conditions.



SMC



DeviceNet Communication


<Writing> Run/Stop Circulating fluid temperature setting Circulating fluid automatic recovery start/stop*1

Option symbol

<Readout> Circulating fluid present temperature Circulating fluid flow Circulating fluid discharge pressure Electric resistivity*2 Alarm occurrence information Status (operating condition) information

*1 Only when the circulating fluid automatic recovery function (option Z) is selected. *2 Only when the DI control kit (option Y) is selected.

For details, please refer to our "Communication Specifications" information.



The circulating fluid temperature and pressure are displayed in SI units [MPa/°C] only. If this option is not selected, a product with a unit selection function will be provided by

No change in external dimensions

HRS

HRS090

HRS100/150

HRSH090

HRSH

HRSE

HRZ

HRZD

HRW

HECR

HEC

HEB

HED

Technical Data

Z Option symbol

Circulating Fluid Automatic Recovery

HRZ – – – Z Circulating fluid automatic recovery

Select this option for users who want to use the circulating fluid automatic recovery function.

The automatic recovery function is a device which can recover the circulating fluid inside pipings into a sub-tank of the thermo-chiller by the external communication or operating display panel. Some components need to be fitted by user. For details, please refer to the "Product Specifications" information for these options.


Applicable model		HRZ001-H-Z HRZ001-H1-Z HRZ002-H-Z HRZ002-H1-Z	HRZ001-L-Z HRZ002-L-Z HRZ004-L-Z HRZ008-H-Z HRZ008-H-Z HRZ004-L2-Z HRZ002-W-Z HRZ002-W-Z HRZ008-W-Z HRZ010-WS-Z HRZ010-W2S-Z	HRZ001-L1-Z HRZ002-L1-Z HRZ004-L1-Z HRZ004-H1-Z HRZ008-H1-Z HRZ002-L2-Z HRZ008-L2-Z HRZ002-W1-Z HRZ008-W1-Z HRZ010-W1S-Z	HRZ008-L-Z HRZ008-L1-Z
Circulating fluid recoverable volume*1	L	15	16 17		17
Purge gas	—	Nitrogen gas			
Purge gas supply port	—	Self-align fitting for O.D. ø8*2			
Purge gas supply pressure	MPa	0.4 to 0.7			
Purge gas filtration	μm	0.01 or less			
Regulator set pressure	MPa	0.15 to 0.3*3			
Recoverable circulating fluid temperature	°C	10 to 30			
Recovery start/stop	—	Start: External communication*4 or operation display panel/Stop: Automatic			
Timeout error	sec	Timer from recovery start to completion Stops recovering when the timer turns to set time. Possible set range: 60 to 300, at the time of shipping from the factory: 300			time.
Height difference with the user system side	m	10 or less			

*1 This is the space volume of the sub-tank when the liquid level of the circulating fluid is within the specification. Guideline of the recovery volume is 80% of the circulating fluid recoverable volume.

*2 Before piping, clean inside the pipings with air blow, etc. Use the piping with no dust generation by purge gas. When using resin tube, where necessary, use insert fittings, etc. in order not to deform the tubings when connecting to self-align fittings.

*3 At the time of shipping from factory, it is set to 0.2 MPa.

*4 For details, please refer to our "Communication Specifications" information.







HRZ Series Specific Product Precautions 1

Be sure to read this before handling the products. Refer to page 383 for safety instructions and pages 384 to 387 for temperature control equipment precautions.

Design

Warning

1. This catalog shows the specifications of a single unit.

- 1. For details, please refer to our "Product Specifications" and thoroughly consider the adaptability between the user's system and this unit.
- Although the protection circuit as a single unit is installed, the user is requested to carry out the safety design for the whole system.

Selection

▲Caution

1. Model selection

In order to select the correct thermo-chiller model, the amount of thermal generation from the user's system, the operating circulating fluid, and its circulating flow are required. Select a model, by referring to the guideline to model selection on page 227.

2. Option selection

Options have to be selected when ordering the thermo-chiller. It is not possible to add them after purchasing the unit.

Handling

Warning

1. Thoroughly read the Operation Manual.

Read the Operation Manual completely before operation, and keep this manual available whenever necessary.

Operating Environment/Storage Environment

A Caution

1. Do not use in the following environment because it will lead to a breakdown.

- 1. Environment like written in "Temperature Control Equipment Precautions."
- 2. Locations where spatter will adhere to when welding.
- 3. Locations where it is likely that the leakage of flammable gas may occur.
- 4. Locations where the ambient temperature exceeds the limits as mentioned below.
 - During operation 10°C to 35°C

During storage 0° C to 50° C (but as long as water or circulating fluid are not left inside the pipings)

- 5. Locations where the ambient relative humidity exceeds the limit as mentioned below.
 - During operation 30% to 70%
 - During storage 15% to 85%
- (Inside the operation facilities) locations where there is not sufficient space for maintenance.
- 7. In locations where the ambient pressure exceeds the atmospheric pressure.
- 2. The Thermo-chiller does not have clean room specification. It generates dust from the pump inside the unit and the cooling fan for the unit inside.

Circulating Fluid

ACaution

 Avoid oil or other foreign matter entering the circulating fluid.
 251

Circulating Fluid

- 2. Use ethylene glycol that does not contain additives such as preservatives.
- 3. The condensation of ethylene glycol aqueous solution must be 60% or less. If the density is too high, the pump will be overloaded, resulting in occurrence of "Pump Breaker Trip FLT." Also, if the density is to low, the unit will freeze at lower temperatures, resulting in product failure.
- 4. Avoid water moisture entering the fluorinated fluid. Otherwise, the unit will freeze, resulting in product failure.
- 5. Use tap water (including for diluting ethylene glycol aqueous solution) which must meet the water quality standards as mentioned below.

Tap Water (as Circulating Water) Quality Standards

The Japan Refrigeration and Air Conditioning Industry Association

JRA GL-02-1994 "Cooling water system – Circulating type – Supply water"					
				Influence	
	Item	Item Unit Standard value		Corrosion	Scale generation
	pH (at 25°C)	—	6.0 to 8.0	0	0
	Electric conductivity (25°C)	[µS/cm]	100*1 to 300*1	0	0
tem	Chloride ion (Cl⁻)	[mg/L]	50 or less	0	
Standard item	Sulfuric acid ion (SO42-)	[mg/L]	50 or less	0	
nda	Acid consumption amount (at pH4.8)	[mg/L]	50 or less		0
Sta	Total hardness	[mg/L]	70 or less		0
	Calcium hardness (CaCO ₃)	[mg/L]	50 or less		0
	Ionic state silica (SiO ₂)	[mg/L]	30 or less		0
_	Iron (Fe)	[mg/L]	0.3 or less	0	0
iten	Copper (Cu)	[mg/L]	0.1 or less	0	
e e	Sulfide ion (S2-)	[mg/L]	Should not be detected.	0	
Reference item	Ammonium ion (NH ₄ +)	[mg/L]	0.1 or less	0	
lefe	Residual chlorine (Cl)	[mg/L]	0.3 or less	0	
	Free carbon (CO ₂)	[mg/L]	4.0 or less	0	

*1 In the case of [M Ω ·cm], it will be 0.003 to 0.01.

 \bullet \bigcirc : Factors that have an effect on corrosion or scale generation.

 Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.



HRZ Series Specific Product Precautions 2

Be sure to read this before handling the products. Refer to page 383 for safety instructions and pages 384 to 387 for temperature control equipment precautions.

Facility Water Supply

Warning

<Water-cooled refrigeration>

1. The water-cooled refrigeration type thermo-chiller radiates heat to the facility water.

Prepare the facility water system that satisfies the facility water specifications below.

2. When using tap water as facility water, use tap water that conforms to the appropriate water quality standards. Use tap water that conforms to the standards shown below.

<Tap Water (as Facility Water) Quality Standards>

The Japan Refrigeration and Air Conditioning Industry Association JRA GL-02-1994 "Cooling water system - Circulation type - Circulating water"

JRA GL-02-1994 "Cooling water system – Circulation type – Circulating water					
				Influence	
	Item Unit Standard v		Standard value	Corrosion	Scale generation
	pH (at 25°C)	—	6.5 to 8.2	0	0
_	Electric conductivity (25°C)	[µS/cm]	100*1 to 800*1	0	0
item	Chloride ion (CI-)	[mg/L]	200 or less	0	
	Sulfuric acid ion (SO42-)	[mg/L]	200 or less	0	
Standard	Acid consumption amount (at pH4.8)	[mg/L]	100 or less		0
star	Total hardness	[mg/L]	200 or less		0
0	Calcium hardness (CaCO ₃)	[mg/L]	150 or less		0
	Ionic state silica (SiO ₂)	[mg/L]	50 or less		0
۶	Iron (Fe)	[mg/L]	1.0 or less	0	0
item	Copper (Cu)	[mg/L]	0.3 or less	0	
e e	Sulfide ion (S2-)	[mg/L]	Should not be detected.	0	
Len	Ammonium ion (NH ₄ +)	[mg/L]	1.0 or less	0	
Reference	Residual chlorine (CI)	[mg/L]	0.3 or less	0	
L TT	Free carbon (CO ₂)	[mg/L]	4.0 or less	0	

*1 In the case of [M Ω cm], it will be 0.001 to 0.01.

O: Factors that have an effect on corrosion or scale generation.

• Even if the water quality standards are met, complete prevention of corrosion is not guaranteed.

3. Set the supply pressure between 0.3 to 0.7 MPa. Ensure a pressure difference at the facility water inlet/outlet of 0.3 MPa or more.

If the supply pressure is high, it will cause water leakage. If the supply pressure and pressure difference at the facility water inlet/outlet is low, it will cause an insufficient flow rate of the facility water, and poor temperature control.

Transportation/Carriage/Movement


\land Warning

1. Transporting with forklift

- 1. It is not possible to hang this product.
- The fork insertion position is either on the left side face or right side face of the unit. Be careful not to bump the fork against a caster or level foot and be sure to put through the fork to the opposite side.
- 3. Be careful not to bump the fork to the cover panel or piping ports.

2. Transporting with casters

- 1. This product is heavy and should be moved by at least two people.
- Do not grip the pipings on the rear side or the handles of the panel.



Mounting/Installation

ACaution

- 1. Avoid using this product outdoors.
- 2. Install on a rigid floor which can withstand this product's weight.
- 3. Install a suitable anchor bolt for the anti-quake bracket taking into consideration the user's floor material.
- 4. Avoid placing heavy objects on this product.

Piping

A Caution

- Regarding the circulating fluid pipings, consider carefully the suitability for shutoff pressure, temperature and circulating fluid. If the operating performance specifications are regularly exceeded, the pipings may burst during operation.
- 2. The surface of the circulating fluid pipings should be covered with the insulating materials which can effectively confine the heat. Absorbing the heat from the surface of pipings may reduce the cooling capacity

Absorbing the heat from the surface of pipings may reduce the cooling capacity performance and the heating capacity may be shortened due to heat radiation.

3. When using fluorinated liquid as the circulating fluid, do not use pipe tape.

Liquid leakage may occur around the pipe tape. For sealant, we recommend that you use the following sealant: SMC Part No., HRZ-S0003 (Silicone sealant)

- 4. For the circulating fluid pipings, use clean pipings which have no dust, oil or water moisture inside the pipings, and blow with air prior to undertaking any piping works. If any dust, oil or water moisture enters the circulating fluid circuit, inferior cooling performance or equipment failure due to frozen water may occur, resulting in bubbles in the circulating fluid inside the tank.
- 5. The reciprocating total volume of the circulating fluid pipings must be less than the volume of the sub-tank. Otherwise, when the equipment is stopped, the in-built alarm may activate or the circulating fluid may leak from the tank. Refer to the specifications table for the sub-tank volume.
- 6. Select the circulating fluid pipings which can exceed the required rated flow. For the rated flow, refer to the pump capacity table.

7. For the circulating fluid piping connection, install a

drain pan just in case the circulating fluid may leak.8. Do not return the circulating fluid to the unit by installing a pump in the user system.


Electrical Wiring

A Caution

SMC

- 1. Power supply and signal cable should be prepared by user.
- 2. Provide a stable power supply which is not affected by surge or distortion.

If the voltage increase ratio (dV/dt) at the zero cross should exceed 40 V/200 µsec., it may result in malfunction.



Technical HED HEB

HECR

HEC

HRS

HRS090

HRS100/150

all a eak. t by



HRZ Series **Specific Product Precautions 3**

Be sure to read this before handling the products. Refer to page 383 for safety instructions and pages 384 to 387 for temperature control equipment precautions.

Electrical Wiring

A Caution


3. This product is installed with a breaker with the following operating characteristics.

For the user's equipment (inlet side), use a breaker whose operating time is equal to or longer than the breaker of this product. If a breaker with shorter operating time is connected, the user's equipment could be cut off due to the inrush current of the motor of this product.


Breaker Operating Characteristics

Applicable model

HRZ001-L HRZ001-H HRZ002-L HRZ002-H HRZ004-L HRZ004-H HRZ001-L1 HRZ008-H HRZ002-L1 HRZ001-H1 HRZ004-L1 HRZ002-H1 HRZ001-L2 HRZ004-H1 HRZ002-L2 HRZ008-H1 HRZ004-L2 HRZ002-W HRZ008-L2 HRZ008-W HRZ002-W1 HRZ008-W1



HRZ008-L HRZ008-L1 **HRZ010-WS** HRZ010-W1S HRZ010-W2S



Operation

ACaution

1. Confirmation before operation

- 1. The circulating fluid should be within the specified range of "HIGH" and "LOW."
- 2. Be sure to tighten the cap for the circulating fluid port until the click sound is heard.

2. Emergency stop method

In the case of an emergency, press down the EMO switch which is fitted on the front face of this product.

Operation Restart Time/Operation and Suspension Frequency

▲ Caution

- 1. Wait five minutes or more before restarting operation after it has been stopped. If the operation is restarted within five minutes, the protection circuit may activate and the operation may not start properly.
- 2. Operation and suspension frequency should not exceed 10 times per day. Frequently switching between operation and suspension may result in the malfunction of the refrigeration circuit.

Maintenance

\land Warning

- 1. Do not operate the switch with wet hands or touch electrical parts such as an electrical plug. This will lead to an electrical shock.
- 2. Do not splash water directly on this product for cleaning. This will lead to an electrical shock or a fire.
- 3. When the panel was removed for the purpose of inspection or cleaning, mount the panel after works were done.

If the panel is still open, or running the equipment with the panel removed, it may cause an injury or electric shock.

A Caution

- 1. In order to prevent a sudden product failure of the unit, replace the replacement parts every 36 months.
- 2. Perform an inspection of the circulating fluid every 3 months.
 - 1. In the case of fluorinated fluids:
 - Discharge the circulating liquid and avoid any dirty objects, or water moisture, or foreign matter entering the system.
 - 2. In the case of ethylene glycol aqueous solution: Maintain the condensation at 60%.
 - 3. In the case of tap water, deionized water: Replacement is recommended.
- 3. Check the water guality of cooling water every 3 months. Regarding the water quality standards for cooling water, refer to "Temperature Control Equipment Precautions."

Refrigerant with GWP reference

Global warming potential (GWP)			
Regulation (EU) No 517/2014 (Based on the IPCC AR4)	Revised Fluorocarbons Recovery and Destruction Law (Japanese law)		
1,430	1,430		
3,922	3,920		
1,774	1,770		
2,088	2,090		
	Regulation (EU) No 517/2014 (Based on the IPCC AR4) 1,430 3,922 1,774		

* This product is hermetically sealed and contains fluorinated greenhouse gases (HFC). When this product is sold on the market in the EU after January 1, 2017, it needs to be compliant with the quota system of the F-Gas Regulation in the EU.

