4 Port Solenoid Valve Common Specifications

Series SJ2000/3000

Manifold Specifications

| | | D-sub connector | | Flat ribbon cable | | Serial | wiring | Individual wiring | | | |
|---|---------------------------|-----------------|--|---|---|--|----------------------|-----------------------|-------------|--|--|
| | Model | | Type 60F | Type 60P | Type 60PG Type 60J Type 60G | Type 60PH | Type 60S□ (EX180) | Type 60S6B (EX510) | Type 60 | | |
| Manifold | type | | | | Plug-in, Cor | nnector type | | | Non-plug-in | | |
| 1(P: SUP |), 3/5(E: EX | (H) | | | C | ommon SUP, EX | Н | | | | |
| Valve stations | | 2 to 24 | 2 to 24 stations 2 to 24 stations (Type PG) 2 to 16 stations (Type J, Type G) 2 to 8 stations | | 2 to 32 stations | 2 to 16 stations | 2 to 20 stations | | | | |
| Applicable connector | | or | D-sub connector Conforming to MIL-C-24308 JIS-X-5101 | Flat ribbon cable connector Socket: 26 pins MIL type with strain relief Conforming to MIL-C-83503 | Flat ribbon cable connector Socket: 20 pins MIL type with strain relief Conforming to MIL-C-83503 | Flat ribbon cable connector Socket: 10 pins MIL type with strain relief Conforming to MIL- C-83503 | _ | | | | |
| Internal v | viring | | Non-polar, +COM | | | | | | | | |
| 4(A), 2(B) | port | Location | Valve | | | | | | | | |
| piping sp | ec. | Direction | | Horizontal, Upward, Downward (Using elbow fittings for upward or downward) | | | | | | | |
| | 1(P), 3/5(I | E) port | C6, C8, N7, N9 (Inch size elbow fitting is not available.) | | | | | | | | |
| Port size | Port size 4(A), 2(B) port | | | | C | C2, C4, N1, N3, M | 3 | | | | |
| | | | | | C2, C | C4, C6, N1, N3, N | 7, M5 | | | | |
| Weight W (g) Note 2) (n: Number of SUP/EXH blocks m: Weight of DIN rail | | | | W = 51n + m + 133 | | | | | | | |

Note 1) When many valves are operated simultaneously, use B type (SUP/EXH both sides), applying pressure to the 1(P) ports on both sides and exhaust from the 3/5(E) ports on both sides.

Flow Characteristics

SJ2000

| 00200 | ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,, | | | | | | | | | | | |
|---------|---|-----------------|----------------------|------|------------------------------|------|------|--|--|--|--|--|
| Port si | ize | | Flow characteristics | | | | | | | | | |
| 1(P) | 4, 2 | | 1→2/4 (P→A/B) | | 4/2→3/5 (A/B→E) | | | | | | | |
| 3/5(E) | (A, B) | C [dm³/(s·bar)] | b | Cv | C [dm ³ /(s·bar)] | b | Cv | | | | | |
| | C2 | 0.13 | 0.55 | 0.04 | 0.13 | 0.50 | 0.04 | | | | | |
| C8 | C4 | 0.33 | 0.16 | 0.08 | 0.36 | 0.13 | 0.08 | | | | | |
| | МЗ | 0.18 | 0.52 | 0.06 | 0.20 | 0.29 | 0.06 | | | | | |

SJ3000

| Port si | ze | Flow characteristics | | | | | | | | |
|---------|--------|------------------------------|---------------|------|------------------------------|------|------|--|--|--|
| 1(P) | 4, 2 | | 1→2/4 (P→A/B) | | 4/2→3/5 (A/B→E) | | | | | |
| 3/5(E) | (A, B) | C [dm ³ /(s·bar)] | b | Cv | C [dm ³ /(s·bar)] | b | Cv | | | |
| | C2 | 0.13 | 0.56 | 0.04 | 0.14 | 0.51 | 0.04 | | | |
| C8 | C4 | 0.42 | 0.17 | 0.11 | 0.45 | 0.16 | 0.11 | | | |
| _ Co | C6 | 0.55 | 0.10 | 0.12 | 0.56 | 0.11 | 0.12 | | | |
| | M5 | 0.40 | 0.28 | 0.11 | 0.45 | 0.15 | 0.11 | | | |

Note) The value is for manifold base with 5 stations and individually operated 2 position type. Please contact SMC for 4 position dual 3 port valves.



Note 2) The weight W is the value for the D-sub connector manifold only with internal pilot, SUP/EXH block straight fittings specifications. To obtain the weight with solenoid valves attached, add the solenoid valve weights given on page 3 for the appropriate number of stations. Refer to page 61 for the weight of DIN rail. (Please contact SMC for the weight of external pilot specifications, elbow fittings.)

Plug-in Connecter Type Manifold

Series **SJ2000/3000**

P.10 D-sub Connector / Flat Ribbon Cable / PC Wiring







P.26 PC Wiring System with Power Supply Terminal



Serial Wiring: EX180





P.42 Gateway System
Serial Transmission System: EX510




Plug-in Connector Type

EX510 Gateway System Serial Transmission System

Type 60S6B Series SJ2000/3000


How to Order Manifold



| Symbol | No. of stations | Note |
|--------|-----------------|------------------------------|
| 02 | 2 stations | |
| : | :: | Up to 16 solenoids possible. |
| 16 | 16 stations | |

^{*} The number of the blanking block assembly is also included. Since single and double wiring are available with the blanking block assembly, select a model compatible with the valve wiring spec. planned for the future.

How to Order Valve Manifold Assembly



- The asterisk denotes the symbol for assembly Prefix to the part no. of the solenoid valve, etc. • The valve arrangement is numbered as the 1st station from D side.
- Indicate the valves to be attached below the manifold part number, in order starting from station 1 as shown in the drawing. In the case of complex arrangement, specify them in the manifold specification sheet.

DIN rail length specified

| | Nil | Standard length | | | | |
|---|-----|-----------------|------------------|--|--|--|
| | 3 | 3 stations | Specify a longer | | | |
| ĺ | : | : | rail than the | | | |
| ĺ | 16 | 16 stations | standard length. | | | |

* Specify the valve stations not exceeding the maximum stations.

SUP/EXH block fitting spec.

| Nil | Straight fitting With external pilot spec. X, PE port | |
|-----|---|--|
| L | Elbow fitting (Upward) With external pilot spec. X, PE port | |
| В | Elbow fitting (Downward) With external pilot spec. X, PE port | |

* There is no need to enter anything when the SUP/EXH block mounting position "M" is selected.

Pilot spec.

| Nil | Internal pilot | | | |
|---------------------------------------|--------------------------------------|--|--|--|
| S | S Internal pilot / Built-in silencer | | | |
| R | External pilot | | | |
| RS External pilot / Built-in silencer | | | | |

- * There is no need to enter anything when the SUP/EXH block mounting position "M" is selected.
- * For built-in silencers, the 3/5(E) ports are plugged.

SUP/EXH block mounting position

| | 31 |
|----|-------------------------------|
| U | U side (2 to 10 stations) |
| D | D side (2 to 10 stations) |
| В | Both sides (2 to 16 stations) |
| M* | Special specifications |


Specify the required specifications (including port sizes other than ø8) by means of the manifold specification sheet.





For details on "Gateway System Serial Transmission System Series EX510," refer to CAT.E02-22B catalog.


Dimensions

SS5J2-60S6B□D-Stations U-□









Note) Refer to page 36 for external pilot spec. and page 23 for elbow fitting manifold dimensions. Please contact SMC regarding the SI unit.


| L: Dim | ension | S | | | | | | n | : Stations |
|--------|--------|-------|-------|-------|-------|-------|-------|-------|------------|
| L | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 |
| L1 | 148 | 160.5 | 160.5 | 173 | 185.5 | 185.5 | 198 | 198 | 210.5 |
| L2 | 137.5 | 150 | 150 | 162.5 | 175 | 175 | 187.5 | 187.5 | 200 |
| L3 | 120.4 | 127.9 | 135.4 | 142.9 | 150.4 | 157.9 | 165.4 | 172.9 | 180.4 |
| 1.4 | 1/ | 16.5 | 12.5 | 15 | 17.5 | 1/1 | 16.5 | 12.5 | 15 |


44


(When equipped with switch)

Dimensions


SS5J2-60S6B□D-Stations B-□







(Station n) ----- (Station 1)





Note) Refer to page 37 for external pilot spec. and page 23 for elbow fitting manifold dimensions. Please contact SMC regarding the SI unit.


| L: Dim | ension | S | | | | | | | | | | | | n: | Stations |
|---------|--------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|----------|
| / - | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| L1 | 160.5 | 173 | 185.5 | 185.5 | 198 | 198 | 210.5 | 223 | 223 | 235.5 | 248 | 248 | 260.5 | 260.5 | 273 |
| L2 | 150 | 162.5 | 175 | 175 | 187.5 | 187.5 | 200 | 212.5 | 212.5 | 225 | 237.5 | 237.5 | 250 | 250 | 262.5 |
| L3 | 135.9 | 143.4 | 150.9 | 158.4 | 165.9 | 173.4 | 180.9 | 188.4 | 195.9 | 203.4 | 210.9 | 218.4 | 225.9 | 233.4 | 240.9 |
| L4 | 12.5 | 15 | 17.5 | 13.5 | 16 | 12.5 | 15 | 17.5 | 13.5 | 16 | 18.5 | 15 | 17.5 | 13.5 | 16 |



How to Add Manifold Stations








Loosen threads ⓐ, which are fixed onto the DIN rail (two locations on one side).

In the direction of the coil, slide the valve where the station is desired to add and the valve lock switch on

If blocks are removed without completely releasing the valve lock switch, the connection hook of that switch could be damaged or deformed.

3 Install an additional valve or an SUP/EXH assembly on the DIN rail.



A manifold equipped with a valve or a block assembly can be mounted on the DIN rail. However, a serial connector block assembly cannot be mounted on the DIN rail when it is connected with another block; the serial connector block must be mounted separately.

Press the valves and block assemblies to each other for connection. Press the valve lock switch in the cylinder port direction until it does not go any further. Fasten threads ⓐ onto the DIN rail.

After fixing the connector block assembly, fasten the threads onto the end block assembly while holding it lightly by hand. This is necessary to improve sealing.

⚠ Caution

D-sub, Connector block assembly for flat ribbon cable, End block assembly M3: 0.6 N⋅m Connector block assembly for EX180 serial wiring M4: 1.4 N⋅m Mounting bracket for EX510 serial wiring M4: 0.6 N⋅m

Caution

- 1. When increasing the number of stations from 10 or below to 11 or above, increase the number of SUP/EXH assemblies as well.
- 2. Be sure to turn off the power and stop the supply of air before disassembly. Furthermore, since air may remain inside the actuator, piping and manifold, confirm that the air is completely exhausted before performing any work.
- 3. After assembly and disassembly, air leakage could occur if blocks are not well connected or a thread is not tightly fastened onto the end block assembly. Before supplying air, make sure that no gaps exist in between blocks and that the valve and block are tightly fastened onto the DIN rail. Also, make sure that air is not leaking before use.
- 4. For the SJ3A6 series manifold with vacuum release valve with restrictor, there is no valve lock switch for connecting, so when mounting, tighten the screws after checking that there are no gaps between valves.



Series SJ2000/3000 Manifold Options

■ SUP block disk assembly


By placing a SUP block disk in a manifold valve's pressure supply passage, two different high and low pressures can be supplied to one manifold. When supplying different pressures using the manifold of the internal pilot, fill out a manifold specification sheet to place an order for an SUP/EXH assembly for the internal pilot specifications and another SUP/EXH assembly for the different-pressure internal pilot specifications (Refer to Circuit Diagram 1).




| Series | Part no. |
|--------|---------------|
| SJ2000 | S.I3000-44-1A |
| SJ3000 | 303000-44-1A |

[Different pressure pneumatic circuit diagram]


- The SJ series supplies air to the pilot port of each valve using a 1(P) port of the SUP/EXH block assembly. When using in situations such as where there are different pressures, combine SUP/EXH block assemblies for internal pilot, external pilot and different-pressure by referring to the circuit below.
- 1. Different-pressure spec. using the internal pilot



2. Different-pressure spec. using the external pilot (For using the SUP/EXH block assembly for external pilot)



3. Different-pressure spec. using the external pilot (For using the SUP/EXH block assembly for different-pressure internal pilot spec.)



Note 1) When operating under the different-pressure spec., supply the higher pressure to the pilot passage. Note 2) If there is a need to partition the pilot passage, consult SMC.



■ EXH block disk assembly

By installing an EXH block disk in a manifold valve's exhaust passage, the valve's exhaust can be separated so that it will not affect other valves.



| Series | Part no. |
|--------|--------------|
| SJ2000 | SJ3000-44-1A |
| SJ3000 | 333000-44-1A |

■ Label for block disk

These labels are attached to manifolds in which SUP and EXH block disks have been installed, in order to identify the installed locations. (Three sheets each included.)

SJ3000-155-1A

Label for SUP/EXH block disk




Label for SUP block disk



Label for EXH block disk




* When a block disk is concurrently ordered by specifying on the manifold specification sheet, etc., a label will be stuck on the position where block disk is mounted.



■ Blanking block assembly

These are mounted when later addition of valves is planned, etc.




| Series | Part no. | Note | Width |
|--------|----------------|---------------------|--------|
| SJ2000 | SJ3000-49-1A | Single wiring | |
| SJ3000 | SJ3000-49-2A | Double wiring | 7.5 mm |
| SJ3A6 | SJ3000-49-2A-N | Double wiring Note) | |

Note) Valve lock switch is not available for the SJ3A6.

■ Silencer with one-touch fitting


This silencer can be mounted on the manifolds' port 3/5 (E: Exhaust) with a single touch.



| Series | Model | Effective area | Α | В | С |
|-----------------|-----------|----------------|-----|----|----|
| For SJ2000 (ø8) | AN203-KM8 | 14 mm² | ø16 | 26 | 51 |

■ Plug


These are inserted in unused cylinder ports and P, E ports.




Dimensions

| Applicable fitting size ø d | Model | Α | L | D |
|------------------------------------|---------|------|------|-----|
| 2 | KJP-02 | 8.2 | 17 | 3 |
| 4 | KQ2P-04 | 16 | 32 | 6 |
| 6 | KQ2P-06 | 18 | 35 | 8 |
| 8 | KQ2P-08 | 20.5 | 39 | 10 |
| 1/8" | KQ2P-01 | 16 | 31.5 | 5 |
| 5/32" | KQ2P-03 | 16 | 32 | 6 |
| 1/4" | KQ2P-07 | 18 | 35 | 8.5 |
| 5/16" | KQ2P-09 | 20.5 | 39 | 10 |

■ DIN rail



* Enter a number from the DIN rail dimension table shown below.




| No. | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |
|-------------|------|-------|------|-------|------|-------|------|-------|------|-------|
| L dimension | 98 | 110.5 | 123 | 135.5 | 148 | 160.5 | 173 | 185.5 | 198 | 210.5 |
| Weight (g) | 17.6 | 19.9 | 22.1 | 24.4 | 26.6 | 28.9 | 31.1 | 33.4 | 35.6 | 37.9 |

| No. | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 |
|-------------|------|-------|------|-------|------|-------|------|-------|------|-------|
| L dimension | 223 | 235.5 | 248 | 260.5 | 273 | 285.5 | 298 | 310.5 | 323 | 335.5 |
| Weight (g) | 40.1 | 42.4 | 44.6 | 46.9 | 49.1 | 51.4 | 53.6 | 55.9 | 58.1 | 60.4 |

| No. | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 |
|-------------|------|-------|------|-------|------|-------|------|-------|------|-------|
| L dimension | 348 | 360.5 | 373 | 385.5 | 398 | 410.5 | 423 | 435.5 | 448 | 460.5 |
| Weight (g) | 62.6 | 64.9 | 67.1 | 69.4 | 71.6 | 73.9 | 76.1 | 78.4 | 80.6 | 82.9 |



■ Flat ribbon cable assembly AXT100 - FC □ -2



Flat Ribbon Cable Assembly


| Cable length (L) | 10 pins | 20 pins | 26 pins |
|---------------------|---------------|---------------|---------------|
| 1.5 m | AXT100-FC10-1 | AXT100-FC20-1 | AXT100-FC26-1 |
| 3 m | AXT100-FC10-2 | AXT100-FC20-2 | AXT100-FC26-2 |
| 5 m | AXT100-FC10-3 | AXT100-FC20-3 | AXT100-FC26-3 |
| Connector width (W) | 17.2 | 30 | 37.5 |

^{*} For other commercial connectors, use a type with strain relief that conforms to MIL-C-83503.

Connector manufacturers:

- Hirose Electric Co., Ltd.
- Sumitomo 3M Limited
- Fujitsu Limited
- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.

■ D-sub connector (25 pins)/Cable assembly AXT100 - DS25-030 050



D-sub Connector Cable Assembly Cable Color List of Each Terminal No.

| Terminal no. | Lead wire color | Dot marking |
|--------------|-----------------|-------------|
| 1 | Black | None |
| 2 | Brown | None |
| 3 | Red | None |
| 4 | Orange | None |
| 5 | Yellow | None |
| 6 | Pink | None |
| 7 | Blue | None |
| 8 | Purple | White |
| 9 | Gray | Black |
| 10 | White | Black |
| 11 | White | Red |
| 12 | Yellow | Red |
| 13 | Orange | Red |
| 14 | Yellow | Black |
| 15 | Pink | Black |
| 16 | Blue | White |
| 17 | Purple | None |
| 18 | Gray | None |
| 19 | Orange | Black |
| 20 | Red | White |
| 21 | Brown | White |
| 22 | Pink | Red |
| 23 | Gray | Red |
| 24 | Black | White |
| 25 | White | None |

D-sub Connector Cable Assembly

| Cable length (L) | Assembly part no. | Note |
|---------------------------|-------------------|----------|
| 1.5 m | AXT100-DS25-015 | Cable 25 |
| 3 m | AXT100-DS25-030 | cores x |
| 5 m | AXT100-DS25-050 | 24AWG |
| | | |

For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308.

Electric Characteristics

| Licoti io Orial actoriotico | | | | | | |
|---|----------------------|--|--|--|--|--|
| Item | Charac- teristics | | | | | |
| Conductor resistance Ω /km, 20°C | 65 or less | | | | | |
| Withstand pressure V, 1 min, AC | 1000 | | | | | |
| Insulation resistance MΩkm, 20°C | 5 or less | | | | | |

Note) The minimum bending radius for D-sub connector cables is 20 mm.

Connector manufacturers:


- Hirose Electric Co., Ltd.
- Fujitsu Limited
- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.

4 Port Solenoid Valve Series SJ2000/3000

■ Regulator block

How to Order Regulator Block


This is used to reduce the pressure supplied from the D side inside the manifold. All valves on the U side are depressurized from the regulator block.




Note) When ordering with a regulator block installed in the manifold, please order using the manifold specification sheet.

Flow Characteristics (Conditions: Inlet pressure 0.7 MPa 2 position solenoid valve mounting)


SJ3000 P port regulation (P→A, B) 0.8 0.7 0.6 Outlet pressure (MPa) 0.5 0.4 0.3 0.2 0.1 160 0 20 40 60 80 100 120 140 Flow rate (d/min (ANR))



Pneumatic circuit (Regulator block mounting example)



Supply pressure from the U side cannot be reduced.






■ Intermediate connector block assembly


This connector block can be used by inserting it into the middle of the manifold.

This can be used, for example, when you wish to separate electrical control of valves in the same manifold, or when the number of control points is insufficient.




Note) When ordering with an intermediate connector block assembly installed in the manifold, please order using the manifold specification sheet.

Intermediate connector block assembly wiring example



* Enables control of U side solenoid valves from the position where the intermediate connector block assembly is installed.



■ Dual flow fitting (Set for SJ3000 series)

SJ3000-120-1A-C8

● Port size

C8 Ø8

N9 Ø5/16"

This is a fitting for cylinder ports which enables simultaneous actuation and increase in flow rate of valves for 2 stations. This is a one-touch fitting with port sizes of $\emptyset 8$ and $\emptyset 5/16$.

* When arranging mounted to the valve, arrange the valve part no. using the part no. without the one-touch fitting, and then add the part no. for the dual flow fitting. If the arrangement is complicated, please specify them by means of the manifold specification sheet.

Example) Valve type (without one-touch fitting)

SJ3160-5CU-CO ----- 2 sets * SJ3000-120-1A-C8 ---- 1 set

